



COMMANDO Solider E2000 Series Managed Switches COMMAND Line Interface (CLI)

Software Version 1.4 onwards

INTRODUCTION

COMMANDO Soldier E2000 Series Switches are fully managed, PoE+ Gigabit Ethernet L2+ switch with network resiliency and high availability, delivering robust performance and intelligent switching for growing networks. This series switches are easy to deploy, use, manage and designed exclusively for the networking needs of growing businesses. The security features equipped with today's advance networking hardware and software technology. This Series switches can be deployed in harsh environments to deliver hassle free mission-critical network services and surveillance requirements.

COMMANDO Soldier E2000 Series Switches Series are fixed-configuration, with flexible uplinks Gigabit Ethernet switches that provide enterprise-class access for campus and branch applications. Designed for the digital workplace, these are optimized for today's mobile and IoT needs. These switches are powerful and flexible enough for users to deploy wireless access points, surveillance cameras, IP phones and other PoE supported devices over longer distances up to 250 meters. COMMANDO Soldier E2000 Series provide easy device Desktop as well as Rack/Wall mounting, on boarding, configuration, monitoring, and troubleshooting. These fully managed switches can provide advanced Layer 2 and basic Layer 3 features as well as supports IEEE 802.3af-compliant PoE (Power over Ethernet) and 802.3at-compliant PoE+ (Power over Ethernet plus). Each switchport is capable to deliver 15.4 W PoE or 30 W PoE+ power on all ports along with automated power (ON/OFF) scheduling. All Switches are PoE/PoE+ capable to provide power across all access ports for wireless APs, security cameras, and other IoT devices. Designed for operational simplicity to lower total cost of ownership, they enable scalable, secure, and energy-efficient business operations with intelligent and automated services.

COMMANDO Soldier E2000 Series Switches Series provides a convenient and cost-effective wired access Rack and Wall mountable solution that can be quickly set up with Zero Touch Provisioning. Theses switches deliver enhanced application, visibility, network reliability, and network resiliency and high availability.

COMMANDO Soldier E2000 Series Switches has wire-speed back haul bandwidth capacity with flexible up to 1 Gigabit Ethernet copper/Fiber uplinks. This series also offers robust QoS, To optimize traffic on your Business Network, these switches provide (Port-based/802.1p/DSCP) QoS to keep latency-sensitive video and voice traffic jitter-free moving smoothly. Additionally, port-based, tag-based VLAN, Voice Vlan can improve security and meet more network segmentation requirements. This series switches also have provisioning of QOS, Static routing, IPV6 features. Moreover, with its innovative energy-efficient technology, can save up to 58% of power consumption, making it an Eco-friendly perfect solution for your business network.

The COMMANDO SoldierOS IP Base switches provides CLI and WEBUI based PoE/PoE+ scheduling Premium feature. PoE/PoE+ Scheduling is a feature which allows you to specify the amount of time at scheduled time that power is delivered to a PoE/PoE+ port automatically making Switch intelligent . This not only can be used to save power when devices are not in use,

but as a security feature to prevent wireless access from being available outside of business hours. It is possible to set a schedule for PoE/PoE+, a start time, an end time and which ports the PoE/PoE+ schedule applies to.

ADMINISTRATION

General commands used in E2000 Series Switches are described in the Administration. The switch administration is to perform some basic switch administration tasks.

1.1 CONFIGURE

Use “**configure terminal**” command to enter global configuration mode. In global configuration mode, the prompt will show as “**Switch(config)#**”.

```
Switch#configure terminal
```

```
Switch(config)#
```

Syntax **configure**

Mode Privileged EXEC

This example shows how to enter global configuration mode.

Example
Switch#configure terminal **terminal**
Switch(config)#



```
Switch#  
Switch# configure terminal  
Switch(config)#
```

1.2 CLEAR ARP

Use “**clear arp-cache**” command to clear all or specific one arp

entry. Switch#**clear arp-cache**

Syntax **clear arp-cache**

Mode User EXEC Privileged EXEC

This example shows how to clear all arp entries.

Switch#**clear arp-cache**

Example
e

```
Switch# show arp
      VLAN Interface  IP address      HW address      Status
-----
Vlan 1          192.168.0.21    28:02:44:0a:7a:70  Dynamic
Total number of entries: 1
Switch# clear arp-cache
```

Used to clear the non aged out unavailable ARP entries

1.3 CLEAR SERVICE

Use “clear service” command to kill all existing sessions for the select service.

Switch#	clear (authentication gvrp interfaces ip ipv6 l2cp line lldp logging mac mvr port- security rmon spanning-tree)
Syntax	clear (authentication gvrp interfaces ip ipv6 l2cp line lldp logging mac mvr port- security rmon spanning-tree)
Mode	Privileged EXEC

This example shows how to clear interfaces,

Switch# clear interfaces GigabitEthernet 1 counters

Example

```
Switch# show interfaces gi
GigabitEthernet1 is up
Hardware is Gigabit Ethernet
Description: Auto-sensed media type is Copper
Speed: 1000000000 bps, media type is Copper
1000000000 bps, 1000000000 bytes, 0 discarded packets
0 errors, 0 discards, 0 discarded packets
0 input errors, 0 CRC, 0 frame
0 input packets with double checksum detected
Last 5 minutes input rate 1489 bits/sec, 1 packets/sec
1000000000 bytes output, 1000000000 bytes, 0 discarded packets
0 broadcast, 0 multicast, 0 unicast
0 output errors, 0 collisions
0 hardware, 0 late collisions, 0 deferred
0 PFC0 output
Last 5 minutes output rate 894 bits/sec, 1 packets/sec
Switch# clear interfaces gi counters
Switch# show interfaces gi
GigabitEthernet1 is up
Hardware is Gigabit Ethernet
Description: Auto-sensed media type is Copper
Speed: 1000000000 bps, media type is Copper
1000000000 bps, 1000000000 bytes, 0 discarded packets
0 errors, 0 discards, 0 discarded packets
0 input errors, 0 CRC, 0 frame
0 input packets with double checksum detected
Last 5 minutes input rate 1392 bits/sec, 0 packets/sec
1000000000 bytes output, 1000000000 bytes, 0 discarded packets
0 broadcast, 0 multicast, 0 unicast
0 output errors, 0 collisions
0 hardware, 0 late collisions, 0 deferred
0 PFC0 output
Last 5 minutes output rate 1392 bits/sec, 0 packets/sec
```

1.4 ENABLE

In User EXEC mode, user only allows to do a few actions. Most of commands are only available in privileged EXEC mode. Use “enable” command to enter the privileged mode to do more actions on switch. In privileged EXEC mode, use “exit” command is able to go back to user EXEC mode with original user privilege level. If you need to go back to user EXEC mode with different privilege level, use “disable” command to specify the privilege level you need. In privileged EXEC mode, the prompt will show “Switch#”.

Switch>enable [<1-15>]

Switch#disable [<1-14>]

X

Synta

enable [*<1-15>*] disable [*<1-14>*]

Parameter	<i><1-15></i>	Specify privileged level to enable
	<i><1-14></i>	Specify privileged level to disable

Default privilege level is 15 if no privilege level is specified on enable command.

Default

Default privilege level is 1 if no privilege level is specified on disable command.

Mode User EXEC

This example shows how to enter privileged EXEC mode and show current privilege

level. Switch>**enable**

Password:

Switch# **show privilege**

Example

```
Switch> enable
Password:
Switch# show privilege
Current Priv: Privilege: admin
Current GUI Privilege: 15
```

Switch# **disable**

Switch>

```
Switch# disable
Switch>
```

1.5 END

Use “**end**” command to return to privileged EXEC mode directly. Every mode except User EXEC mode has the “**end**” command.

Switch#**configure terminal**

Switch(config)# **interface GigabitEthernet 1**

Switch(config-if)# **end**

Syntax **end**

Privileged EXEC Global Configuration

Mode Interface Configuration

Line
Conf
gurat
ion

This example shows how to enter Interface Configuration mode and use end command to go back to privileged EXEC mode


Switch#**configure terminal**

Examp
le

Switch(config)# **interface GigabitEthernet 1**

Switch(config-if)# **end**

Switch#



```
Switch# configure terminal
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# end
Switch#
```

1.6 EXIT

In User EXEC mode, “**exit**” command will close current CLI session. In other modes, “**exit**” command will go to the parent mode. And every mode has the “**exit**” command.

Switch# **exit**

Syntax **exit**

Mode User EXEC Privileged EXEC Global Configuration Interface Configuration Line Configuration

This example shows how to enter privileged EXEC mode and use exit command to go back to user EXEC mode.

Switch>**enable**

Example

Switch# **exit**

Switch>

```
Switch> enable
Switch#
Switch# exit
Switch>
```

1.7 HISTORY

Use “**history**” command to specify the maximum commands history number for CLI running on console, telnet or ssh service. Every command input by user will record in history buffer. If all history commands exceed configured history number, older ones will be deleted from buffer. Use “**no history**” to disable the history feature. And use “show history” to show all history commands.

```
Switch#configure terminal
```

```
Switch(config)# line console
```

```
Switch(config-line)# history
```

```
100 Switch(config-line)# exit
```

	history <1-256>
Synta	
x	no history

Parameter <1-256>Specify maximum CLI history entry

number. Default Default maximum history entry number is

128.

Mode	Line Configuration
------	--------------------

This example shows how to change console history number to 100, telnet history number to 150 and ssh history number to 200.

```
Switch#configure terminal
```

```
Switch(config)# line console
```

```
Switch(config-line)# history
```

```
100 Switch(config-line)# exit
```

```
Switch(config)# line telnet
```

```
Switch(config-line)# history
```

```
150 Switch(config-line)# exit
```

```
Switch(config)# line ssh
```

```
Switch(config-line)# history
```

```
200 Switch(config-line)# exit
```

This example shows how show line information.

```
Switch# show line
```

```
Switch(config)# line telnet
Switch(config-line)# history 100
Switch(config-line)# exit
Switch# show line
Console -----
Session Timeout : 10 (minutes)
History Count : 100
Password Entry : 3
Silent Time : 0 (seconds)
Telnet -----
Telnet Server : enabled
Session Timeout : 10 (minutes)
History Count : 150
Password Entry : 3
Silent Time : 0 (seconds)
SSH -----
SSH Server : enabled
Session Timeout : 10 (minutes)
History Count : 200
Password Entry : 3
Silent Time : 0 (seconds)
```

This example shows how show history

```
Switch# show history
```

```
Switch# show history
=====
1. exit
2. enable
3. exit
4. enable
5. configure
6. interface GigabitEthernet 1
7. exit
8. enable
9. exit
10. enable
11. configure
12. line console
13. history 100
14. exit
15. line telnet
16. history 150
17. exit
18. line ssh
19. history 200
20. exit
21. show history
```

1.8 HOSTNAME

Use “**hostname**” command to modify hostname of the switch. The system name is also used to be CLI prompt.

Switch#**configure terminal**

Switch(config)# **hostname** *{WORD}*

Syntax **hostname** *{WORD}*

Parameter *WORD* Specify the hostname of the

switch. Default Default name string is

“Switch”.

Mode Global Configuration

This example shows how to modify contact information

Switch#**configure terminal**

Example Switch(config)# **hostname commando**

commando(config)#



```
Switch(config)# hostname commando
commando(config)#
```

1.9 INTERFACE

Some configurations are port based. In order to configure these configurations, we need to enter Interface Configuration mode to configure them. Use “**interface**” command to enter the Interface Configuration mode and select the port to be configured. In Interface Configuration mode, the prompt will show as “**Switch(config- if)#**”

Switch#**configure terminal**

Switch(config)# **interface** *{IF_PORTS}*

Switch(config)# **interface range** *{IF_PORT starting - IF_PORT ending }*

Syntax
x **interface** *{IF_PORTS}*
interface range *{IF_PORTS}*

IF_PORTS Specify the port to select. This parameter allows partial port name and ignore case. For Example:

GigabitEthernet 1, GigabitEthernet2, GigabitEthernet3 and

Parameter so on If port range is specified, the list format is also available.

For Example:

gi1,3,5

gi2,gi1-3

Mode Global Configuration

Usage Some configurations are port based. In order to configure these configurations, we need to enter Interface Configuration mode to configure them. Use “interface” command to enter the Interface Configuration mode and select the port to be configured. In Interface Configuration mode, the prompt will show as “**Switch(config- if)#**”

This example shows how to enter Interface Configuration

mode Switch#**configure terminal**

Switch(config)# **interface GigabitEthernet 1**

Switch(config-if)#

Example

```
Switch# configure terminal
Switch(config)# interface GigabitEthernet 1
Switch(config-if)#
```

Switch#**configure terminal**

Switch(config)# **interface range GigabitEthernet 1-3**

Switch(config-if-range)#

```
Switch#
Switch# configure terminal
Switch(config)# int range 1-3
Switch(config-if-range)#
```

1.10 IP ADDRESS

Use “**ip address**” command to modify administration ipv4 address. This address is very important. When we try to use telnet, ssh, http, https, snmp to connect to the switch, we need to use this ip address to access E2000 series switches.

Note:- By default Switch is having 192.168.0.1 as access IP.

Switch#**configure terminal**

Switch(config)# **ip address** {A.B.C.D} [**mask** {A.B.C.D}]

Syntax **ip address** A.B.C.D [**mask** A.B.C.D]

Parameter
address A.B.C.D Specify IPv4 address for switch
mask A.B.C.D Specify net mask address for switch

Default Default IP address is 192.168.0.1 and default net mask is

255.255.255.0. Mode Global Configuration

This example shows how to modify the ipv4 address of the switch.

Default setting of E2000 series Switches

```
Switch# show ip
##### Config #####
IP Address: 192.168.0.1
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.0.254

##### Status #####
IP Address: 192.168.0.1
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.0.254
```

Switch#configure terminal


Switch(config)# ip address 192.168.1.1 mask 255.255.255.0

```
Switch# configure terminal
Switch(config)# ip address 192.168.1.1 mask 255.255.255.0
```

After this configuration you can access Switch with 192.168.1.1 IP address.

Example

Accessing New IP address with Telnet.



This way to access with newly set IP address.

```
Username: admin
Password: *****
Switch# show ip
##### Config #####
IP Address: 192.168.1.1
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.0.254

##### Status #####
IP Address: 192.168.1.1
Subnet Mask: 255.255.255.0
Default Gateway: 0.0.0.0
```

1.11 DEFAULT-GATEWAY

Use “**ip default-gateway**” command to modify default gateway address. And use “**no ip default-gateway**”

to restore default gateway address to factory

default. Switch#**configure terminal**

Switch(config)# **ip default-gateway {A.B.C.D}**

Switch(config)# **no ip default-gateway**

ip default-gateway {A.B.C.D}

Synta

x **no ip default-gateway**

Parameter *A.B.C.D* Specify default gateway IPv4 address for

switch Default Default IP address of default gateway is

192.168.0.254. Mode Global Configuration

This example shows how to modify the ipv4 address of the switch.

Switch#**configure terminal**

Switch(config)# **ip default-gateway 192.168.1.10**

Examp
le

This example shows how to show current ipv4 default gateway of the switch.

```
Switch# conf t
Switch(config)# ip default-gateway 192.168.1.10
Switch(config)# do sh ip
##### Config #####
IF Address: 192.168.1.1
Subnet: 255.255.255.0
Default Gateway: 192.168.1.10

##### Status #####
IF Address: 192.168.1.1
Subnet: 255.255.255.0
Default Gateway: 192.168.1.10
```


1.13 IPV6 AUTOCONFIG

Use “**ipv6 autoconfig**” command to enabled IPv6 auto configuration feature. Use “**no ipv6 autoconfig**”

command to disabled IPv6 auto configuration feature.

```
Switch#configure terminal
```

```
Switch(config)# ipv6 autoconfig
```

```
Switch(config)# no ipv6 autoconfig
```

ipv6 autoconfig

Synta

x **no ipv6**

autoconfig

Default Default IPv6 auto config is

enabled. Mode Global Configuration

This example shows how to enable IPv6 auto config.

```
Switch#configure terminal
```

```
Switch(config)# ipv6 autoconfig
```

Example This example shows how to show current IPv6 auto config state.

```
Switch# show ipv6
```

```
Switch# config t
Switch(config)# ipv6 autoconfig
Switch(config)# do sh ipv6
##### Config #####
  State: enabled
  Auto Config: enabled
  DHCPv6: disabled
  Gateway: 1
##### State #####
  IP Address: fe80::2a01:4c0f::fe0010/64
  Default Gateway: 1
```

1.14 IPV6 ADDRESS

Use “**ipv6 address**” command to specify static IPv6 address.

Switch#**configure terminal**

Switch(config)# **ipv6 address {X:X::X:X} prefix <0-128>**

Syntax **ipv6 address X:X::X:X prefix <0-128>**

Parameter **address X:X::X:X** Specify IPv6 address for switch

prefix <0-128> Specify IPv6 prefix length for switch

Mode Global Configuration

This example shows how to add static ipv6 address of the

switch. Switch#**configure terminal**

Switch(config)# **ipv6 address fe80::20e:2eff:fe1:4b3c prefix**

Example **128** This example shows how to show current ipv6 address of

the switch. Switch# **show ipv6**

```
Switch(config)# ipv6 address fe80::20e:2eff:fe1:4b3c prefix 128
Switch(config)# exit
Switch# show ipv6
##### Config #####
Status: enabled
Auto Config: enabled
DHCPv6: disabled
Gateway: ::
IP Address: fe80::20e:2eff:fe1:4b3c/128

##### Status #####
IP Address: fe80::2e0:4c0ff:fe00:0/64
IP Address: fe80::20e:2eff:fe1:4b3c/128
Default Gateway: ::
```

1.15 IPV6 DEFAULT-GATEWAY

Use “**ipv6 default-gateway**” command to modify default gateway IPv6.

Switch#**configure terminal**

Switch(config)# **ipv6 default-gateway {X:X::X:X}**

Syntax **ipv6 default-gateway {X:X::X:X}**

Parameter X:X::X:X Specify default gateway IPv6 address for

switch Mode Global Configuration

This example shows how to modify the ipv6 default gateway address of the switch.

Switch#**configure terminal**

Switch(config)# **ipv6 default-gateway fe80::dcad:beff:feef:103**

Example

Switch# **show ipv6**

```
Switch(config)# ipv6 default-gateway fe80::dcad:beff:feef:103
Switch(config)# exit
Switch# show ipv6
##### Config #####
  Status: enabled
  Auto Config: enabled
  DHCPv6: disabled
  Gateway: fe80::dcad:beff:feef:103
  IP Address: fe80::20e:12eff:fe1:4b3c/128
##### Status #####
  IP Address: fe80::2e0:4cfff:fe00:0/64
  TE Address: fe80::20e:12eff:fe1:4b3c/128
  Default Gateway: :
```

1.16 IPV6 DHCP

Use “**ipv6 dhcp**” command to enabled dhcpv6 client to get IP address from remote DHCPv6 server. Use

“**no ipv6 dhcp**” command to disabled dhcpv6 client and use static ipv6 address or ipv6 auto config

address. Switch#**configure terminal**

Switch(config)# **ipv6 dhcp**

Switch(config)# **no ipv6 dhcp**

	ipv6 dhcp
Synta	
x	no ipv6 dhcp

Default Default DHCPv6 client is

disabled. Mode Global Configuration

This example shows how to enable dhcp client.

Switch#**configure terminal**

Switch(config)# **ipv6 dhcp**

Examp
e This example shows how to show current dhcpv6 client state of the switch. Switch# **show ipv6**

```
Switch(config)# ipv6 dhcp
Switch(config)# exit
Switch# show ipv6
##### Config #####
  Status: enabled
  Auto Config: enabled
  DHCPv6: enabled
  Gateway: fe80::dca:d1:beff::fe0f:103
  IP Address: fe80::20e:2eff:fe11:4b3c/128
##### Status #####
  IP Address: fe80::2e0:4c1ff:fe50:0/64
  IP Address: fe80::20e:2eff:fe21:4b3c/128
  Default Gateway: ::
Switch#
```

1.17 IP SERVICE

This is one of very important command to enable/disable management access via CLI. Use “**ip (telnet | ssh | http | https)**” command to enable all kinds of management services. Such as telnet, ssh, http and https from CLI.

```
Switch#configure terminal
```

```
Switch(config)# ip (telnet | ssh | http | https)
```

```
Switch(config)# no ip (telnet | ssh | http | https)
```

```
Syntax
ip (telnet | ssh | http | https)
no ip (telnet | ssh | http | https)
```

```
telnet Enable/Disable telnet
```

```
Parameter
service ssh Enable/Disable ssh
service
```

```
http Enable/Disable http service
```

```
https Enable/Disable https
```

```
service
```

```
Default telnet service is disabled.
```

```
Default ssh service is disabled.
```

```
Default
Default http service is enabled.
```

```
Default https service is disabled.
```

```
Mode Global Configuration
```

This example shows how to enable telnet service and show current telnet service status.

```
Switch#configure terminal
```

```
Switch(config)# ip telnet
```

Telnet daemon enabled.

```
Switch(config)# exit
```

```
Switch# show line telnet
```

Example
e

```
Switch(config)# ip telnet
Switch(config)# exit
Switch# show line telnet
Telnet
-----
Telnet Server : enabled
Session Timeout : 10 (minutes)
History Count : 10
Password Retry : 3
Silent Time : 0 (seconds)
```

This example shows how to enable https service and show current https service status.

```
Switch#configure terminal
```

```
Switch(config)# ip https
```

```
Switch(config)# exit
```

```
Switch# show ip https
```

```
Switch# configure
Switch(config)# ip https
Switch(config)# exit
Switch# show ip https
HTTP daemon : enabled
Session Timeout : 10 (minutes)
```

1.18 IP SESSION-TIMEOUT

Use “**ip session-timeout**” command to specify the session timeout value for http or https service. When user login into WEBGUI and do not do any action after session timeout will be logged out.

Switch#**configure terminal**

Switch(config)# **ip (http | https) session-timeout <0-86400>**

Syntax **ip (http | https) session-timeout <0-86400>**

httpSpecify session timeout for http

Parameter service. https Specify session timeout for
er

https service.

<0-86400>Specify session timeout minutes. 0 means never timeout.

Default Default session timeout for http and https is 10

minutes. Mode Global Configuration

1.19 IP SSH

Example

This example shows how to change http session timeout to 15min and https session timeout to 20min

Switch#co

configure terminal

Switch(config)# **ip http session-timeout 15**

```
Switch(config)# ip http session-timeout 15
Switch(config)# ip https session-timeout 20
Switch(config)# exit
Switch# show ip http
  HTTP daemon : enabled
Session Timeout : 15 (minutes)
Switch# show ip https
  HTTPS daemon : enabled
Session Timeout : 20 (minutes)
```

Switch(config)# **ip https session-timeout 20**

This example shows how to enable https service and show current https service status. Switch# **show ip http**

Switch# **show ip https**

Use “**ip ssh**” command to generate the key files for ssh connection. Switch#**configure terminal**

Switch(config)# ip ssh (v1|v2|all)

Switch(config)# no ip ssh (v1|v2|all)

Syntax ip ssh (v1|v2|all)

x no ip ssh

(v1|v2|all)

v1 Generate/Delete version 1 key

Parameter files v2 Generate/Delete version 2

key files

all Generate/Delete version 1 and 2 key files

Default Version 2 key files will be generated by

default Mode Global Configuration

1.20 LINE

Example

T
h
i
s

e
x
a
m
p
l
e

s
h
o
w

show how to delete and re-generate ssh version 2 key files.


Switch#configure terminal

Switch(config)# no ip ssh v2

Switch(config)# do show flash

Switch(config)# ip ssh v2

Switch(config)# do show flash



```
Switch(config)# no ip ssh v2
Switch(config)# do show flash
File Name      File Size      Modified
-----
startup-config 1480           2018-01-01 00:18:55
vsa_certs     1245           2018-01-01 00:00:45
image        8554240        2018-11-17 18:36:59
Switch(config)# ip ssh v2
Switch(config)# do show flash
File Name      File Size      Modified
-----
startup-config 1480           2018-01-01 00:18:55
vsa_certs     1245           2018-01-01 00:26:55
image        8554240        2018-11-17 18:36:59
```

Some configurations are line based. In order to configure these configurations, we need to enter Line Configuration mode to configure them. Use “line” command to enter the Line Configuration mode and select the line to be configured. In Line Configuration mode, the prompt will show as “Switch(config-line)#”

Switch#configure terminal

Switch(config)# line (console | telnet | ssh)

Syntax line (console | telnet | ssh)

console Select console line to

configure. ParameterTelnet Select

telnet line to configure.

Ssh Select ssh line to configure.

Mode Global Configuration

This example shows how to enter Interface Configuration mode

Switch# **configure**

Example Switch(config)# **line**

console Switch(config-

line)#

```
Switch# configure
Switch(config)# line console
Switch(config-line)#
```

1.21 REBOOT

Use “**reboot**” command to make system hot restart. Switch will be Power OFF and again ON (Restart) with this command.

Switch#**reboot**

Syntax

reboot

t

Mode Privileged EXEC

This example shows how to restart the system

Example

```
Switch# reboot
```

Switch# **reboot**

1.22 ENABLE PASSWORD

Use “**enable password**” command to edit password for each privilege level for enable authentication. Use “**no enable**” command to restore enable password to default empty value. The only way to show this configuration is using “**show running-config**” command.

Switch#**configure terminal**

```
Switch(config)# enable [privilege <1-15>] (password UNENCRYPY-PASSWORD |  
secret UNENCRYPY-PASSWORD | secret encrypted ENCRYPT-PASSWORD)
```

```
Switch(config)# no enable [privilege <0-15>]
```

```
enable [privilege <1-15>] (password UNENCRYPT-PASSWORD |  
secret UNENCRYPT-PASSWORD | secret encrypted ENCRYPT-  
PASSWORD) no enable [privilege <0-15>]
```

Syntax

privilege <0-15> Specify the privilege level to configure. If no privilege level is specified, default is 15.

password UNENCRYPT- Specify password string and make it not encrypted.

Parameter

secret UNENCRYPT- PASSWORD Specify password string and make it encrypted.

secret encrypted ENCRYPT- PASSWORD Enter an encrypted password. Use this keyword to enter a password that is already encrypted (for instance, a password that you copied from another the configuration file of another device).

Default

No default enable password for all privilege levels.

Mode

Global Configuration

1.23 EXEC-TIMEOUT

Use “**exec-timeout**” command to specify the session timeout value for CLI running on console, telnet or ssh service. When user login into CLI and do not do any action after session timeout will be logged out from the CLI session.

```
Switch#configure terminal
```

```
Switch(config)# line console
```

```
Switch(config-line)# exec-timeout <0-65535>
```

Syntax **exec-timeout** <0-65535>

Parameter <0-65535>Specify session timeout minutes. 0 means never

timeout Default Default session timeout for all lines are 10 minutes.

Mode Line Configuration

This example shows how to change console session timeout to 15min, telnet session timeout to 20min and ssh session timeout to 25min. Timeout after specified minutes (0 means no timeout)

```
Switch#configure terminal
```

```
Switch(config)# line console
```

```
Switch(config-line)# exec-timeout
```

```
15 Switch(config-line)# exit
```

```
Switch(config)# line telnet
```

```
Switch(config-line)# exec-timeout
```

```
20
```

```
Switch(config-line)# exit
```

```
Switch(config)# line ssh
```

```
Switch(config-line)# exec-timeout
```

```
25 Switch(config-line)# exit
```

This example shows how show line information.

```
Switch# show line
```

```
Switch(config-line)# line console
Switch(config-line)# exec-timeout 15
Switch(config-line)# exit
Switch(config)# line telnet
Switch(config-line)# exec-timeout 20
Switch(config-line)# exit
Switch(config)# line ssh
Switch(config-line)# exec-timeout 25
Switch(config-line)# exit
Switch(config)# exit
Switch# show line
-----
console
  Session Timeout : 15 (minutes)
  History Count   : 128
  Password Retry  : 3
  Silent Time     : 0 (seconds)
telnet
  Telnet Server   : enabled
  Session Timeout : 20 (minutes)
  History Count   : 128
  Password Retry  : 3
  Silent Time     : 0 (seconds)
ssh
  SSH Server      : enabled
  Session Timeout : 25 (minutes)
  History Count   : 128
  Password Retry  : 3
  Silent Time     : 0 (seconds)
```

Example

1.24 PASSWORD-THRESH

Use “**password-thresh**” command to specify the password fail retry number for CLI running on console, telnet or ssh service. When user input password to login and authenticate failed, the fail retry number will increase one. After fail retry number exceed configured one, the CLI will block login for the period of silent time which configured by the command “**silent-time**”.

```
Switch#configure terminal
```

```
Switch(config)# line console
```

```
Switch(config-line)# password-
```

```
thresh 4
```

Syntax **password-thresh** *<0-120>*

Parameter *<0-120>*Specify password fail retry number. 0 means no

limit. Default Default password fail retry number is 3.

Mode Line Configuration

This example shows how to change console fail retry number to 4, telnet fail retry number to 5 and ssh fail retry number to 6. The number of allowed password attempts. (Range: 0-120; 0: no threshold)

```
Switch#configure terminal
```

```
Switch(config)# line console
```

```
Switch(config-line)# password-
```

```
thresh 4 Switch(config-line)# exit
```

```
Switch(config)# line telnet
```

```
Switch(config-line)# password-
```

```
thresh 5
```

```
Switch(config-line)# exit
```

```
Switch(config)# line ssh
```

```
Switch(config-line)# password-thresh 6
```

```
Switch(config-line)# exit
```

This example shows how show line information.

```
Switch# show line
```

```
Switch(config)# line console
Switch(config-line)# password-thresh 4
Switch(config-line)# exit
Switch(config)# line telnet
Switch(config-line)# password-thresh 5
Switch(config-line)# exit
Switch(config)# line ssh
Switch(config-line)# password-thresh 6
Switch(config-line)# exit
Switch(config)# exit
Switch# show line
Console
-----
Session Timeout : 15 (minutes)
History Count    : 128
Password Retry   : 4
Silent Time      : 0 (seconds)
Telnet
-----
Telnet Server    : enabled
Session Timeout : 20 (minutes)
History Count    : 128
Password Retry   : 5
Silent Time      : 0 (seconds)
SSH
-----
SSH Server       : enabled
Session Timeout : 30 (minutes)
History Count    : 128
Password Retry   : 6
Silent Time      : 0 (seconds)
```

Example

1.25 PING

Ping (Packet Internet Groper) tests the connection between two network nodes by sending packets to a host and measure the round-trip time. Use “**ping**” command to do network ping diagnostic.

```
Switch# ping HOSTNAME[count <1-999999999>]
```

Syntax **ping** HOSTNAME[count <1-999999999>]

HOSTNAME Specify IPv4/IPv6 address or domain name to

Parameter ping.

count<1-999999999> Specify how many times to ping.

User EXEC

Mode

Privileged EXEC

This example shows how to ping remote host

Example
192.168.0.21 Switch# ping 192.168.0.21

```
Switch# ping 192.168.0.21
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.0.21: timeout is 2000 ms:
OOOOO
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/ma = 0.100/0.100/0.100 ms
```

1.26 TRACEROUTE

Traceroute discovers the IP routes along which packets were forwarded by sending an IP packet to the target host and back to the device. The Trace route page shows each hop between the device and a target host, and the round-trip time to each such hop.

Use “**traceroute**” command to do network trace route

diagnostic. Switch# **traceroute** {*A.B.C.D*} [**max_hop** <2-255>]

Syntax **Traceroute** {*A.B.C.D*} [**max_hop** <2-255>]

A.B.C.D Specify IPv4 to trace.

Parameter

max_hop <2-255> Specify maximum hop to trace.

Mode
User EXEC

Privileged EXEC

This example shows how to trace route host 192.168.0.21.

Example

Switch# **traceroute 192.168.0.21**

```
traceroute to 192.168.0.21, 30 hops max, 38 byte packets
 0 192.168.0.21 (192.168.0.21) 0.000 ms 0.000 ms 20.000 ms
```

1.27 SHOW ARP

Use “**show arp**” command to show all arp

entries. Switch# **show arp**

Syntax **show arp**

Mode User EXEC

Privileged EXEC

This example shows how to show arp entries.

Example Switch# **show arp**

e

```
Switch# show arp
      IP address      HW address      Status
-----
 192.168.0.23        28:00:01:0a:7b:30 Dynamic
Total number of entries: 1
```

1.28 SHOW CPU UTILIZATION

Use “**show cpu utilization**” command to show current CPU

utilization. Switch# **show cpu utilization**

Syntax **show cpu utilization**

Mode Privileged EXEC

This example shows how to show current CPU utilization.

Example
Switch# **show cpu utilization**

```
Switch# show cpu utilization
CPU utilization
Current: 24
```

1.29 SHOW HISTORY

Use “**show history**” to show commands we input before.

Switch# **show history**

Syntax **show history**

User EXEC

Mod Privileged EXEC

e

Global

Configuration

This example shows how show history commands.

Switch# **show history**

Example

```
Switch# show history
Maximum History Count: 128
-----
1. configure
2. ip dns 111.111.111.111 222.222.222.222
3. exit
4. ip dns 111.111.111.111 222.222.222.222
5. configure
6. exit
7. show ip dns
8. configure
9. no ip dns
10. ip dns
11. ip
12. ip dns 111.111.111.111 222.222.222.222
13. ip dns 8.8.8 8.8.4 8
14. ip dns 1.1.1.1 1.1.1.1
15. ip dns lookup
16. exit
17. show ip http
18. show ip https
19. show ip route
20. show ipw
21. configure
22. ipv6 address fe80::2de12eff:fe14b3c prefix 128
--More--
```

1.30 SHOW INFO

Use “show info” command to show system summary

information. Switch#show info

Syntax **show info**

Mode User EXEC

Mode Privileged EXEC

This example shows how to show system

version. Switch# show info

Example

```
Switch# show info
System Name       : Switch
System Location  : default
System Contact   : default
MAC Address      : 00E014C10000100
Default IP Address : 192.168.0.1
Subnet Mask      : 255.255.255.0
Loader Version   : 2.10.0.4
Loader Date      : Nov 31 2024 - 15:17:03
Firmware Version : Solis1e00.2K.v1.4
Firmware Date    : Dec 10 2020 - 16:45:00
System Output ID : 1.3.4.1.4.1.27282.1.1
System Up time   : 0 days, 0 hours, 24 mins, 24 secs
```

1.31 SHOW IP

Use “**show ip**” command to show system IPv4 address, net mask and default gateway. Switch#**show ip**

Syntax **show ip**

Mode User EXEC

Privileged EXEC

This example shows how to show current ipv4 address of the switch. Switch# **show ip**

Example

```
Switch# show ip
***** Config *****
IP Address: 192.168.0.1
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.0.254

***** Status *****
IP Address: 192.168.0.1
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.0.254
```

1.32 SHOW IP DHCP

Use “**show ip dhcp**” command to show IPv4 dhcp client enable state.

Switch#**show ip dhcp**

Syntax **show ip dhcp**

Mode User EXEC

 Privileged EXEC

This example shows how to show current dhcp client state of the

Example switch. Switch# **show ip dhcp**

e

```
Switch# show ip dhcp
DHCP Status - Disabled
```

1.33 SHOW IP HTTP

Use “**show ip http**” command to show HTTP/HTTPS

information. Switch#**show ip (http|https)**

Syntax **show ip (http|https)**

Mode Privileged EXEC

This example shows how to show current ipv4 address of the switch. Switch# **show ip http**

Example

e

Switch# **show ip https**

```
Switch# show ip http
HTTP daemon : enabled
Session Timeout : 15 (minutes)
Switch# show ip https
HTTPS daemon : enabled
Session Timeout : 20 (minutes)
```

1.34 SHOW IPV6

Use “**show ipv6**” command to show system IPv6 address, net mask, default gateway and auto config state. Switch#**show ipv6**

Syntax **show ipv6**

Mode User EXEC

Mode Privileged EXEC

This example shows how to show current ipv6 address of the switch. Switch# **show ipv6**

Example

```
Switch# show ipv6
##### Config #####
State: enabled
Auto config: enabled
DHCPv6: enabled
Gateway: fe80::deadbeef::feef103
IP Address: fe80::20e:2eff:fe21:4b3c/128
##### Status #####
IP Address: fe80::2e0:4cff:fe00:10/64
IP Address: fe80::20e:2eff:fe21:4b3c/128
##### Gateway: ::
```

1.35 SHOW LINE

Use “**show line**” command to show all line configurations including session timeout, history count, password retry number and silent time. For telnet and ssh, it also shows the service enable/disable state.

Switch#**show line [(console | telnet | ssh)]**

Syntax **show line [(console | telnet | ssh)]**

console Select console line to show.

Parameter **telnet** Select telnet line to show.

Ssh Select ssh line to show.

Mode Privileged EXEC

This example shows how show all lines' information.

Switch# **show line**

Example

```
Switch# show line
Console
-----
Session Timeout : 15 (minutes)
History Count   : 128
Password Retry  : 6
Silent Time     : 0 (seconds)
Telnet
-----
Telnet Server   : enabled
Session Timeout : 20 (minutes)
History Count   : 128
Password Retry  : 6
Silent Time     : 0 (seconds)
SSH
-----
SSH Server      : enabled
Session Timeout : 25 (minutes)
History Count   : 128
Password Retry  : 6
Silent Time     : 0 (seconds)
```

1.36 SHOW MEMORY STATISTICS

Use “**show memory statistics**” command to show current memory utilization. Switch#**show memory statistics**

Syntax **show memory statistics**

Mode Privileged EXEC

This example shows how to show current system memory statistics.

Example
Switch# **show memory statistics**

```
Switch# show memory statistics
      total (B)   used (B)   free (B)   shared (B)   buffer (B)   cache (B)
-----
Mem:    128192    66884    59208         0         0         0
+-- buffers/cache:  66884    59208
Mem:          0         0         0
```

1.37 SHOW PRIVILEGE

Use “**show privilege**” command to show the privilege level of the current

user. Switch#**show privilege**

Syntax **show privilege**

	User EXEC
Mod	
e	Privileged EXEC

This example shows how to show arp entries.

ExampleSwitch# **show privilege**

```
Switch# show privilege
Current CLI Username: admin
Current CLI Privilege: 15
```

1.38 SHOW USERNAME

Use “**show username**” command shows all user accounts in local database. Switch#**show username**

Syntax **show username**

Mode Privileged EXEC

This example shows how to show existing user accounts.

Example
Switch# **show username**

```
Switch# show username
User | Type | Date/Time | Password
-----|-----|-----|-----
15 | secret |          | $1234567890123456789012345678901234567890
```

1.39 SHOW USERS

Use “**show users**” command show information of all active users. Switch#**show users**

Syntax **show users**

Mode Privileged EXEC

This example shows how to show existing user accounts.

Example
Switch# **show users**

```
Switch# show users
-----
Username      Protocol      Location
-----
admin         console       0.0.0.0
admin         telnet       192.168.0.44
```

1.40 SHOW VERSION

Use “**show version**” command to show loader and firmware version and build date.

Switch#**show version**

Syntax **show version**

Mode
User EXEC

Privileged EXEC

This example shows how to show system

Example
Switch# **show version**

```
Switch# show version
Loader Version : 2.0.0.6
Loader Date   : Nov 17 2019 - 18:17:03
Firmware Version : SoldierOS_2K.v1.4
Firmware Date  : Oct 10 2020 - 16:46:56
```

1.41 SILENT-TIME

Use “**silent time**” command to specify the silent time for CLI running on console, telnet or ssh service. When user input password to login and authenticate failed, the fail retry number will increase one. After fail retry number exceed configured one, the CLI will block login for the period of silent time which configured by the command “**silent-time**”.

```
Switch#configure terminal
```

```
Switch(config)# line {console|telnet|ssh|http}
```

```
Switch(config-line)# silent-time <0-65535>
```

Syntax **silent-time** <0-65535>

Parameter <0-65535>Specify silent time with unit seconds. 0 means do not salient. Default Default silent time is 0.

Mode Line Configuration

This example shows how to change console silent time to 10, telnet silent time to 15 and ssh silent time to 20.

```
Switch#configure terminal
```

```
Switch(config)# line console
```

```
Switch(config-line)# silent-time
```

```
10 Switch(config-line)# exit
```

```
Switch(config)# line telnet
```

```
Switch(config-line)# silent-time
```

```
15
```

```
Switch(config-line)# exit
```

```
Switch(config)# line ssh
```

```
Switch(config-line)# silent-time
```

```
20 Switch(config-line)# exit
```

This example shows how show line information.

```
Switch# show line
```

```
Switch(config)# line console
Switch(config-line)# silent-time 10
Switch(config-line)# exit
Switch(config)# line telnet
Switch(config-line)# silent-time 15
Switch(config-line)# exit
Switch(config)# line ssh
Switch(config-line)# silent-time 20
Switch(config-line)# exit
Switch(config)# exit
Switch# show line
-----
Console
  Session Timeout : 15 (minutes)
  History Count   : 128
  Password Retry  : 4
  Silent Time     : 10 (seconds)
Telnet
-----
Telnet Server : enabled
  Session Timeout : 20 (minutes)
  History Count   : 128
  Password Retry  : 4
  Silent Time     : 15 (seconds)
SSH
-----
SSH Server : enabled
  Session Timeout : 25 (minutes)
  History Count   : 128
  Password Retry  : 6
  Silent Time     : 20 (seconds)
```

Examp
le

1.42 SSL

Use “ssl” command to generate security certificate files such as RSA,

DSA. Switch#ssl

Syntax **ssl**

Mode Global Configuration

This example shows how to generate certificate files.

Switch# ssl

Example

```
Switch# ssl
Generating a 2048 bit RSA private key
.....
writing new private key to "/mnt/flash/ssl_key.pem.tmp"
-----
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank.
For some fields there will be a default value.
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [AU]:IN
State or Province Name (full name) [Some-State]:HM
Locality Name (eg, city) []:HM
Organization Name (eg, company) [Internet Widgits Pty Ltd]:CMD
Organizational Unit Name (eg, section) []:CMD
Common Name (e.g. server fully qualified domain name) []:CMD
Email Address []:info@cmd.com
```

Switch# show flash

```
Switch# show flash
File Name      File Size      Modified
-----
startup-config 1683           2019-01-01 00:19:55
e2e2           2479           2019-01-01 01:26:43
dsa2           668            2019-01-01 01:26:55
ssl_cert       1334           2019-01-01 02:18:27
image          8605240        2019-11-27 18:36:55
```

1.43 SYSTEM NAME

Use “**system name**” command to modify system name information of the switch. The system name is also used to be CLI prompt.

Switch#configure terminal

Switch(config)#system name {NAME}

Syntax **system name {NAME}**

Parameter NAME *NAME* Specify system name string.

Default Default name string is “**Switch**”.

Mode Global Configuration

This example shows how to modify contact information

Switch#configure terminal

Switch(config)# system name

Example commando commando(config)#
 commando# show info

```
Switch(config)# system name commando
commando(config)# exit
commando# show info
System Name        : commando
System Location    : Default
System Contact     : default
MAC Address        : 00:20:4C:00:00:00
IP Address         : 192.168.0.1
Subnet Mask        : 255.255.255.0
Loader Version     : 1.0.0.6
Loader Date        : Nov 17 2019 - 18:17:03
Firmware Version   : 1.0.0.10
Firmware Date      : Nov 17 2019 - 18:36:59
System Memory ID   : 1-0-6-1-1-2752-3-2-10
System Up Time     : 0 days, 2 hours, 22 mins, 15 secs
```

1.44 SYSTEM CONTACT

Use “**system contact**” command to modify contact information of the switch. Switch#**configure terminal**

Switch(config)# **system contact**

{CONTACT} Syntax **system contact**

{CONTACT} Parameter *CONTACT*

Specify contact string.

Default Default contact string is “**Default Contact**”.

Mode Global Configuration

This example shows how to modify contact information

Switch#**configure terminal**

Switch(config)# **system contact callcommando**

Example Switch# **show info**

```
Switch(config)# system contact callcommando
Switch(config)# exit
Switch# show info
System Name       : Switch
System Location  : Default
System Contact   : callcommando
MAC Address      : 00E04C000000
IP Address       : 192.168.0.1
Subnet Mask      : 255.255.255.0
Loader Version   : 1.0.0.0
Loader Date      : Nov 27 2019 - 18:17:03
Firmware Version : 1.0.0.10
Firmware Date    : Nov 27 2019 - 18:36:39
System Contact ID : 1.3.6.4-4-1.27282.3-2.10
System Up Time   : 0 days, 2 hours, 24 mins, 54 secs
```

1.45 SYSTEM LOCATION

Use “**system location**” command to modify location information of the

switch. Switch#**configure terminal**

Switch(config)# **system location**

{LOCATION} Syntax **system location**

{LOCATION} Parameter *LOCATION*Specify

location string.

Default Default location string is “**Default Location**”.

Mode Global Configuration

This example shows how to modify contact

information Switch#**configure terminal**

Switch(config)# **system location home**

This example shows how to show system location information

Examp

e

Switch# **show info**

```
Switch(config)# system location homecommando
Switch(config)# exit
Switch# show info
System Name       : Switch
System Location  : homecommando
System Contact   : callcommando
MAC Address      : 00:09:4C:00:00:00
IP Address       : 192.168.0.1
Subnet Mask      : 255.255.255.0
Loader Version   : 1.0.0.4
Loader Date      : Nov 17 2019 - 18:17:03
Firmware Version : 1.0.0.00
Firmware Date    : Nov 17 2019 - 18:34:59
System Object ID : 1.3.6.1.4.1.27282.3.2.10
System Up Time   : 1 d, 0 hrs, 2 mins, 20 secs
```

1.46 TERMINAL LENGTH

Use “**terminal length**” command to specify the maximum line number the terminal is able to print.

Switch#**terminal length** <0-24>

Syntax **terminal length** <0-24>

Parameter <0-24>Specify terminal length value. 0 means no limit.

Default Default terminal length is 24.

Mode
User EXEC
Privileged EXEC

This example shows how to change terminal length.

Example
Switch# **terminal length 3**
Switch# **show running-config**

```
Switch# terminal length 3
Switch# show running-config
SYSTEM CONFIG FILE ::= BEGIN
!
System Description: IC-9004 K14382K Switch
!
System Version: V1.0.0.10
--More--
```

1.47 USERNAME

Use “**username**” command to add a new user account or edit an existing user account. And use “**no username**” to delete an existing user account. The user account is a local database for login authentication.

Switch#configure terminal

```
Switch(config)# username WORD<0-32>[privilege (admin|user|<0-15>)] (nopassword | password UNENCRYPY-PASSWORD | secret UNENCRYPY-PASSWORD | secret encrypted ENCRYPT- PASSWORD)
```

```
Switch(config)# no username WORD<0-32>
```

Synta
x

```
username WORD<0-32>[privilege (admin|user|<0-15>)](nopassword| password UNENCRYPY-PASSWORD | secret UNENCRYPY-PASSWORD | secret encrypted ENCRYPT-PASSWORD)
```

```
no username WORD<0-32>
```

Username WORD<0-32>Specify user name to

add/delete/edit. **privilege** admin Specify privilege level to

be admin (privilege 15) **privilege** user Specify privilege

level to be user (privilege 1) **privilege** <0-15>

Paramet
er

Specify custom privilege level password.

UNENCRYPY- PASSWORD Specify password string and make it not encrypted.

Secret UNENCRYPY- PASSWORD Specify password string and make it encrypted.

secret encrypted ENCRYPT- PASSWORD Enter an encrypted password. Use this keyword to enter a password that is already encrypted (for instance, a password that you copied from another the configuration file of another device).

Default Default username “**admin**” has password “**commando**” with

privilege 15. Mode

Global Configuration

AAA (Authentication, Authorization, Accounting)

The AAA feature allows you to verify the identity of, grant access to, and track the actions of users managing E2000 Series switches. The E2000 Series switches support Remote Access Dial-In User Service (RADIUS) or Terminal Access Controller Access Control device Plus (TACACS+) protocols.

Based on the user ID and password combination that you provide, the E2000 Series switches perform local authentication or authorization using the local database or remote authentication or authorization using one or more AAA servers. A preshared secret key provides security for communication between the E2000 series switches and AAA servers. You can configure a common secret key for all AAA servers or for only a specific AAA server.



Fig 2.1.1 AAA E2000 Series Switches

AAA AUTHENTICATION

AAA security provides the following services:

1) Authentication - Identifies users, including login and password dialog, challenge and response, messaging support, and, encryption depending on the security protocol that you select. Authentication is the process of verifying the identity of the person or device accessing the E2000 Series switches. This process is based on the user ID and password combination provided by the entity trying to access the E2000 switch. The E2000 Series switches allow you to perform local authentication (using the local lookup database) or remote authentication (using one or more RADIUS or TACACS+ servers).

2) Authorization - Authorization Provides access controls.

AAA authorization is the process of assembling a set of attributes that describe what the user is authorized to perform. Authorization in E2000 Series switches is provided by attributes that are downloaded from AAA servers. Remote security servers, such as RADIUS and TACACS+, authorize users for specific rights by associating attribute-value (AV) pairs, which define those rights with the appropriate user.

3) Accounting - Provides the method for collecting information, logging the information locally, and sending the information to the AAA server for billing, auditing, and reporting.

The accounting feature tracks and maintains a log of every management session used to access the E2000 Series switches. You can use this information to generate reports for troubleshooting and auditing purposes. You can store accounting logs locally or send them to remote AAA servers.

Login authentication is used when user try to login into the switch. Such as CLI login dialog and WEBUI login web page. Enable authentication is used only on CLI for user trying to switch from User EXEC mode to Privileged EXEC mode.Both of them support following authenticate methods. TACACS+ provides more control over the authorization of commands while in RADIUS, no external authorization of commands is supported. All the AAA packets are encrypted in TACACS+ while only the passwords are encrypted in RADIUS is more secure.

Each list allows you to combine these methods with different orders. For example, we want to authenticate login user with remote TACACS+ server, but server may be crashed. Therefore, we need a backup plan, such as another Radius server. So we can configure the list with TACACS+ server as first authentication method and Radius server as second one.

Switch#configure terminal

```
Switch(config)# aaa authentication (login | enable) (default | listname) [methodlist][methodlist]
```

[methodlist] [methodlist]

Switch(config)# **no aaa authentication (login | enable) {listname}**

Synta **aaa authentication (login | enable) (default | *listname*) *methodlist***
[methodlist] [methodlist] [methodlist]

x **no aaa authentication (login | enable) {listname}**

Parameter **login** Add/Edit login authentication list

enable Add/Edit enable authentication list

default Edit default authentication list

listname Specify the list name for authentication type

methodlist Specify the authenticate method, including none, local enable, tacacs+, radius.

Default authentication list name for type login is **“default”** and default method is **“local”**.

Default authentication list name for type enable is **“default”** and default method is **“enable”**

Mode Global Configuration

This example shows how to add a login authentication list to authenticate with order tacacs+, radius, local.

Switch(config)# **aaa authentication login test1 tacacs+ radius**

local This example shows how to show existing login

authentication lists Switch# **show aaa authentication login lists**

```
Switch(config)# aaa authentication login test1 tacacs+ radius local
Switch(config)# exit
Switch# show aaa authentication login lists
Login List Name      Authentication Method List
-----
default            local
test1              tacacs+ radius local
```

Example

Switch(config)# **aaa authentication enable test1 tacacs+ radius**

enable This example shows how to show existing enable

authentication lists Switch# **show aaa authentication login lists**

Enable

```
Switch(config)# aaa authentication enable test1 tacacs+ radius enable
Switch(config)# exit
Switch# show aaa authentication login list
Login List Name      Authentication Method List
-----
default             local
test1               tacacs+ radius local
```

2.1 LOGIN AUTHENTICATION

Different access methods are allowed to bind different login authentication lists. Use **“login authentication”**

command to bind the list to specific line (console, telnet, ssh).

```
Switch#configure terminal
```

```
Switch(config-line)# login authentication
```

```
{listname} Switch(config-line)# no login
```

authentication

```
login authentication {listname}
```

Syntax

```
x no login authentication
```

Parameterlistname Specify the login authentication list name

to use. Default Default login authentication list for each line

is **“default”**. Mode Line Configuration

This example shows how to create a new login authentication list and bind to telnet line.

```
Switch(config)# aaa authentication login test1 (tacacs+ | radius | local | none | enable)
```

```
Switch(config)# line telnet
```

```
Switch(config-line)# login authentication test1
```

Example

e

This example shows how to show line binding

lists. Switch# show line lists

```
Switch(config)# aaa authentication login test1 tacacs+
Switch(config)# line telnet
Switch(config-line)# login authentication test1
Switch(config-line)# exit
Switch(config)# exit
Switch# show line lists
-----
Line Type | AAA Type | List Name
-----
console | login | default
telnet | enable | default
telnet | login | test1
telnet | enable | test1
ssh | login | default
ssh | enable | default
http | login | test1
https | login | test1
```

2.2 IP HTTP LOGIN AUTHENTICATION

Different access methods are allowed to bind different login authentication lists. Use “**ip (http | https) login authentication**” command to bind the list to WEBUI access from http or https.

```
Switch#configure terminal
```

```
Switch(config)# ip (http | https) login authentication {listname}
```

Switch(config)# no ip (http | https) login authentication

Syntax
x ip (http | https) login authentication *{listname}*
no ip (http | https) login authentication

http: Bind login authentication list to user access WEBUI with http

Parameter
protocol **https**: Bind login authentication list to user access WEBUI with
https protocol *listname* Specify the login authentication list name to use.

Default Default login authentication list for each line is

“default”. Mode Global Configuration

This example shows how to create two new login authentication lists and bind to http and https. Switch#configure terminal

Switch(config)# aaa authentication login test1 tacacs+ radius local

Switch(config)# aaa authentication login test2 radius local

Switch(config)# ip http login authentication test1

Example
e Switch(config)# ip https login authentication

test2 This example shows how to show line

binding lists. Switch# show line lists

```
Switch(config)# aaa authentication login test2 radius local
Switch(config)# ip http login authentication test1
Switch(config)# ip https login authentication test2
Switch(config)# exit
Switch# show line lists
-----
Line Type | AAA Type | List Name
-----
console | login | default
| enable | default
telnet | login | test1
| enable | test1
ssh | login | default
| enable | default
http | login | test1
https | login | test2
```

2.3 ENABLE AUTHENTICATION

Different access methods are allowed to bind different enable authentication lists. Use “**enable authentication**” command to bind the list to specific line (console, telnet, ssh).

```
Switch#configure terminal
```

```
Switch(config-line)# enable authentication
```

```
{listname} Switch(config-line)# no enable
```

authentication

```
enable authentication {listname}
```

Syntax

```
x no enable authentication
```

Parameter listname Specify the enable authentication list name

to use. Default Default enable authentication list for each line

is “**default**”. Mode Line Configuration


This example shows how to create a new enable authentication list and bind to telnet line.

```
Switch#configure terminal
```

```
Switch(config)# aaa authentication enable test1 tacacs+ radius enable
```

```
Example Switch(config)# line telnet
```

```
e Switch(config-line)# enable authentication test1
```



```
Switch(config)# aaa authentication enable test1 tacacs+ radius enable
Switch(config)# line telnet
Switch(config-line)# enable authentication test1
Switch(config-line)# exit
Switch#show line logs
Switch#show line logs
Line Type   Auth Type   List Name
-----
console    login       default
telnet     enable     default
telnet     login      test1
ssh        login      default
http       login      default
https      login      default
```

2.4 SHOW AAA AUTHENTICATION

Use “**show aaa authentication**” command to show login authentication or Enable authentication

method lists.

Switch#**show aaa authentication (login | enable) lists**

Syntax **show aaa authentication (login | enable) lists**

login Show login authentication list.

Parameter

enable Show enable authentication list.

Mode

Privileged EXEC

This example shows how to show existing login authentication

lists. Switch# **show aaa authentication login lists**

```
Switch# show aaa authentication login lists
Login List Name  Authentication Method List
-----
default         local
test1           tacacs+ radius local
test2           radius local
```

Example

This example shows how to show existing enable authentication lists

Switch# **show aaa authentication login lists**

```
Switch# show aaa authentication login lists
Login List Name  Authentication Method List
-----
default         local
test1           tacacs+ radius local
test2           enable
```

2.5 SHOW LINE LISTS

Use “show line lists” command to show all lines binding list of

all. Switch#show line lists

Syntax **show line lists**

Mode Privileged EXEC

This example shows how to show line binding lists.

Switch# **show line lists**

Example

```
Switch# show line lists
-----
Line Type | AAA Type | List Name
-----
console | |
| login | default
| enable | default
telnet | |
| login | test1
| enable | test1
ssh | |
| login | default
| enable | default
http | |
| login | test1
https | |
| login | test1
```

2.6 TACACS DEFAULT-CONFIG

Use “**tacacs default-config**” command to modify default values of tacacs+ server. These default values will be used when user try to create a new tacacs+ server and not assigned these values.

Switch#**configure terminal**

Switch(config)#**tacacs default-config [key TACACSKEY] [timeout <1-30>]**

Syntax **tacacs default-config [key TACACSKEY] [timeout <1-30>]**

Parameter **key TACACSKEY** Specify default tacacs+ server key string.
timeout <1-30> Specify default tacacs+ server timeout value.

Default Default tacacs+ key is “*****”.
Default tacacs+ timeout is 5 seconds.

Mode Global Configuration

This example shows how modify default tacacs+ configuration

Switch#**configure terminal**

Switch(config)# **tacacs default-config timeout 20**

Switch(config)# **tacacs default-config key tackey**

Example This example shows how to show default tacacs+ configurations.

Switch# **show tacacs default-config**

```
Switch(config)# tacacs default-config timeout 20
Switch(config)# tacacs default-config key tackey
Switch(config)# exit
Switch# show tacacs default-config
Timeout| Key
-----|-----
20 | tackey
```

2.7 TACACS HOST

Use “TACACS+ host” command to add or edit tacacs+ server for Authentication, Authorization or accounting. Use “no” form to delete one or all TACACS+ servers from database.

Switch#configure terminal

```
Switch(config)# tacacs host {HOSTNAME} [port <0-65535>] [key TACPLUSKEY] [priority <0-65535>] [timeout <1-30>]
```

```
Switch(config)#no tacacs [host {HOSTNAME}]
```

Syntax
X

```
tacacs host HOSTNAME [port <0-65535>] [key TACPLUSKEY] [priority <0-65535>] [timeout <1-30>]
no tacacs [host {HOSTNAME}]
```

HOSTNAME Specify tacacs+ server host name, both IP address and domain name are available.

port <0-65535> Specify tacacs+ server udp port

Parameter
key TACPLUSKEY Specify tacacs+ server key string

priority <0-65535> Specify tacacs+ server priority

timeout <1-30> Specify tacacs+ server timeout value

Default
Default tacacs+ key is “*****”.

Default tacacs+ timeout is 5 seconds.

Mode
Global Configuration

This example shows command execution,

Example

```
Switch#
Switch#configure t
Switch(config)# tacacs host change port 22 key TACPLUSKEY priority 45 timeout 5
```

2.8 SHOW TACACS DEFAULT-CONFIG

Use “**show tacacs default-config**” command to show tacacs+ default. Switch#**show tacacs default-config**

Syntax **show tacacs default-config**

Mode Privileged EXEC

This example shows how to show default tacacs+ configurations.

Example
Switch# **show tacacs default-config**

```
Switch# show tacacs default-config
-----key
20 | tacacs
```

2.9 SHOW TACACS

Use “**show tacacs**” command to show existing tacacs+ servers.

Switch#**show tacacs**

Syntax **show tacacs**

Mode Privileged EXEC

This example shows how to show existing tacacs+ server.

ExampleSwitch# **show tacacs**

```
Switch# show tacacs
-----
Prio | Timeout | IP Address | Port | Key
-----
 4 | 25 | 192.168.0.100 | 49 | TACACSKEY
```

2.10 SHOW Default-config

Use “**radius default-config**” command to modify default values of radius server. These default values will be used when user try to create a new radius server and not assigned these values.

Switch#**configure terminal**

Switch(config)#**radius default-config [key RADIUSKEY] [retransmit <1-10>] [timeout <1-30>]**

Syntax **radius default-config [key RADIUSKEY] [retransmit <1-10>] [timeout <1-30>]**
]

key RADIUSKEY Specify default radius server key string

Parameter**retransmit <1-10>** Specify default radius server retransmit value

timeout <1-30> Specify default radius server timeout value

Default radius key is “*****”.

Default
t Default radius retransmit is 3
times. Default radius timeout is 3
seconds

Mode Global Configuration

This example shows how modify default radius configuration,

Switch#**configure terminal**

Switch(config)# **radius default-config timeout 20**

Switch(config)# **radius default-config key radiuskey**

Examp
e Switch(config)# **radius default-config retransmit 5**

This example shows how to show default radius configurations.

Switch# **show radius default-config**

```
Switch(config)# radius default-config timeout 20
Switch(config)# radius default-config key radiuskey
Switch(config)# radius default-config retransmit 5
Switch(config)# exit
Switch# show radius default-config
Retries| Timeout| Key
-----|-----|-----
5 | 20 | radiuskey
```

2.11 RADIUS HOST

Use “radius host” command to add or edit an existing radius server. Use “no” form to delete one or all radius servers from database.

Switch#configure terminal

```
Switch(config)# radius host {HOSTNAME } [auth-port <0-65535>] [key RADIUSKEY][priority <0-65535>] [retransmit <1-10>] [timeout <1-30>] [type (login|802.1x|all)]
```

```
Switch(config)# no radius [host {HOSTNAME }]
```

Syntax
X

```
radius host HOSTNAME [auth-port <0-65535>] [key RADIUSKEY][priority <0-65535>] [retransmit <1-10>] [timeout <1-30>] [type (login|802.1x|all)]
```

```
no radius [host HOSTNAME]
```

HOSTNAME Specify radius server host name, both IP address and domain name are available.

auth-port <0-65535> Specify radius server udp

Parameter
er

port **key** RADIUSKEY Specify radius server key

string **priority** <0-65535> Specify radius server

priority

retransmit <1-10> Specify radius server retransmit times

timeout <1-30> Specify radius server timeout value

Default Default radius timeout is 3

seconds. Mode Global Configuration

e

Example

This example shows how to create a new radius server

```
Switch(config)# radius host 192.168.1.111 auth-port 12345 key radiuskey  
priority100 retransmit 5 timeout 10 type all
```

This example shows how to show existing radius server. Switch# **show radius**



```
Switch(config)# show radius
Switch# show radius
-----
Host      IP Address  Auth-Port  Retransmit  Timeout  Type  Key
-----
192.168.1.111  12345      5          10          all      radiuskey
```

2.12 SHOW RADIUS Default-config

Use “**show radius default-config**” command to show radius default configurations.

Switch#**show radius default-config**

Syntax **show radius default-config**

Mode Privileged EXEC

This example shows how to show default radius

Example configurations. Switch# **show radius default-config**

```
Switch# show radius default-config
Radius Timeout Key
-----
3 1 3 1
Switch#
```

2.13 SHOW RADIUS

Use “**show radius**” command to show existing radius servers.

Switch#**show radius**

Syntax **show radius**

Mode Privileged EXEC

This example shows how to show existing radius server.

Example
Switch# **show radius**

```
Switch# show radius
-----
Prio | IP Address | Auth-Port | Retries | Timeout | Type | Key
-----
100 | 192.168.1.111 | 12345 | 5 | 10 | All | radiuskey
```

ACL (ACCESS CONTROL LIST)

An ACL is a sequential collection of permit and deny conditions that apply to packets. Packet filtering can help limit network traffic and restrict network use by certain users or devices. ACLs filter traffic as it passes through a switch and permit or deny packets crossing specified interfaces. When a packet is received on an interface, the switch compares the fields in the packet against any applied ACLs to verify that the packet has the required permissions to be forwarded, based on the criteria specified in the access lists. One by one, it tests packets against the conditions in an access list. The first match decides whether the switch accepts or rejects the packets. Because the switch stops testing after the first match, the order of conditions in the list is critical. If no conditions match, the switch rejects the packet. If there are no restrictions, the switch forwards the packet; otherwise, the switch drops the packet. The switch can use ACLs on all packets it forwards.

You configure access lists on a switch to provide basic security for your network. If you do not configure ACLs, all packets passing through the switch could be allowed onto all parts of the network. You can use ACLs to control which hosts can access different parts of a network or to decide which types of traffic are forwarded or blocked. For example, you can allow e-mail traffic to be forwarded but not Telnet traffic.

An ACL contains an ordered list of access control entries (ACEs). Each ACE specifies permit or deny and a set of conditions the packet must satisfy in order to match the ACE. The meaning of permit or deny depends on the context in which the ACL is used.

The switch supports IP ACLs and Ethernet (MAC) ACLs:

- 1) IP ACLs filter IPv4 traffic, including TCP, User Datagram Protocol (UDP), Internet Group Management Protocol (IGMP), and Internet Control Message Protocol (ICMP).
- 2) Ethernet ACLs filter non-IP traffic.




Fig 3.1.1 IP ACL E2000 series Switches

3.1 MAC ACL

MAC ACLs are ACLs that filter traffic using information in the Layer 2 header of each packet. You can use ACLs to control which hosts can access different parts of a network or to decide which types of traffic are forwarded or blocked at the router interfaces.

Use the `mac acl` command to create a MAC access list and to enter `mac-acl` configuration mode. The name of ACL must be unique that cannot have same name with other ACL or QoS policy. Once an ACL is created, an implicit **“deny any”** ACE created at the end of the ACL. That is, if there are no matches, the packets are denied. Use the `no` form of this command to delete.




Fig 3.2.1 MAC ACL E2000 series

Switches `Switch#configure terminal`

`Switch(config)# mac acl {NAME}`

`Switch(config)#no mac acl {NAME}`

Syntax `mac acl {NAME}`

`no mac acl {NAME}`

Parameter `NAME` Specify the name of MAC

ACL Mode Global Configuration

The example shows how to create a mac acl. You can verify settings by the following `show acl` command

`Switch#configure`

Example `terminal Switch(config)#`

`e`

`mac acl test Switch(mac-`

`acl)# show acl`

```
Switch(config)# mac acl commando
Switch(config-mac-acl)# show acl
MAC access list commando
```

3.2 PERMIT (MAC)

Use the permit command to add permit conditions for a mac ACE that bypass those packets hit the ACE.

The “**sequence**” also represents hit priority when ACL bind to an interface. An ACE not specifies “**sequence**” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE cannot be added if has the same conditions as existed ACE.

Switch#**configure terminal**

Switch(config)# **mac acl** {*NAME*}

Switch(config-mac-acl)#**[sequence** <1-2147483647>] **permit** (A:B:C:D:E:F /A:B:C:D:E:F|any) (A:B:C:D:E:F/A:B:C:D:E:F|any) [**vlan** <1-4094>] [**cos** <0-7><0-7>][**ethtype** <0x0600-0xFFFF>]

Switch(config-mac-acl)#**no sequence** <1-2147483647>

Syntax
x

```
[sequence <1-2147483647>] permit (A:B:C:D:E:F/A:B:C:D:E:F|any)
(A:B:C:D:E:F/A:B:C:D:E:F|any) [vlan <1-4094>] [cos <0-7><0-7>][ethtype <0x0600-
0xFFFF>]
no sequence <1-2147483647>
```

<1-2147483647> b (Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.

(A:B:C:D:E:F/A:B:C:D:E:F|any) Specify the source MAC address and mask of packet or any MAC address.

Parameter

(A:B:C:D:E:F/A:B:C:D:E:F|any) Specify the destination MAC address and mask of packet or any MAC address.

[vlan <1-4094>] (Optional) Specify the vlan ID of packet.

[cos <0-7><0-7>] (Optional) Specify the Class of Service value and mask of packet.

[ethtype <0x0600-0xFFFF>] (Optional) Specify Ethernet protocol number of packet.

Mode MAC ACL Configuration

The example shows how to add an ACE that permit packets with source MAC address 22:33:44:55:66:77. VLAN 3 and Ethernet type 1999. You can verify settings by the following show acl command,

```
Switch#configure terminal
```

```
Switch(config)# mac acl test
```

Example

```
Switch(mac-acl)# sequence 999 permit 22:33:44:55:66:77/ FF:FF:FF:FF:FF:FF any  
vlan 3  
ethtype 0x2800
```

```
Switch(mac-acl)# show
```

```
acl
```



```
Switch(config)# mac acl test  
Switch(config-mac-acl)# sequence 999 permit 22:33:44:55:66:77/ FF:FF:FF:FF:FF:FF any vlan 3 ethtype 0x2800  
Switch(config-mac-acl)# show acl  
  
Switch(mac-acl)# show  
ACL access list commands  
sequence 999 permit 22:33:44:55:66:77/ FF:FF:FF:FF:FF:FF any vlan 3 ethtype 0x2800
```

3.3 DENY (MAC) ACL

Use the deny command to add deny conditions for a mac ACE that drop those packets hit the ACE. The “sequence” also represents hit priority when ACL bind to an interface. An ACE not specifies “sequence” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE cannot be added if has the same conditions as existed ACE. Use “shutdown” to shutdown interface while ACE hit.

Switch#configure terminal

Switch(config)# mac acl {NAME }

```
Switch(config-mac-acl)#[sequence <1-2147483647>] deny (A:B:C:D:E:F/ A:B:C:D:E:F|any)
(A:B:C:D:E:F/A:B:C:D:E:F|any) [vlan <1-4094>] [cos <0-7><0-7>] [ethtype <0x0600-0xFFFF>]
[shutdown]
```

```
Switch(config-mac-acl)# no sequence <1-2147483647>
```

```
[sequence <1-2147483647>] deny (A:B:C:D:E:F/A:B:C:D:E:F|any)
(A:B:C:D:E:F/A:B:C:D:E:F|any) [vlan <1-4094>] [cos <0-7><0-7>] [ethtype <0x0600-
0xFFFF>] [shutdown]
Synta
x
no sequence <1-2147483647>
```

<1-2147483647> (Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.

(A:B:C:D:E:F/A:B:C:D:E:F|any)Specify the source MAC address and mask of packet or any MAC address.

(A:B:C:D:E:F/A:B:C:D:E:F|any)Specify the destination MAC address and mask of packet or any MAC address.

Paramet
er

[vlan <1-4094>] (Optional) Specify the vlan ID of packet.

[cos <0-7><0-7>](Optional) Specify the Class of Service value and mask of packet. [ethtype <0x0600-0xFFFF>](Optional) Specify Ethernet protocol number of packet [shutdown](Optional) Shutdown interfaces while ACE hit.

Mode MAC ACL Configuration

The example shows how to add an ACE that denies packets with destination MAC address aa:bb:cc:xx:xx:xx and VLAN 9. You can verify settings by the following show acl command

Switch#configure terminal

Switch(config)# mac acl test

Example

Switch(mac-acl)# sequence 30 permit any any

Switch(mac-acl)# deny any aa:bb:cc:00:0:00/FF:FF:FF:00:00:00 vlan 9 shutdown

Switch(mac-acl)# show acl

```
Switch(config)# mac acl test
Switch(config-mac-acl)# sequence 30 permit any any
Switch(config-mac-acl)# deny any aa:bb:cc:00:0:00/FF:FF:FF:00:00:00 vlan 9 shutdown
Switch(config-mac-acl)# show acl

MAC access list commands:
sequence 30 permit any any
sequence 300 permit 22:32:44:55:66:77/FF:FF:FF:FF:FF:FF any vlan 9 eth-type 0x0001
sequence 1019 deny any aa:bb:cc:00:00:00/FF:FF:FF:00:00:00 vlan 9 shutdown
```

3.4 IP ACL

Use the ip acl command to create an IPv4 access list and to enter ip-acl configuration mode. The name of ACL must be unique that cannot have same name with other ACL or QoS policy. Once an ACL is created, an implicit **deny any** ACE created at the end of the ACL. That is, if there are no matches, the packets are denied. Use the no form of this command to delete.




Fig 3.4.1 IP ACL with permit and

deny. Switch#configure terminal

Switch(config)# ip acl {NAME}

Switch(config)# no ip acl {NAME}

Syntax ip acl {NAME}

x no ip acl {NAME}

Parameter NAME Specify the name of IPv4

ACL Mode Global Configuration

The example shows how to create an IP ACL. You can verify settings by the following show acl command

Switch#configure terminal

Example Switch(config)#ip acl iptest

Switch(config-ip-acl)# do show

```
Switch(config)# ip acl iptest
Switch(config-ip-acl)# show acl
IP access list iptest
```

acl

3.5 PERMIT (IP)

Use the permit command to add permit conditions for an IP ACE that bypasses those packets hit the ACE. The “**sequence**” also represents hit priority when ACL bind to an interface. An ACE not specifies “**sequence**” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE cannot be added if has the same conditions as existed ACE.

Switch#**configure terminal**

Switch(config)# ip acl {NAME}

Switch(config-ip-acl)# permit ip 192.168.1.0/255.255.255.0 any permit icmp any any echo-request any

[sequence <1-2147483647>] permit (<0- 255> |ip|ip|egp|igp |hmp|rdp|ipv6| ipv6:route|ipv6:frag|rsvp|ipv6:icmp|ospf|pim|l2tp|ip) (A.B.C.D/A.B.C.D|any) (A.B.C.D/A.B.C.D|any)[(dscp|precedence) VALUE]]

[sequence <1-2147483647>] permit icmp(A.B.C.D/A.B.C.D|any) (A.B.C.D/A.B.C.D|any) (<0-255>|echo-reply|destination-unreachable|source-quench|echo-request|router-advertisement|router-solicitation|time-exceeded|timestamp|timestamp-reply|traceroute|any) (<0- 255>|any) [(dscp|precedence) VALUE]

[sequence <1-2147483647>] permit tcp (A.B.C.D/A.B.C.D|any) (<0-65535> |echo|discard|daytime|ftp-data|ftp|telnet|smtp|time|hostname|whois|tacacs-ds|domain|www|pop2|pop3|syslog|talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any) (A.B.C.D/A.B.C.D|any) (<0-65535>|echo|discard|daytime|ftp-data|ftp|telnet|smtp|time|hostname|whois| tacacs-

Syntax
X

ds|domain|www|pop2|pop3|syslog|talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any)[match- all TCP_FLAG][(dscp|precedence) VALUE]

[sequence <1-2147483647>] permit udp (A.B.C.D/A.B.C.D|any) (<0-65535> |echo|discard| time|nameserver|tacacs-ds|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|snmp|snmptrap|who|syslog|talk|rip|PORT_RANGE|any) (A.B.C.D/A.B.C.D|any)

<0-65535>|echo |discard|time|nameserver|tacacs-ds|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|snmp|snmptrap|who|syslog|PORT_RANGE|any) [(dscp|precedence) VALUE]

no sequence <1-2147483647>

<1-2147483647> (Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.

(A.B.C.D/A.B.C.D|any) Specify the source IPv4 address and mask of packet or any IPv4 address.

(A.B.C.D/A.B.C.D|any) Specify the destination IPv4 address and mask of packet or any IPv4 address.

[dscp VALUE](Optional) Specify the DSCP of packet.

[precedence VLAUE](Optional) Specify the IP precedence of packet.

icmp-type Specify ICMP message type for filtering ICMP packet. Enter a type name of list or a Parameter number of ICMP message type.

icmp-code Specify ICMP message code for filtering ICMP packet.

I4-source-port Specify TCP/UDP source port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.

I4-destination-port Specify TCP/UDP destination port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.

match-all Specify tcp flag for TCP packet. If a flag should be set it is prefixed by

"+".If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst,

+syn, +fin,-urg, -ack, -psh, -rst, -syn and -fin.To define more than 1 flag - enter additional flags one after another without a space (example +syn-ack).

Mode IP ACL Configuration

The example shows how to add a set of ACEs. You can verify settings by the following show acl command.

This command shows how to permit a source IP address subnet.

```
Switch#configure terminal
```

```
Switch(config)# ip acl {commando}
```

```
Switch(config-ip-acl)#permit ip 192.168.1.0/255.255.255.0 any
```

This command shows how to permit ICMP echo-request packet with any IP address. Switch(config-ip-acl)#permit icmp any any echo-request any

Example

This command shows how to permit any IP address HTTP packets with DSCP 5.

```
Switch(config-ip-acl)#permit tcp any any any www dscp 5
```

This command shows how to permit any source IP address SNMP packet connect to destination IP address 192.168.1.1.

```
Switch(config-ip-acl)#permit udp any any 192.168.1.1/255.255.255.255 snmp
```

```
Switch(config-ip-acl)#show acl
```

```
Switch(config-ip-acl)# permit ip 192.168.1.0/255.255.255.0 any
Switch(config-ip-acl)# permit icmp any any echo-request any
Switch(config-ip-acl)# permit tcp any any any www dscp 5
Switch(config-ip-acl)# permit udp any any 192.168.1.1/255.255.255.255 snmp
Switch(config-ip-acl)# show acl

IP access list iptest
sequence 1 permit ip 192.168.1.0/255.255.255.0 any
sequence 21 permit icmp any any echo-request any
sequence 41 permit tcp any any any www dscp 5
sequence 61 permit udp any any 192.168.1.1/255.255.255.255 snmp
```

3.6 DENY (IP)

Use the deny command to add deny conditions for an IP ACE that drop those packets hit the ACE. The “**sequence**” also represents hit priority when ACL bind to an interface. An ACE not specifies “**sequence**” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE cannot be added if has the same conditions as existed ACE. Use “**shutdown**” to shutdown interface while ACE hit.

```
Switch#configure terminal
```

```
Switch(config)# ip acl {iptest}
```

```
Switch(config-ip-acl)#deny ip 192.168.1.80/255.255.255.255 any
```

```
[sequence <1-2147483647>] deny (<0-255>|ipinip|egp|igp|hmp|rdp|ipv6|ipv6:rout|ipv6:frag|rsvp|ipv6:icmp|ospf|pim|l2tp|ip)(A.B.C.D/A.B.C.D|any)(A.B.C.D/A.B.C.D|any)[(dscp|precedence) VALUE] [shutdown]
```

```
[sequence <1-2147483647>] deny icmp (A.B.C.D/A.B.C.D|any)(A.B.C.D/A.B.C.D|any)( <0-255>|echo-reply|destination-unreachable|
```

```
source-quench|echo-request|router-advertisement|router-solicitation|
```

```
time-exceeded|timestamp|timestamp-reply|traceroute|any)(<0-255>|any) [(dscp|precedence) VALUE] [shutdown]
```

```
[sequence <1-2147483647>]deny tcp (A.B.C.D/A.B.C.D|any) (<0-65535>|echo|
```

```
discard|daytime|ftp- data|ftp|telnet|smtp|time|hostname|whois|tacacs- ds| domain|www|pop2|pop3|syslog|talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any)(<0-
```

Synta
x

```
65535>|echo|discard|daytime|ftp-
```

```
(A.B.C.D/A.B.C.D|any) data|ftp|telnet|smtp|time|hostname|whois| (<0-65535>
```

```
|echo|discard|daytime|ftp-
```

```
data|ftp|telnet|smtp|time|hostname|whois|tacacsd|domain|www|pop2|pop3|syslog|talk| klogin|kshell|sunrpc|drip|PORT_RANGE|any)
```

```
[match-all TCP_FLAG] [(dscp|precedence) VALUE] [shutdown]
```

```
[sequence <1-2147483647>]deny udp (A.B.C.D/A.B.C.D|any)( <0-65535>
```

|echo| s|snmp|snmptrap|who|syslog|
discar talk|rip|PORT_RANGE|any)(A.B.C.D/A.B.C.D|any)(<0-65535>
d|time |echo|discard|time|nameserver|tacacs-ds|domain|bootps|bootpc|tftp|
|name sunrpc|ntp|netbiosns|snmp|snmptrap|who|syslog|PORT_RANGE|any)
server [(dscp|precedenc
|tacac e) VALUE] [shutdown]
s-
ds|do no sequence <1-2147483647>
main|
bootp
s|

b
o
o
t
p
c
|
t
f
t
p
|
s
u
n
r
p
c
|
n
t
p
|
n
e
t
b
i
o
s
-
n

<1-2147483647> (Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.

(A.B.C.D/A.B.C.D|any) Specify the source IPv4 address and mask of packet or any IPv4 address.

(A.B.C.D/A.B.C.D|any) Specify the destination IPv4 address and mask of packet or any IPv4 address.

[dscp VALUE] (Optional) Specify the DSCP of packet.

[precedence VLAUE] (Optional) Specify the IP precedence of packet.

icmp-type Specify ICMP message type for filtering ICMP packet. Enter a type name of list or a number of ICMP message type.

Parameter

icmp-code Specify ICMP message code for filtering ICMP packet.

l4-source-port Specify TCP/UDP source port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.

l4-destination-port Specify TCP/UDP destination port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.

match-all Specify tcp flag for TCP packet. If a flag should be set it is prefixed by "+". If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. To define more than 1 flag - enter additional flags one after another without a space (example +syn-ack).

[shutdown] (Optional) Shutdown interface while ACE hit.

Mode IP ACL Configuration

The example shows how to add an ACE that denies packets with source IP address 192.168.1.80. You can verify settings by the following show acl command

```
Switch#configure terminal
```

```
Switch(config)# ip acl iptest
```

Example

```
e Switch(config-ip-acl)#deny ip 192.168.1.80/255.255.255.255 any
```

Switch(config-ip-acl)#show acl

```
Switch(config)# ip acl iptest
Switch(config-acl)# deny ip 192.168.1.80/255.255.255.255 any
Switch(config-acl)# show acl
.
IP access list iptest:
  sequence 1 deny ip 192.168.1.80/255.255.255.255 any
```

3.7 IPV6 ACL

Use the `ipv6 acl` command to create an IPv6 access list and to enter `ipv6-acl` configuration mode. The name of ACL must be unique that cannot have same name with other ACL or QoS policy. Once an ACL is created, an implicit **“deny any”** ACE created at the end of the ACL. That is, if there are no matches, the packets are denied. Use the `no` form of this command to delete.

Switch#**configure terminal**

Switch(config)# **ipv6 acl** {*NAME*}

Switch(config)# **no ipv6 acl** {*NAME*}

Syntax	ipv6 acl { <i>NAME</i> }
x	no ipv6 acl { <i>NAME</i> }

Parameter	<i>NAME</i> Specify the name of IPv6
-----------	--------------------------------------

ACL Mode	Global Configuration
----------	----------------------

The example shows how to create an IPv6 ACL. You can verify settings by the following `show acl` command

Switch#**configure terminal**

Example	Switch(config)# ipv6 acl
e	ipv6test Switch(config-ipv6-
	acl)# show acl

```
Switch(config)# ipv6 acl ipv6test
Switch(config-ipv6-acl)# show acl
IPv6 access list ipv6test
```

3.8 PERMIT (IPV6)

Use the permit command to add permit conditions for an IPv6 ACE that bypasses those packets hit the ACE. The “sequence” also represents hit priority when ACL bind to an interface. An ACE not specifies “sequence” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE cannot be added if has the same conditions as existed ACE.

```
Switch#configure terminal
```

```
Switch(config)# ipv6 acl {ipv6test}
```

```
Switch(config-ipv6-acl)#permit ipv6 fe80:1122:3344:5566::1/64 any
```

```
[sequence <1-2147483647>] permit (<0-255>|ipv6) (X:X::X:X/ <0-128>|any) (X:X::X:X/ <0-128>|any)[(dscp|precedence) VALUE]
```

```
[sequence <1-2147483647>] permit icmp (X:X::X:X/ <0-128>|any)
```

```
(X:X::X:X/ <0-128>|any) (<0-255>|destination-unreachable|packet-too-
```

```
big|
```

```
time-exceeded|parameter-problem|echo-request|echo-reply|mld-query|mld-report|mldv2-report|mld-done|router-solicitation|router-advertisement|nd-ns|nd-na|any) (<0-255>|any)[(dscp|precedence) VALUE]
```

```
[sequence <1-2147483647>] permit tcp (X:X::X:X/ <0-128>|any)
```

```
(<0-65535>|echo|discard|daytime|ftp-data|ftp|telnet|smtp|time|hostname|whois|tacacs-
```

```
Synta cs- ds|domain|www|pop2|pop3|syslog|
```

```
x talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any) (X:X::X:X/ <0-128>|any)
```

```
(<0-65535>|echo|discard|daytime|ftp-data|ftp|
```

```
telnet|smtp|time|hostname|whois|tacacs-ds|domain|www|pop2|pop3|syslog|talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any)[match-allTCP_FLAG] [(dscp|precedence) VALUE]
```

```
[sequence <1-2147483647>] permit udp (X:X::X:X/ <0-128>|any)
```

```
(<0-65535>|echo|discard|time|nameserver|tacacs-ds|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-
```

```

n      card|time|nameserver|tacacs-ds|domain| bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|
s      snmp|snmptrap|who|syslog|PORT_RANGE|any)
|      [(dscp|precedence) VALUE]
s
n      no sequence <1-2147483647>
m
p
|
s
n
m
p
t
r
a
p
|
w
h
o
|
s
y
s
l
o
g
|
talk|ri
p|POR
T_RAN
GE|an
y)
(X:X::X
:X| <0-
128>|
any)

(<0-
655
35>|
ech
o|dis

```

<1-2147483647>(Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.

(X:X::X:X/<0-128>|any) Specify the source IPv6 address and prefix of packet or any IPv6 address.

(X:X::X:X/<0-128>|any) Specify the destination IPv6 address and prefix of packet or any IPv6 address.

[dscp VALUE](Optional) Specify the DSCP of packet.

[precedence VLAUE](Optional) Specify the IP precedence of packet.

Parameter **icmp-type** Specify ICMP message type for filtering ICMP packet. Enter a type name of list or a number of ICMP message type.

icmp-code Specify ICMP message code for filtering ICMP packet.

I4-source-port Specify TCP/UDP source port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.

I4-destination-port Specify TCP/UDP destination port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.

match-all Specify tcp flag for TCP packet. If a flag should be set it is prefixed by "+".If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin.To define more than 1 flag - enter additional flags one after another without a space (example +syn-ack).

Mode IPv6 ACL Configuration

The example shows how to add a set of ACEs. You can verify settings by the following show acl command.

This command shows how to permit a source IP address subnet.

Switch#**configure terminal**

Example Switch(config)# **ipv6 acl** {commando}

Switch(ipv6-acl)# **permit ipv6 fe80:1122:3344:5566::1/64 any**

Switch(ipv6-acl)# show acl

```
Switch(config-ipv6-acl)# permit ipv6 fe80::122:3344:5566::1/64 any
Switch(config-ipv6-acl)# show acl
IPv6 access list ipv6test
sequence 1 permit ipv6 fe80::122:3344:5566::1/64 any
```

3.9 DENY (IPv6)

Use the deny command to add deny conditions for an IPv6 ACE that drop those packets hit the ACE. The “sequence” also represents hit priority when ACL bind to an interface. An ACE not specifies “sequence” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE cannot be added if has the same conditions as existed ACE. Use “shutdown” to shutdown interface while ACE hit.

Switch#configure terminal

Switch(config)# ipv6 acl {ipv6test}

Switch(config-ipv6-acl)# permit ipv6 fe80:1122:3344:5566::1/64 any

```
[sequence <1-2147483647>] deny (<0-255>|ipv6) (X::X:X/X/ <0-128>|any) (X::X:X/X/ <0-128>|any) [(dscp|precedence) VALUE] [shutdown]
```

```
[sequence <1-2147483647>] deny icmp (X::X:X/X/ <0-128>|any) (X::X:X/X/ <0-128>|any) (<0-255>|destination- unreachable|packet-too-big|
```

```
time-exceeded|parameter-problem|echo-request|echo-reply| mld-query|mld-report|mldv2-report|mld-done| router- solicitation|router-advertisement|nd-ns|nd-na|any) (<0- 255>|any)[(dscp|precedence) VALUE] [shutdown]
```

```
[sequence <1-2147483647>] deny tcp (X::X:X/X/ <0-128>|any) (<0-65535>|echo|discard|daytime|ftp-data|ftp|telnet|smtp|
```

Syntax

```
time|hostname|whois|tacacs-ds|domain|www|pop2|pop3|syslog|talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any) (X::X:X/X/ <0-128>|any) (<0-65535>|echo|discard|daytime|ftp- data|ftp|
```

```
telnet|smtp|time|hostname|whois|tacacs-ds|domain|www|pop2|pop3|syslog|talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any)[match-all TCP_FLAG] [(dscp|precedence) VALUE] [shutdown]
```

```
[sequence <1-2147483647>] deny udp (X::X:X/X/ <0-128>|any) (<0-65535>|echo|discard|time|nameserver|tacacs-ds|domain|
```

```
bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|snmp|snmptrap|who|syslog|
```

```
talk|rip|PORT_RANGE|any) (X::X:X/X/ <0-128>|any) (<0-65535>|echo|discard|time|nameserver|tacacs-ds|domain|
```

```
bootps|bootpc|tftp|sunrpc|ntp|netbios-
```

ns|
snm
p|sn
mptr
ap|
who
|sysl
og|P
ORT
_RA
NGE
|any
)
[(ds
cp|p
rece
den
ce)
VAL
UE]
[shu
tdo
wn]

no
seque
nce
<1-
21474
83647
>

Parameter <1-2147483647>(Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.

(A.B.C.D/A.B.C.D|any) Specify the source IPv4 address and mask of packet or any IPv4 address.

(A.B.C.D/A.B.C.D|any) Specify the destination IPv4 address and mask of packet or any IPv4 address.

[dscp VALUE](Optional) Specify the DSCP of packet.

[precedence VLAUE](Optional) Specify the IP precedence of packet.

icmp-type Specify ICMP message type for filtering ICMP packet. Enter a type name of list or a number of ICMP message type.

Parameter

icmp-code Specify ICMP message code for filtering ICMP packet.

I4-source-port Specify TCP/UDP source port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.

I4-destination-port Specify TCP/UDP destination port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.

match-all Specify tcp flag for TCP packet. If a flag should be set it is prefixed by "+".If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, - urg, -ack, -psh, -rst, -syn and -fin.To define more than 1 flag - enter additional flags one after another without a space (example +syn-ack).

[shutdown](Optional) Shutdown interface while ACE hit.

Mode IP ACL Configuration

The example shows how to add an ACE that denies packets with destination IP address fe80::abcd. You can verify settings by the following show acl command

Switch#**configure terminal**

Switch(config)# **ipv6 acl** {ipv6test}

Example

Switch(config-ip-acl)#**deny ipv6 any fe80::abcd/128**

Switch(config-ip-acl)#show acl

```
Switch(config)# ipv6 acl ipv6test
Switch(config-ipv6-acl)# deny ipv6 any fe80::abod/128
Switch(config-ipv6-acl)# show acl

IPv6 acls list ipv6test
sequence 1 permit ipv6 fe80::1122:3344:5566::1/64 any
sequence 21 deny ipv6 any fe80::abod/128
```

3.10 BIND ACL

Use the **(mac|ip|ipv6) acli {NAME}** command to bind an ACL to interfaces. An interface can bind only one ACL or QoS policy. Use the no form of this command to return to unbind an ACL from interface.




Fig 3.10.1 E2000 Series Switches bind an ACL to interface

Switch#**configure terminal**

Switch(config)# **(mac|ip|ipv6) acli {NAME}**

Switch(config)# **[no] (mac|ip|ipv6) acli {NAME}**

(mac|ip|ipv6) acli {NAME}

Syntax

[no] (mac|ip|ipv6) acli {NAME}

(mac|ip|ipv6) Specify a type of ACL to binding to interface

Parameter

NAME Specify the name of ACL

Mode Interface Configuration

The example shows how to bind an existed ACL to interface.

Switch#**configure terminal**

Switch(config)# **interface**

Example GigabitEthernet 1 Switch(config-if)# **ip**

acli iptest

Switch(config-if)# **do show running-config interfaces GigabitEthernet 1**

```
Switch(config-if)# ip aol ipsec
Switch(config-if)# do show running-config interfaces GigabitEthernet 1
interface g11
 ip aol "ipsec"
```

3.11 SHOW ACL

Use the show acl command to show created ACLs. You can specify macip or ipv6 to show specific type ACL or specify unique name string to show ACL with the name.

Switch#show acl

Switch#show (mac|ip|ipv6) acl

Switch#show (mac|ip|ipv6) acl (NAME)

show acl

Syntax show (mac|ip|ipv6) acl

x show (mac|ip|ipv6) acl NAME

(mac|ip|ipv6) Specify a type of ACL to show

Parameter NAME Specify the name of ACL

Mode Global Configuration Context Configuration

The example shows how to show all IP ACL.

Example Switch# show ip acl

```
Switch# show ip acl
IP access list iptest
sequence 1 deny ip 192.168.1.80/255.255.255 any
```

3.12 SHOW ACL UTILIZATION

Use the show acl utilization command to show the usage of PIE of ASIC. When an ACL bind to interface, it needs ASIC resource to help to filter packet. An ASIC has limited resource. This command help user to know the PIE usage of AISC.

Switch#show acl utilization

Syntax show acl utilization

Mode Global

Configuration

The example shows how to show

utilization ExampleSwitch# show acl utilization

```
Switch# show acl utilization
Type: System Reserve      usage: 256
Type: ASIC-based VTM      usage: 819
Type: App                  usage: 128
```

AUTHENTICATION MANAGER

You can control access to your network through Switch by using authentication methods such as 802.1X, MAC Based and Web Based. Authentication manager implementation that delegates responsibility for authentication to one or more authentication providers. The authentication manager port setting page control all the authentication methods, such as 802.1x, MAC authentication. It also handles network authentication requests and enforces authentication per port basis. The Auth Manager maintains operational data for all port based network connection. Use MAC-based authentication to authenticate devices based on their physical media access control (MAC) address. WEB-Based authentication enables you to authenticate users on switches by redirecting Web browser requests to a login page that requires users to input a valid username and password before they can access the network. WEB-Based Local Account can be defined as the process of verifying someone's identity by using pre-required details (Commonly username and password).

802.1X: 802.1X is an IEEE standard for port-based network access control (PNAC). It provides an authentication mechanism for devices seeking to access a LAN.

During the authentication process, the switch completes multiple message exchanges between the end device and the authentication server. While 802.1X authentication is in process, only 802.1X traffic and control traffic can transit the network.

The 802.1X authentication method only works if the end device is 802.1X-enabled, but many single-purpose network devices such as printers and IP phones do not support the 802.1X protocol. You can configure MAC RADIUS authentication on interfaces that are connected to network devices that do not support 802.1X and for which you want to allow to access the LAN. When an end device that is not 802.1X-enabled is detected on the interface, the switch transmits the MAC address of the device to the authentication server. The server then tries to match the MAC address with a list of MAC addresses in its database. If the MAC address matches an address in the list, the end device is authenticated.


```
Switch#configure terminal
```

```
Switch(config)#authentication (dot1x|mac|web)
```

```
Switch(config)#no authentication
```

```
(dot1x|mac|web)
```

```
authentication (dot1x|mac|web)
```

Synta

```
x no authentication (dot1x|mac|web)
```

Default Default is disabled for all type

Mode Interface Configuration

The following example shows how to enable 802.1x/MAC/WEB authentication.

Switch#configure terminal

Switch(config)# interface GigabitEthernet

1 Switch(config-if)# authentication dot1x

Switch(config-if)# authentication mac

ExampleSwitch(config-if)# authentication web

Switch# show authentication interface GigabitEthernet 1

```
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# authentication dot1x
Switch(config-if)# authentication mac
Switch(config-if)# authentication web
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 1
Interface Configurations
Interface GigabitEthernet1
Admin Control      : disable
Auth Mode         : multi-auth
Type dot1x State  : enabled
Type mac State    : enabled
Type web State    : enabled
Type Order        : dot1x
MAC/WEB Method Order : radius
Guest VLAN        : disabled
Reauthentication  : disabled
Max Sessions     : 256
VLAN Assign Mode  : static
Common Timers
Reauthentication Period: 3600
Inactive Timeout      : 60
Quiet Period          : 60
EAP Parameters
EAP Max Request       : 2
EAP TX Period         : 30
Supplicant Timeout    : 30
Server Timeout        : 30
Webauth Parameters
--More--
```


The following example shows how to configure MAC authentication radius id format to be upper case with colon delimiter every 2 chars

```
Switch#configure terminal
```

```
Switch(config)# authentication mac radius mac-case upper
```

```
Switch(config)# authentication mac radius mac-delimiter colon gap 2
```

Example

```
Switch# show authentication
```

```
Switch(config)# authentication mac radius mac-case upper
Switch(config)# authentication mac radius mac-delimiter colon gap 2
Switch(config)# exit
Switch# show authentication
Authentication mac case      : enabled
Authentication mac state    : enabled
Authentication mac state    : enabled
Authentication mac state    : enabled
Guest VLAN                  : disabled
Mac-auth Radius User ID Format: XX:XX:XX:XX:XX:XX
Mac-auth Local Entry        :
Mac-auth Local Entry        :
Interface Configurations
Interface GigabitEthernet1
Admin Config                : disabled
Port Mode                   : multi-auth
Type Mac State              : enabled
Type Order                  : static
Mac/MS Method Order        : radius
Guest VLAN                  : disabled
Reauthentication            : disabled
Max Retries                 : 24
VLAN Assign Mode            : static
-----
```

4.5 AUTHENTICATION MAC LOCAL

Use “**authentication mac local**” command to add local MAC authentication hosts in database. This local host database is used when MAC authentication method is configured as “**local**”. The MAC authentication module will find host in this local database and authenticated it. Use the no form of this command to delete local host from database.

Switch#**configure terminal**

Switch(config)#**authentication mac local mac-addr control auth [vlan <1-4094>] [reauth-period <300-4294967294>] [inactive-timeout <60-65535>]**

Switch(config)#**authentication mac local mac-addr control**

unauth Switch(config)#**no authentication mac local mac-addr**

authentication mac local mac-addr control auth [vlan <1-4094>] [reauth-period <300-4294967294>] [inactive-timeout <60-65535>]

Syntax

x

authentication mac local mac-addr control unauth

Switch(config)#**no authentication mac local mac-addr**

mac-addr MAC Authentication local MAC address.

control auth Host with this MAC address will be authorized.

control unauth Host with this MAC address will be force-unauthorized

Parameter **vlan <1-4094>**MAC Authentication host assigned VLAN.

reauth-period <300-4294967294>MAC Authentication host reauthentication period inactive-timeout.

<60-65535>MAC authentication host inactive timeout.

Default Default is no local MAC Authentication

entry. Mode Global Configuration

The following example shows how to add a new local mac authentication host.

Switch#configure terminal

```
Switch(config)# authentication mac local 00:11:22:33:00:01 control auth vlan  
3  
reauth-period 500 inactive-timeout 300
```

Switch# show authentication

Example

```
Switch(config)# authentication mac local 00:11:22:33:00:01 control auth vlan 3 reauth-period 500
Switch(config)# exit
Switch# show authentication
Authentication dot1x state : enabled
Authentication mac state : enabled
Authentication web state : enabled
Guest VLAN : disabled
Mac-auth Radius User ID Format: XX-XX-XX-XX-XX-XX
Mac-auth Local Entry :
MAC Address Control VLAN Period Timeout
-----
00:11:22:33:00:01 Authorized 3 500 N/A
Web-auth Local Entry :
Interface Configurations
Interface GigabitEthernet
Admin Control : disable
Host Mode : multi-auth
Type dot1x State : enabled
Type mac State : enabled
Type web State : enabled
Type Order : dot1x
802.1X/WEB Method Order : radius
```

4.6 AUTHENTICATION GUEST-VLAN

Use “**authentication guest-vlan**” command to enable the global setting of guest VLAN and specify guest VLAN ID. Use the “**no**” form of this command to disable guest VLAN.

```
Switch#configure terminal
```

```
Switch(config)#authentication guest-vlan <1-
```

```
4094> Switch(config)#no authentication guest-
```

```
vlan
```

```
authentication guest-vlan <1-4094>
```

Synta

```
x no authentication guest-vlan
```

Parameter <1-4094>Guest VLAN ID

Default Default guest VLAN is

disabled Mode Global Configuration

The following example shows how to create guest VLAN.

```
Switch#configure
```

```
terminal Switch(config)#
```

```
vlan 3 Switch(config-
```

```
vlan)# exit
```

Examp

```
e Switch(config)# authentication guest-vlan 3
```

```
Switch# show authentication
```

```
Switch(config)# vlan 3
Switch(config)# exit
Switch(config)# authentication guest-vlan 3
Switch(config)# exit
Switch# show authentication
Authentication dot1x state      : enabled
Authentication mac state       : enabled
Authentication web state       : enabled
Guest VLAN                      : enabled (3)
Mac-auth Radius User ID Format: XX:XX:XX:XX:XX:XX
Mac-auth Local Entry           :
MAC Address      Control   VLAN   Priority  Timeout
-----
XX:XX:XX:XX:XX:XX Authorized 3      500     N/A
Mac-auth Local Entry           :
Interface Configurations
Interface GigabitEthernet1
Admin Control      : disable
Host Mode          : multi-auth
Type dot1x State   : enabled
Type mac State     : enabled
Type web State     : enabled
Type Order         : dot1x
MAC/WEB Method Order : radius
More
```

4.7 AUTHENTICATION GUEST-VLAN (INTERFACE)

Use “**authentication guest-vlan**” command to enable the port setting of guest VLAN. Use the “**no**”

form of this command to disable guest

VLAN. Switch#**configure terminal**

Switch(config)# **interface** {interface-name}

Switch(config-if)#**authentication guest-vlan**

Switch(config-if)#**no authentication guest-**

vlan

authentication guest-vlan

Synta

x **no authentication guest-vlan**

Default Default guest VLAN is

disabled Mode Interface

Configuration

The following example shows how to enable guest VLAN.

Switch#**configure terminal**

Example Switch(config)# **interface**

GigabitEthernet1 Switch(config-if)#

authentication guest-vlan

```
Switch# configure
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# authentication guest-vlan
```

4.8 AUTHENTICATION HOST-MODE

Use “**authentication host-mode**” command to configure the port, Authentication host mode. Use the “**no**”

form of this command to restore default

value. Switch#**configure terminal**

Switch(config)# **interface** {interface-name}

Switch(config)#**authentication host-mode** (multi-auth|multi-host|single-host)

Switch(config)#**no authentication host-mode**

Syntax
x authentication host-mode (multi-auth|multi-host|single-host) no authentication host-mode

multi-auth Multiple Authentication Mode. In this mode, every client need to pass authenticate procedure individually.

Parameter
multi-host Multiple Host Mode. In this mode, only one client need to be authenticated and other clients will get the same access accessibility.

single-host Single Host Mode. In this mode, only one host is allowed to be authenticated. It is the same as multi-auth mode with max hosts number configure to be 1.

Default Default is multi-auth

mode. Mode Interface Configuration

Example

The
follow
ing
exam
ple
show
s how
to
modif
y port
host
mode
to
multi-
host.
Switc
h#co
nfigur
e
termi
nal
S
W

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# authentication host-mode multi-
host
Switch# show authentication interface
GigabitEthernet 2
```

```
Switch# configure
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# authentication host-mode multi-host
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : auto
Host Mode          : multi-host
Type dhcp State   : disabled
Type mac State    : disabled
Type web State    : disabled
Type snmp        : snmp
MAC/NEE Method Order : radius
Guest VLAN        : disabled
Reauthentication  : enabled
Max Hosts         : 256
```

4.9 AUTHENTICATION MAX-HOSTS

Use “**authentication max-hosts**” command to configure the port max hosts number for multi-auth mode. The host exceed the max host number is not allowed to create authentication session and do authenticating. Use “**no**” form of this command to restore default value.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-name}
```

```
Switch(config-if)#authentication max-hosts <1-
```

```
256> Switch(config-if)#no authentication max-
```

hosts

```
authentication max-hosts <1-256>
```

Synta

```
x no authentication max-hosts
```

Parameter <1-256> Available max host number in multi-auth

mode. Default Default max host number is 256

Mode Interface Configuration

The following example shows how to change port max hosts number.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# authentication max-hosts
```

Examp
e

```
100 Switch# show authentication interface GigabitEthernet 2
```


4.10 AUTHENTICATION METHOD

Use “**authentication method**” command to configure the port authentication method order.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-name}
```

```
Switch(config-if)# authentication method local
```

radius

```
authentication method (local [radius] | radius [local])
```

Syntax

```
x no authentication order
```

Local Use local account to authenticate

Parameter

Radius Use remote RADIUS server to authenticate

Default Default is RADIUS method in first place and no other

method. Mode Interface Configuration

The following example shows how to modify port authentication order to local and then RADIUS.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# authentication method local radius
```

Example

```
e Switch# show authentication interface
```

```
GigabitEthernet 2
```


Switch(config-if)# authentication order (dot1x [mac] [web] | mac [dot1x] [web] | web)

Switch(config-if)# no authentication order

Syntax authentication order (dot1x [mac] [web] | mac [dot1x] [web] | web) no authentication order

dot1x Authenticating user by IEEE 802.1X

Parameter mac Authenticating user by mac based authentication

web Authenticating user by web based

authentication Default Default is dot1x type in first place

and no other types. Mode Interface Configuration

The following example shows how to modify port authentication order to dot1x, mac and web.

Switch#configure terminal

Switch(config)# interface GigabitEthernet 2

Switch(config-if)# authentication order dot1x mac

web

Example

e Switch# show authentication interface GigabitEthernet 2

```
Switch# configure
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# authentication order dot1x mac web
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : disabled
Host Mode          : multi-auth
Type dot1x State   : disabled
Type mac State     : disabled
Type web State     : disabled
Type Schemes      : dot1x mac web
MAC/web Method Order : local radius
Guest VLAN        : disabled
Reauthentication   : disabled
Max Hosts         : 100
VLAN Assign Mode   : static
Common Timers
  Reauthenticate Period: 3600
  Inactive Timeout     : 60
  Quiet Period        : 60
802.1x Parameters
  EAP Max Requests    : 2
  EAP TX Period       : 30
  Reply Timeout       : 30
  Server Timeout      : 30
Web-auth Parameters
```

4.12 AUTHENTICATION PORT-CONTROL

Use “**authentication port-control**” command to enable the port authentication control mode. Use the “**no**”

form of this command to disable authentication port control

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-name}
```

```
Switch(config-if)# authentication port-control (auto|force-auth|force-unauth)
```

```
Switch(config-if)# no authentication port-control
```

Syntax
x authentication port-control (auto|force-auth|force-unauth) no authentication port-control

Parameter
er **Auto** Need passing authentication procedure to get network accessibility
force-auth Port is force authorized and all clients have network accessibility.
force-unauth Port is force unauthorized and all clients have no network accessibility.

Mode Interface Configuration

The following example shows how to configure port control to auto mode.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# authentication port-control
```

```
auto
```

Example
e Switch# show authentication interface GigabitEthernet 1

```
Switch# configure
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# authentication port-control auto
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : auto
Host Mode         : multi-auth
Type dot1x State  : disabled
Type mac State   : disabled
Type web State    : disabled
Type web State    : disabled
Type Order       : dot1x mac web
RADIUS Method Order : local radius
Guest VLAN       : disabled
Resubscription   : disabled
Max Sess        : 100
VLAN Assign Mode : static
Common Timers
Reauthentication Period: 3600
Inactive Timeout      : 60
Quiet Period          : 60
802.1x Parameters
EAP Max Request      : 2
EAP Rx Period        : 30
Supplicant Timeout   : 30
Server Timeout       : 30
WebAuth Parameters
```

4.13 AUTHENTICATION RADIUS-ATTRIBUTES VLAN

Use “**authentication radius-attributes vlan**” command to configure the port RADIUS VLAN assign mode. Use the “**no**” form of this command to disable the port RADIUS VLAN assign.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-name}
```

```
Switch(config-if)# authentication radius-attributes vlan (reject | static)
```

```
Switch(config-if)# no authentication radius-attributes vlan
```

	authentication radius-attributes vlan (reject static)
Syntax	
x	no authentication radius-attributes vlan
	reject If get VLAN authorized information, just use it. However, if there is no VLAN authorized information, reject the host and make it unauthorized.
Parameter	static If get VLAN authorized information, just use it. If there is no VLAN authorized information, keep original VLAN of host.
Default	Default radius attributes VLAN assign mode is
static. Mode	Interface Configuration

The following example shows how to configure port VLAN assign to reject mode.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# authentication radius-attributes vlan reject
```

```
Switch# show authentication interface GigabitEthernet 2
```

Example

```
Switch# configure
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# authentication radius-attributes vlan reject
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
.
Interface GigabitEthernet2
Admin Control      : auto
Auth Mode         : multi-auth
Type dot1x State  : disabled
Type mac State    : disabled
Type web State    : disabled
Type Order        : dot1x mac web
NAC-RX Method Order : local radius
Guest VLAN        : disabled
Authentication    : disabled
Max Hours         : 100
VLAN Assign Mode  : reject
Common Timers
  Reauthenticate Period: 3600
  Inactive Timeout     : 60
  Quiet Period         : 60
802.1x Parameters
  EAP Max Request     : 2
  EAP TX Period       : 30
  Supplicant Timeout  : 30
  Server Timeout      : 30
Web-auth Parameters
-More-#
```

4.14 AUTHENTICATION REAUTH

Use “**authentication reauth**” command to enable the port reauthentication. Use the “**no**” form of this command to disable reauthentication.

Switch#**configure terminal**

Switch(config)# **interface** {interface-

name} Switch(config-if)#

authentication reauth

Switch(config-if)# **no authentication reauth**

authentication reauth

Synta

x **no authentication reauth**

Mode Interface Configuration

The following example shows how to enable port reauthentication.

Switch#**configure terminal**

Switch(config)# **interface**

GigabitEthernet 2 Switch(config-if)#

authentication reauth

Example Switch# **show authentication interface GigabitEthernet 2**

```
Switch# configure
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# authentication reauth
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : auto
Host Mode          : multi-auth
Type dot1x State   : disabled
Type mac State     : disabled
Type web State     : disabled
Type Guest         : dot1x mac web
MAC/Web Method Order : local radius
Guest VLAN        : disabled
Reauthentication   : enabled
Max Hosts         : 100
VLAN Assign Mode   : reject
Common Timers
Reauthenticate Period: 3600
Inactive Timeout    : 60
Quiet Period        : 60
EAP ik Parameters
EAP Max Request     : 2
EAP TX Period       : 30
Supplicant Timeout  : 30
Server Timeout      : 30
Web-auth Parameters
--More--
```

4.15 AUTHENTICATION TIMER INACTIVE

Use “**authentication timer inactive**” command to configure the port inactive timeout value. Sometimes, we may assign a long aging time for a host, but in fact, it is not active. This inactive timeout will detect the host is active or not. If the host is inactive exceed this timeout, it should be removed. Use “**no**” form of this command to restore default value.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-name}
```

```
Switch(config-if)# authentication timer inactive <60-65535>
```

```
Switch(config-if)# no authentication timer inactive
```

	authentication timer inactive <60-65535>
Syntax	
x	no authentication timer inactive
Parameter	<60-65535>Interval in seconds after which if there is no activity from the client then it will be unauthorized
Default	Default inactive timeout is 60

seconds. Mode Interface Configuration

The following example shows how to configure port inactive period.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# authentication timer inactive 300
```

```
Switch# show authentication interface
```

Example

```
e GigabitEthernet 2
```

```
Switch configure
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# authentication timer inactive 300
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
.
Interface GigabitEthernet2
Admin Control      : auto
Host Mode         : multi-auth
Type dot1x State  : disabled
Type mac State   : disabled
Type web State    : disabled
Type Order        : dot1x mac web
MAC/Web Method Order : local radius
Guest VLAN        : disabled
Reauthentication  : enabled
Max Sess         : 100
VLAN Assign Mode  : reject
Common Timers
  Reauthentication Period: 3600
  Inactive Timeout      : 300
  Quiet Period         : 60
EAP-PA Parameters
  EAP Max Request      : 2
  EAP TX Period        : 30
  Supplicant Timeout   : 30
  Server Timeout       : 30
Web-auth Parameters
Host#
```

4.16 AUTHENTICATION TIMER QUIET

Use “**authentication timer quiet**” command to configure the port quiet period value. After authenticating fail many times and the port is guest VLAN disabled, the port/host will enter lock state until quiet period expired. In lock state, the port/host is not allowed to do authenticating. Use “**no**” form of this command to restore default value.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-name}
```

```
Switch(config-if)# authentication timer quiet <0-65535>
```

```
Switch(config-if)# no authentication timer quiet
```

```
Synta      authentication timer quiet <0-65535>
x          no authentication timer quiet
```

```
Parameter <0-65535>Interval in seconds to wait following a failed
authentication exchange
```

```
Default   Default quiet period is 60
```

```
seconds. Mode   Interface Configuration
```

The following example shows how to configure port quiet period.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# authentication timer quiet 300
```

```
Examp     Switch# show authentication interface
le        GigabitEthernet 2
```

```
Switch# configure
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# authentication timer quiet 300
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : auto
Host Mode          : multi-auth
Type dot1x State   : disabled
Type mac State     : disabled
Type web State     : disabled
Type Control       : dot1x mac web
MDC/WEB Method Order : local radius
Guest EAP          : disabled
Reauthentication   : enabled
Max Hosts         : 100
MAB Admin Mode     : reject
Common Timers
Reauthenticate Period: 300
Quiet Period        : 300
MAB Parameters
EAP Max Request     : 2
EAP EA Period       : 30
Supplicant Timeout  : 30
Server Timeout      : 30
Web-mab Parameters
--More--
```

4.17 AUTHENTICATION TIMER REAUTH

Use “**authentication timer reauth**” command to configure the port reauthentication period value with unit second if the reauthentication time is not assigned by local database or remote authentication server. On the other hand, if the reauthentication time is assigned by local database or remote server, this configured reauthentication time will be ignored. Use “**no**” form of this command to restore default value.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-name}
```

```
Switch(config-if)# authentication timer reauth <300-4294967294>
```

```
Switch(config-if)# no authentication timer reauth
```

```
authentication timer reauth <300-4294967294> no authentication timer reauth
```

Syntax

x

Parameter <300-4294967294> Time in seconds after which an automatic re-authentication should be initiated

Default Default reauthentication period is 3600

seconds. Mode Interface Configuration

The following example shows how to configure port reauthentication period.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# authentication timer reauth 300
```

```
Example Switch# show authentication interface
```

```
e
```

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# authentication timer reauth 300
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
  Admin Control      : auto
  Auth Mode         : multi-auth
  Type dot1x State   : disabled
  Type mac State     : disabled
  Type web State     : disabled
  Type Order        : dot1x mac web
  MAC/WEB Method Order : local radius
  Supp. TSM         : disabled
  Reauthentication   : enabled
  Max Hours         : 100
  VAM Assign Mode    : reject
  Common Timers
    Reauthentication Period: 300
    Inactive Timeout      : 300
    Quiet Period         : 300
  802.1x Parameters
    EAP Max Request      : 2
    EAP Tx Period       : 30
```

4.18 AUTHENTICATION WEB LOCAL

Use “**authentication web local**” command to add local account in database. This local account database is used when web authentication method is configured as “**local**”. The web authentication module will find account in this local database and authenticated it. Use the “**no**” form of this command to delete local account from database.

Switch#**configure terminal**

```
Switch(config)# authentication web local username USERNAME password (encryptedCRYPT-PASSWORD | PASSWORD) [vlan <1-4094>] [reauth-period <300-4294967294>] [inactive-timeout <60-65535>]
```

```
Switch(config)# no authentication web local username USERNAME
```

Syntax

```
authentication web local username USERNAME password (encryptedCRYPT-PASSWORD | PASSWORD) [vlan <1-4094>] [reauth-period <300-4294967294>] [inactive-timeout <60-65535>]
```

```
no authentication web local username USERNAME
```

USERNAME Local account user name

Encrypted CRYPT-PASSWORD Encrypted password.

PASSWORD Un-encrypted password.

Parameter

vlan <1-4094> Assigned VLAN of this local account reauth-period

Re-authentication period <300-4294967294> of this local account inactive-timeout.

Inactive timeout <60-65535> of this local account.

Mode

Global Configuration

4.19 AUTHENTICATION WEB MAX-LOGIN-ATTEMPTS

Use “**authentication web max-login-attempts**” command to configure the port WEB authentication max login attempt number. After login fail number exceed, the host will enter Lock state and is not able to authenticate until quiet period exceed. Use “**no**” form of this command to restore default value.

Switch#configure terminal

Switch(config)# interface {interface-id}

Switch(config-if)# authentication web max-login-attempts (infinite|<3-10>)

Switch(config-if)# no authentication web max-login-attempts

Syntax
authentication web max-login-attempts (infinite|<3-10>) no authentication web max-login-attempts

Parameter
infinite Do not care user login fail number
<3-10> Allow user login fail number

Default Default max login attempt number

is 3. Mode Interface Configuration

The following example shows how to configure port max login attempt number.

Switch#configure terminal

Switch(config)# interface GigabitEthernet 2

Switch(config-if)# authentication web max-login-attempts 5

Example

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# authentication web max-login-attempts 5
Switch(config-if)# exit
Switch#show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : auto
Auth Mode         : multi-auth
Type dot1x State  : disabled
Type mac State    : disabled
Type web State    : disabled
Type Creds2      : dot1x mac web
RADIUS Method Order : local radius
Guest VLAN       : disabled
Reauthentication  : enabled
Max Stays        : 120
VLAN Assign Mode  : reject
Common Timers
  Reauthenticate Period : 300
  Inactive Timeout      : 300
  Quiet Period         : 300
Dot1x Parameters
  EAP Max Request      : 2
  EAP TX Period        : 30
  Supplout Timeout     : 30
  Server Timeout       : 30
Web-Auth Parameters
--More--
```

authentication interface GigabitEthernet 2

4.20 CLEAR AUTHENTICATION SESSIONS

Use “**clear authentication sessions**” command to delete existing authentication sessions. If no parameter is specified, all sessions will be deleted. After authentication session is deleted, host need to do authentication procedure again.

```
Switch# clear authentication sessions
```

```
Switch# clear authentication sessions interfaces
```

```
{IF_PORTS} Switch# clear authentication sessions mac
```

```
{mac-addr} Switch# clear authentication sessions
```

```
session-id {WORD} Switch# clear authentication
```

```
sessions type (dot1x|mac|web)
```

```
clear authentication sessions
```

```
clear authentication sessions interfaces {IF_PORTS}
```

```
Syntax clear authentication sessions mac {mac-addr}
```

```
X clear authentication sessions session-id {WORD}
```

```
clear authentication sessions type (dot1x|mac|web)
```

```
interfaces IF_PORTS Clear sessions on specific
```

```
Parameter interface mac mac-addr Clear session with specific
```

```
MAC address session-id WORD Clear session with
```

```
specific session ID type
```

```
(dot1x|mac|web)type Clear session with specific authentication
```

```
Mode Privileged EXEC
```

```
Example
```

T
h
e

f
o
l
l
o
w
i
n
g

e
x
a
m
p
l
e

s
h
o
w
s

h
o
w

t
o

c
l
e
a
r

a
l

I authentication sessions.

Switch# **clear authentication sessions**

Switch# **show authentication sessions**

4.21 DOT1X

Use “**dot1x**” command to enable the global setting of 802.1x. The “**authentication dot1x**” command has the same effect as this one. This command is a backward compatible command. Use the “**no**” form of this command to disable 802.1 x authentications.

Switch#**configure terminal**

Switch(config)# **dot1x**

Switch(config)# **no dot1x**

Syntax
dot1x
no dot1x

Default Default 802.1x is

disabled Mode Global

Configuration

The following example shows how to enable 802.1 x authentications.

Switch#**configure terminal**

Switch(config)# **dot1x**

Example
Switch# **show authentication**

```
Switch(config)# dot1x
Switch(config)# exit
Switch# show authentication
Authentication dot1x state : enabled
Authentication mac state : enabled
Authentication web state : enabled
Port VLAN : enabled (0)
Mac-auth Radius User ID Format: XXXXXXXXXXXXXXXX
Mac-auth Local Entry :
MAC Address Control VLAN Result Inactive
-----
00112233445566 Authorized 3 500 N/A
Mac-auth Local Entry :
User Name VLAN Result Inactive
-----
dot1x 3 301 61
Interface Configurations
Interface GigabitEthernet1
Admin Control : disable
Show Mode : sample-mode
```

4.22 DOT1X GUEST-VLAN

Use “**dot1x guest-vlan**” command to enable the global setting of guest VLAN and specify guest VLAN ID. Use the “**no**” form of this command to disable guest VLAN.

```
Switch#configure terminal
```

```
Switch(config)# dot1x guest-vlan <1-4094>
```

```
Switch(config)# no dot1x guest-vlan
```

```
dot1x guest-vlan <1-4094>
```

Syntax

```
no dot1x guest-vlan
```

Parameter <1-4094>Guest VLAN ID

Default Default guest VLAN is

disabled Mode Global Configuration

The following example shows how to create guest VLAN.

```
Switch#configure terminal
```

```
Switch(config)# vlan 3
```

```
Switch(config-vlan)# exit
```

```
Switch(config)# dot1x guest-
```

Example

```
vlan 3 Switch# show
```

```
authentication
```

```
Switch(config)# vlan 3
Switch(config-vlan)# exit
Switch(config)# dot1x guest-vlan 9
Switch(config)# exit
Switch# show authentication
Authentication dot1x state : enabled
Authentication mac state : enabled
Authentication web state : enabled
Guest VLAN : enabled (3)
Mac-auth Radius User ID Format: XX:XX:XX:XX:XX:XX
Mac-auth Local Entry :
MAC Address Control VLAN Result Inactive
-----
05:11:22:33:00:01 Authorized 3 500 N/A
Mac-auth Local Entry :
Interface Configurations
Interface GigabitEthernet1
Admin Control : disable
Host Mode : single-host
Type dot1x State : enabled
Type mac State : enabled
Type web State : enabled
```

4.23 DOT1X MAX-REQ

Use “**dot1x max-req**” command to configure the port 802.1x max EAP request value. The max request is the maximum number of EAP requests that can be sent. If a response is not received after the defined period (supplicant timeout), the authentication process is restarted. Use “**no**” form of this command to restore default value.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-
```

```
id} Switch(config-if)# dot1x max-
```

```
req <1-10> Switch(config-if)# no dot1x
```

```
max-req
```

```
dot1x max-req <1-10>
```

Synta

```
x no dot1x max-req
```

Parameter <1-10> The maximum number of EAP requests that can be sent. If a response is not received after the defined period (supplicant timeout), the authentication process is restarted.

Default Default EAP max request number

is 2. Mode Interface Configuration

The following example shows how to configure port 802.1x EAP TX period.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
Example dot1x max-req 1
```

```
Switch# show authentication interface GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# dot1x max-req 1
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
  Admin Control      : disable
  Host Mode          : multi-auth
  Type dot1x State   : disabled
  Type mac State     : disabled
  Type web State     : disabled
  Type Guest         : dot1x
  MAC/Web Method Order : radius
  Guest VLAN        : disabled
  Reauthentication   : disabled
  Max Hours         : 256
  VLAN Assign Mode   : static
Common Timers
  Reauthenticate Period: 3600
  Inactive Timeout     : 60
  Quiet Period         : 300
802.1x Parameters
  EAP Max Request     : 1
  EAP TX Period       : 10
```

4.24 DOT1X PORT-CONTROL

Use “**dot1x port-control**” command to enable the port authentication control mode. The “**authentication port-control**” command has the same effect. Use the “**no**” form of this command to disable authentication port control.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-id}
```

```
Switch(config-if)# dot1x port-control (auto|force-auth|force-unauth)
```

```
Switch(config-if)# no dot1x port-control
```

```
dot1x port-control (auto|force-auth|force-unauth)
```

Syntax

```
no dot1x port-control
```

Auto Need passing authentication procedure to get network accessibility

force-auth Port is force authorized and all clients have network accessibility.

force-unauth

Port is force unauthorized and all clients have no network accessibility.

Mode Interface Configuration

The following example shows how to configure port control to auto mode.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
dot1x port-control auto
```

```
Switch# show authentication interface GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# dot1x port-control auto
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : auto
Host Mode         : multi-auth
Type dot1x State  : disabled
Type mac State    : disabled
Type web State    : disabled
Type Control     : dot1x
MAC/WEB Method Order : radius
Guest VLAN       : disabled
Reauthentication  : disabled
Max Hosts        : 256
VLAN Assign Mode : static
Common Timers
Reauthenticate Period: 3600
Inactive Timeout    : 60
Quiet Period        : 300
802.1x Parameters
EAP Max Request     : 1
EAP TX Period       : 10
Reauthenticate Period: 3600
```

4.25 DOT1X REAUTH

Use “**dot1x reauth**” command to enable the port reauthentication. The “**authentication reauth**” command has the same effect, it is a backward compatible command

Switch#**configure terminal**

Switch(config)# **interface** {interface-

id} Switch(config-if)# **dot1x reauth**

Switch(config-if)# **no dot1x reauth**

Syntax
x **dot1x reauth**
no dot1x reauth

Mode Interface Configuration

The following example shows how to enable port reauthentication.

Switch#**configure terminal**

Switch(config)# **interface** {interface-id}

Switch(config-if)# **interface**

GigabitEthernet 2 Switch(config-if)# **dot1x**

Example
e **reauth**

Switch# **show authentication interface** GigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# dot1x reauth
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : auto
Auth Mode         : multi-auth
Type dot1x State  : disabled
Type mac State    : disabled
Type web State    : disabled
Type Order        : dot1x
RADIUS Method Order : radius
Guest VLAN       : disabled
Reauthentication  : enabled
Max Stages       : 256
VLAN Assign Mode  : static
Common Timers
Reauthentication Period: 3600
Inactive Timeout     : 60
Quiet Period         : 300
802.1x Parameters
EAP Max Request     : 1
EAP TX Period       : 10
```

4.26 DOT1X TIMEOUT REAUTH-PERIOD

Use “**dot1x timeout reauth**” command to configure the port reauthentication period value with unit second if the reauthentication time is not assigned by local database or remote authentication server. On the other hand, if the reauthentication time is assigned by local database or remote server, this configured reauthentication time will be ignored. The “**authentication timer reauth**” command has the same effect and it is a backward compatible command. Use “**no**” form of this command to restore default value.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-id}
```

```
Switch(config-if)# dot1x timeout reauth-period <300-4294967294>
```

```
Switch(config-if)# no dot1x timeout reauth-period
```

Synta	dot1x timeout reauth-period <300-
x	4294967294> no dot1x timeout reauth-
	period
Parameter	<300-4294967294>Time in seconds after which an automatic re-authentication should be initiated
Default	Default reauthentication period is 3600 seconds. Mode Interface Configuration
Mode	Interface Configuration
	e

ExampI

The following configuration example shows how to configure port 802.1x reauthentication period. Switch#configure terminal
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# dot1x timeout reauth-period 300
Switch# show authentication interface
GigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# dot1x timeout reauth-period 300
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
  Admin Control      : auto
  Host Mode          : multi-auth
  Type dot1x State   : disabled
  Type mac State     : disabled
  Type web State     : disabled
  Type User          : dot1x
  MAC/NEE Method Order : radius
  Guest VLAN         : disabled
  Reauthentication   : enabled
  Max Hours          : 256
  VLAN Assign Mode   : static
  Common Timers
    Reauthenticate Period: 300
    Inactive Timeout     : 60
    Quiet Period         : 300
  802.1x Parameters
    EAP Max Request      : 1
    EAP TX Period        : 10
```

4.27 DOT1X TIMEOUT QUIET-PERIOD

Use “**dot1x timeout quiet-period**” command to configure the port quiet period value. The “**authentication timer quiet**” command has the same effect and it is backward compatible command. After authenticating fail many times and the port is guest VLAN disabled, the port/host will enter lock state until quiet period expired. In lock state, the port/host is not allowed to do authenticating. Use “**no**” form of this command to restore default value.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-id}
```

```
Switch(config-if)# dot1x timeout quiet-period <0-65535>
```

```
Switch(config-if)# no dot1x timeout quiet-period
```

```
dot1x timeout quiet-period <0-65535>
```

Syntax

```
no dot1x timeout quiet-period
```

Parameter <0-65535> Interval in seconds to wait following a failed authentication exchange

Default Default quiet period is 60

seconds. Mode Interface Configuration

The following example shows how to configure port 802.1x quiet period.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# dot1x timeout quiet-period 300
```

```
Switch# show authentication interface
```

e

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# dot1x timeout quiet-period 300
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : disable
Host Mode         : multi-auth
Type dot1x State  : disabled
Type mac State   : disabled
Type web State    : disabled
Type Order       : dot1x
MAC/WEB Method Order : radius
Guest VLAN       : disabled
Reauthentication : disabled
Max Hours        : 256
VLAN Assign Mode : static
Common Timers
  Reauthenticate Period: 3600
  Inactive Timeout     : 60
  Quiet Period         : 300
802.1x Parameters
  EAP Max Requests    : 2
  EAP TX Period       : 10
```

4.28 DOT1X TIMEOUT SERVER-TIMEOUT

Use “**dot1x timeout server-timeout**” command to configure the port 802.1x server timeout value. The server timeout is the number of seconds that lapses before the device resends a request to the authentication server.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-id}
```

```
Switch(config-if)# dot1x timeout server-timeout <1-65535>
```

```
Switch(config-if)# no dot1x timeout server-timeout
```

```
dot1x timeout server-timeout <1-65535>
```

Syntax

x

```
no dot1x timeout server-timeout
```

Parameter

<1-65535> Number of seconds that lapse before the device resends a request to the authentication server.

Default

Default server timeout is 30 seconds.

Mode

Interface Configuration

The following example shows how to configure port 802.1x server timeout.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# dot1x timeout supp-timeout 150
```

Example

```
Switch# show authentication interface
```

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# dot1x timeout supp-timeout 150
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : disable
Host Mode         : multi-auth
Type dot1x State  : disabled
Type mac State    : disabled
Type web State    : disabled
Type Guest        : dot1x
MAC/WEB Method Order : radius
Guest VLAN        : disabled
Reauthentication  : disabled
Max Hosts         : 256
VLAN Assign Mode  : static
Common Timers
  Reauthenticate Period: 3600
  Inactive Timeout     : 60
  Quiet Period         : 60
802.1x Parameters
  EAP Max Requests    : 2
  EAP TX Period       : 30
```

4.29 DOT1X TIMEOUT SUPP-TIMEOUT

Use “**dot1x timeout supp-timeout**” command to configure the port supplicant timeout value. The supplicant timeout is the number of seconds that lapses before EAP requests are resent to the supplicant. Use “**no**” form of this command to restore default value.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-id}
```

```
Switch(config-if)# dot1x timeout supp-timeout <1-65535>
```

```
Switch(config-if)# no dot1x timeout supp-timeout
```

```
dot1x timeout supp-timeout <1-65535>
```

Syntax

```
x no dot1x timeout supp-timeout
```

Parameter <1-65535>

Number of seconds that lapses before EAP requests are resent to the supplicant

Default Default supplicant timeout is 30

seconds. Mode Interface Configuration

The following example shows how to configure port 802.1x supplicant timeout.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# dot1x timeout supp-timeout 120
```

```
Example Switch# show authentication interface
```

e

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# dot1x timeout supp-timeout 120
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
Interface GigabitEthernet2
Admin Control      : disable
Host Mode         : multi-auth
Type dot1x State  : disabled
Type mac State   : disabled
Type web State   : disabled
Type Control     : local
MAC/WEB Method Order : radius
Guest VLAN       : disabled
Reauthentication : disabled
Max Hosts       : 256
VLAN Assign Mode : static
Common Timers
  Reauthenticate Period: 3600
  Inactive Timeout    : 60
  Quiet Period       : 60
802.1x Parameters
  EAP Max Requests   : 2
  EAP TX Period     : 30
```

4.30 DOT1X TIMEOUT TX-PERIOD

Use “**dot1x timeout tx-period**” command to configure the port 802.1x EAP TX period value. The TX period is the number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the supplicant (client) before resending the request. Use “**no**” form of this command to restore default value.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-id}
```

```
Switch(config-if)# dot1x timeout tx-period <1-65535>
```

```
Switch(config-if)# no dot1x timeout tx-period
```

```
dot1x timeout tx-period <1-65535>
```

Syntax
no dot1x timeout tx-period

Parameter <1-65535> Number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the supplicant (client) before resending the request.

Default Default EAP TX period is 30

seconds. Mode Interface Configuration

The following example shows how to configure port 802.1x EAP TX period.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet
```

```
2 Switch(config-if)# dot1x timeout tx-
```

```
period 10
```

Example

```
Switch# show authentication interface GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# dot1x timeout tx-period 10
Switch(config-if)# exit
Switch(config)# exit
Switch# show authentication interface GigabitEthernet 2
Interface Configurations
-----
Interface GigabitEthernet2
Admin Control    : enable
Auth Mode       : multi-auth
Type dot1x State : disabled
Type aaa State  : disabled
Type web State  : disabled
Type other      : none
MDC/MSR Method Order : radius
Guest VLAN      : disabled
Reauthentication : disabled
Max Hops        : 256
VLAN Access Mode : static
Common Timers
-----
Authentication Period: 3000
Inactive timeout    : 60
Quiet Period       : 60
EAP Parameters
-----
EAP Max Request    : 2
EAP TX Period      : 10
Supplicant Timeout : 120
Server Timeout     : 30
EAP-Auth Parameters
```

4.31 SHOW AUTHENTICATION

Use “show authentication” command to show all authentication manager configurations. Use

“show authentication interface” command to show authentication manager configuration of specific port. Switch# show authentication

Switch# show authentication interfaces *{IF_PORTS}*

show authentication

Synta

x show authentication interfaces *{IF_PORTS}*

Parameter Interfaces *IF_PORTS* Specify port list to show port

configurations Mode Privileged EXEC

This example shows how to show the mac authentication configurations of port GigabitEthernet 1.

Switch# show authentication

```
Switch# show authentication
Authentication dot1x state : enabled
Authentication mac state : enabled
Authentication web state : enabled
Guest VLAN : enabled (3)
Mac-auth Radius User ID Format: XX:XX:XX:XX:XX:XX
Mac-auth Local Entry :
-----
Mac Address      Control      VLAN      Reauth  Inactive
-----
00:11:22:33:00:01 Authorized    3         300     N/A
-----
Web-auth Local Entry :
Interface Configurations :
Interface GigabitEthernet1 :
Admin Control : disable
Host Mode : single-host
Type dot1x State : enabled
Type mac State : enabled
Type web State : enabled
Type Guest : dot1x
MAC/WEB Method Order : radius
More
```

Examp

e Switch# show authentication interface GigabitEthernet 2

```
Switch# show authentication interface GigabitEthernet 2
Interface Configurations :
Interface GigabitEthernet2 :
Admin Control : disable
Host Mode : multi-auth
Type dot1x State : disabled
Type mac State : disabled
Type web State : disabled
Type Guest : dot1x
MAC/WEB Method Order : radius
Guest VLAN : disabled
Reauthentication : disabled
Max Hosts : 256
VLAN Assign Mode : static
Common Timers :
Reauthenticate Period : 3600
Inactive Timeout : 60
Quiet Period : 60
EAP Parameters :
EAP Max Request : 2
EAP TX Period : 10
Supplicant Timeout : 120
Retries Timeout : 30
Web-auth Parameters :
More
```

4.32 SHOW AUTHENTICATION SESSIONS

Use “**show authentication sessions**” command to show authentication detail session information. Switch# **show authentication sessions [detail]**

Switch# **show authentication sessions interface**

{IF_PORTS} Switch# **show authentication sessions**

session-id *{WORD}* Switch# **show authentication session**

type (dot1x|mac|web)

show authentication sessions [detail]

show authentication sessions interface

Syntax

x

{IF_PORTS} **show authentication sessions session-**

id *{WORD}* **show authentication session type**

(dot1x|mac|web)

detail Show session detail information.

Interface *IF_PORTS* Show session detail information of specific port

Parameter

session-id *WORD* Show session detail information of specific session id

Type (dot1x|mac|web) Show session detail information of specific authentication type

Mode Privileged EXEC

This example shows how to show current authentication session brief and detail information.

Example

e

Switch# **show authentication sessions**

Switch# **show authentication sessions detail**

DIAGNOSTIC

E2000 Series Switches Diagnostics offer proactive diagnostics and real-time alerts and provides higher network availability and increased operational efficiency. Log files of a switch are classified into: user log files and diagnostic log files. A diagnostic log file records the service processing flow and fault information. These logs sent to the log buffer, console, or terminal monitors. You can set up a switch to automatically transfer diagnostic information to a remote server. If a fault occurs, you can provide troubleshooting and support.




Fig 5.1.1 Network Troubleshooting Flowchart

5.1 SHOW CABLE-DIAG

To show the estimated copper cable length attached to a specific interface, use the command `show cable-diag` in the Privileged EXEC mode. For the proper information of the cable length, the interface must be active and linked up.

Switch#`show cable-diag interfaces {IF_NMLPORTS}`

Syntax `show cable-diag interfaces {IF_NMLPORTS}`

Parameter Interfaces `{IF_NMLPORTS}` Display the cable diagnostic information of the copper media for an interface ID or a list of interfaces IDs.

Mode Privileged EXEC

The following example shows the result of cable diagnostic for the interface GigabitEthernet 23

Example
Switch# `show cable-diag interfaces GigabitEthernet 23`

```
Switch# show cable-diag interfaces GigabitEthernet 23
Port | Speed | Local pair | Pair length | Pair status
-----|-----|-----|-----|-----
G23 | auto | Pair A | 1.00 | Normal
      |      | Pair B | 1.00 | Normal
      |      | Pair C | 1.00 | Normal
      |      | Pair D | 1.00 | Normal
```


DHCP (Dynamic Host Configuration Protocol)

Syntax
x ip dhcp snooping database write-delay <15-86400>
no ip dhcp snooping database write-delay

Parameter <15-86400> Specifies the seconds of timeout. Specify the duration for which the transfer should be delayed after the binding database changes

Default DHCP snooping database write-delay is 300

seconds Mode Global Configuration

The example shows how to set write-delay timer to 60 seconds. You can verify settings by the following show ip dhcp snooping database command.

Switch#configure terminal

Switch(config)# ip dhcp snooping database write-delay 60

Example

e Switch(config)# do show ip dhcp snooping database

```
Switch(config)# ip dhcp snooping database write-delay 60
Switch(config)# do show ip dhcp snooping database
Time | Type | IP | MAC | File
-----|-----|---|----|----
Write delay timer | 60 seconds
Agent timer | 300 seconds
Agent Binding | Binding
Delay timer expiry | 60 seconds
Agent timer expiry | 60
Last Successful Time | None
Last Failed Time | None
Last Failed Reason | No failure recorded.
-----|-----|---|----|----
Total Requests | 1 |
Successful Transfers | 0 | Failed Transfers | 0
Successful Drops | 0 | Failed Drops | 0
Successful Writes | 0 | Failed Writes | 0
```

6.21 IP DHCP SNOOPING DATABASE TIMEOUT

Use the `ip dhcp snooping database timeout` command to modify the timeout timer. Use the “no” form of this command to default setting.

Switch#configure terminal

Switch(config)# ip dhcp snooping database timeout <0-86400>

Switch(config)# no ip dhcp snooping database timeout

Syntax
x ip dhcp snooping database timeout <0-86400> no ip dhcp snooping database

timeout

Parameter <15-86400> Specifies the seconds of timeout. Specify (in seconds) how long to wait for the database transfer process to finish before stopping the process. Use 0 to define an infinite duration, which means to continue trying the transfer indefinitely

Default DHCP snooping database timeout is 300 seconds

Mode Global Configuration

The example shows how to set timeout timer to 60 seconds. You can verify settings by the following show ip dhcp snooping database command.

Switch#configure terminal

Switch(config)# ip dhcp snooping database timeout 60

Example

```
fileName : backup_file
Write delay timer : 60 seconds
Abort timer : 60 seconds
Agent running : Running
Delay timer expiry : 60 seconds
Abort timer expiry : 0
Last Succeeded Time : None
Last Failed Time : None
Last Failed Reason : No failure recorded.
Total Attempts : 1
Successful Transfers : 0 Failed Transfers : 0
Successful Reads : 0 Failed Reads : 0
Successful Writes : 0 Failed Writes : 0
```

Switch(config)#do show ip dhcp snoop

6.22 CLEAR IP DHCP SNOOPING DATABASE STATISTICS

Use the `clear ip dhcp snooping database statistics` command to clear statistics of DHCP Snooping database.

Switch# `clear ip dhcp snooping database statistics`

Syntax `clear ip dhcp snooping database`

statistics Mode Privileged EXEC

The example shows how to clear statistics of DHCP Snooping agent. You can verify settings by the following `show ip dhcp snooping database` command.

switch# `clear ip dhcp snooping database statistics`

switch# `show ip dhcp snooping database`

Example

```
Switch# clear ip dhcp snooping database statistics
Switch# show ip dhcp snooping database
ipps : tftp://192.168.1.30
filename : backup_file
Write delay timer : 60 seconds
Abort timer : 60 seconds
Agent Running : None
Delay timer expiry : Not Running
Abort timer expiry : Not Running
Last Succeeded Time : None
Last Failed Time : None
Last Failed Reason :
Total Attempts : 0
Successful Transfers : 0 Failed Transfers : 0
Successful Reads : 0 Failed Reads : 0
Successful Writes : 0 Failed Writes : 0
```

6.23 RENEW IP DHCP SNOOPING DATABASE

Use the **renew ip dhcp snooping database** command to renew DHCP Snooping database from backup file. Switch# **renew ip dhcp snooping database**

Syntax **renew ip dhcp snooping database**

Mode Privileged EXEC

The example shows how to renew DHCP Snooping database. You can verify settings by the following **show ip dhcp snooping database** and **show ip dhcp snooping binding** command.

Switch# **renew ip dhcp snooping database**

Examp Switch# **show ip dhcp snooping database**

e

```
Switch# renew ip dhcp snooping database
Switch# show ip dhcp snooping database
Type : tftp: 192.168.1.80
Filename : backup_file
Write Delay Timer : 60 seconds
Abort Timer : 60 seconds
Agent Running : Running
Delay Timer Expiry : 60 seconds
Abort Timer Expiry : 25
Last Successful Time : None
Last Failed Time : 01-12-2018 23:56:13 UTC-7
Last Failed Reason : Unable to access host
Total Attempts : 2
Successful Transfers : 0 Failed Transfers : 1
Successful Reads : 0 Failed Reads : 0
Successful Writes : 0 Failed Writes : 1
```

6.24 SHOW IP DHCP SNOOPING DATABASE

Use the `show ip dhcp snooping database` command to show settings of DHCP Snooping agent. Switch# `show ip dhcp snooping database`

Syntax `show ip dhcp snooping database`

Mode Privileged EXEC

The example shows how to show settings of DHCP Snooping agent.

Switch # `show ip dhcp snooping database`

Example

```
Username: admin
Password: *****
Switch# show ip dhcp snooping database
Type : None
File Name :
Write Delay Timer : 300 seconds
Abort Timer : 300 seconds

Agent Running : None
Delay Timer Expiry : Not Running
Abort Timer Expiry :Not Running

Last Succeeded Time : None
Last Failed Time : None
Last Failed Reason : No failure recorded.

Actual Attempts      : 0
Successful Transfers : 0 Failed Transfers : 0
Successful Reads     : 0 Failed Reads     : 0
Successful Writes    : 0 Failed Writes    : 0
```

DOS Denial-of-Service (DoS)

7.1 DOS

A **Denial-of-Service (DoS) attack** is an attack meant to shut down a machine or network, making it inaccessible to its intended users. DoS attacks accomplish this by flooding the target with traffic, or sending it information that triggers a crash. In both instances, the DoS attack deprives legitimate users (i.e. employees, members, or account holders) of the service or resource they expected.

Victims of DoS attacks often target web servers of high-profile organizations such as banking, commerce, and media companies, or government and trade organizations. Though DoS attacks do not typically result in the theft or loss of significant information or other assets, they can cost the victim a great deal of time and money to handle.

There are two general methods of DoS attacks: flooding services or crashing services. Flood attacks occur when the system receives too much traffic for the server to buffer, causing them to slow down and eventually stop. Popular flood attacks include:

- Buffer overflow attacks – the most common DoS attack. The concept is to send more traffic to a network address than the programmers have built the system to handle. It includes the attacks listed below, in addition to others that are designed to exploit bugs specific to certain applications or networks.
- ICMP flood – leverages misconfigured network devices by sending spoofed packets that ping every computer on the targeted network, instead of just one specific machine. The network is then triggered to amplify the traffic. This attack is also known as the smurf attack or ping of death.
- SYN flood – sends a request to connect to a server, but never complete. Continues until all open ports are saturated with requests and none are available for legitimate users to connect to.

Other DoS attacks simply exploit vulnerabilities that cause the target networks or service to crash. In these attacks, input is sent that takes advantage of bugs in the target that subsequently crash or severely destabilize the network, so that it can't be accessed or used.

To enable the specific Denial of Service (DoS) protection, use the command **dos** in the Global Configuration mode. Otherwise, use the no form of the command to disable the specific DoS protection.

```
Switch#configure terminal
```

```
Switch(config)# dos ipv6-min-frag-size-length 1024
```

```
Switch(config)# dos ipv6-min-frag-size-check
```

dos (daeqsa-deny|icmp-frag-pkts-deny|icmpv4-ping-max-check|icmpv6-ping-max-check|ipv6-min-frag-size-check|land-deny|nullscan-deny|pod-deny|smurf-deny|syn-sportl1024-

deny|synfin-deny|synrst-deny|tcp-frag-off-min-check|tcpblat-deny|tcphdr-min-check|udpblat-deny|xmas-deny)

dos icmp-ping-max-length MAX_LEN

Synta
x

dos ipv6-min-frag-size-length MIN_LEN

dos smurf-netmask MASK

dos tcphdr-min-length HDR_MIN_LEN

no dos (tcp-frag-off-min-check|synrst-deny|synfin-deny|xma-deny|nullscan-deny|syn-sportl1024-deny|tcphdr-min-check|smurf-deny|icmpv6-ping-max-check|icmpv4-ping-max-check|icmp-frag-pkts-deny|ipv6-min-frag-size-check|pod-deny|tcpblat-deny|udpblat-deny|land-deny|daeqsa-deny)

daeqsa-deny Drops the packets if the destination MAC address is equal to the source MAC address.

icmp-frag-pkts-deny Drops the fragmented ICMP packets.

icmpv4-ping-max-check Checks the maximum size of ICMP ping packets, and drops the packets larger than the maximum packet size defined by the command `dos icmp-ping-max-length MAX_LEN`

icmpv6-ping-max-check Checks the maximum size of ICMPv6 ping packets, and drops the packets larger than the maximum packet size defined by the command `dos icmp-ping-max-length MAX_LEN`.

ipv6-min-frag-size-check Checks the minimum size of IPv6 fragments, and drops the packets smaller than the minimum size defined by the command `dos ipv6-min-frag-size-length MIN_LEN`.

land-deny Drops the packets if the source IP address is equal to the destination IP address.

nullscan-deny Drops the packets with NULL scan.

pod-deny Avoids ping of death attack.

smurf-deny Avoids smurf attack.

syn-sportl1024-deny Drops SYN packets with sport less than 1024.

Parameter **synfin-deny** Drops the packets with SYN and FIN bits set.

er

synrst-deny Drops the packets with SYN and RST bits set.

tcp-frag-off-min-check Drops the TCP fragment packets with offset equals to one.

tcpblat-deny Drops the packages if the TCP source port is equal to the TCP destination port.

tcphdr-min-check Checks the minimum TCP header and drops the TCP packets with the header smaller than the minimum size defined by the command `dos tcphdr-min-length HDR_MIN_LEN`.

udpblat-deny Drops the packets if the UDP source port equals to the UDP destination port.

value is 512 bytes.

xmas-deny
Drops the packets if the sequence number is zero, and the FIN, URG and PSH bits are set.

ipv6-min-frag-size-length MIN_LEN Specify the minimum size of IPv6 fragments. The valid range is from 0 to 65535 bytes, and default value is 1240 bytes.

smurf-netmask MASK Specify the netmask of smurf attack. The length range is from 0 to 323 bytes, and default length is 0 bytes.

tcphdr-min-length HDR_MIN_LEN Specify the minimum TCP header length. The length range is from 0 to 31 bytes, and default length is 20 bytes.

icmp-ping-max-length MAX_LENGTH
Specify the maximum size of the ICMPv4/ICMPv6 ping packets. The valid range is from 0 to 65535 bytes, and the default

All of DoS protections are enabled by default. The default parameter are:

- The maximum size of ICMP ping packages is 512 bytes

Default

- The minimum size of IPv6 fragments is 1240 bytes.

- The Smurf netmask length is 0 bytes.

- The minimum TCP header length is 20 bytes

Mode

Global Configuration

The following example sets the minimum fragment size to 1024 bytes, and enables the minimum size of IPv6 fragments validation.

Switch#configure terminal

Switch(config)# dos ipv6-min-frag-size-length 1024

Example

Switch(config)# dos ipv6-min-frag-size-check

```
Switch(config)# dos ipv6-min-frag-size-length 1024
Switch(config)# dos ipv6-min-frag-size-check
Switch(config)# exit
Switch# show dos
-----
Type                               | State (Length)
-----
SMAC equal to MAC                  | enabled
Land (DIP = DIP)                   | enabled
TCP Rst (SPORT = SPORT)            | enabled
TCP Rst (SPORT = SPORT)            | enabled
RND Ping of Death                  | enabled
IPv6 Min Fragment Size             | enabled (1024 Bytes)
ICMP Fragment Protection            | enabled
IPv6 Ping Max Packet Size          | enabled (512 Bytes)
IPv6 Ping Max Packet Size          | enabled (512 Bytes)
Smurf Attack                        | enabled (Netmask Length: 0)
TCP Min Header Length              | enabled (20 Bytes)
TCP Fin (RST = 101)                | enabled
Null Scan Attack                   | enabled
X-Mas Scan Attack                  | enabled
TCP SYN-FIN Attack                 | enabled
TCP SYN-RST Attack                 | enabled
TCP Fragment (Offset = 1)         | enabled
```

7.2 DOS (INTERFACE)

To enable the DoS on the specific interface, use the command **dos** in the Interface Configuration mode. Otherwise, use the “**no**” form of the command to disable the DoS on the interface.

```
Switch#configure terminal
```

```
Switch(config)# interface {interface-
```

```
ID} Switch(config-if)# dos
```

```
Switch(config-if)# no dos
```

```
dos
Syntax
x no dos
```

Default DoS protection is disabled on each

interface. Mode Interface Configuration

The following example enables the DoS on the interface GigabitEthernet 2.

```
Switch#configure terminal
```

```
ExampleSwitch(config)# interface
```

```
Switch(config)# interface gigabitEthernet 2
Switch(config-if)# dos
Switch(config-if)# exit
Switch(config)# exit
Switch# show dos interfaces GigabitEthernet 2
-----
Port      | DoS Protection
-----|-----
g12      | enabled
```

```
GigabitEthernet 2 Switch(config-if)# dos
```

7.3 SHOW DOS

To show the DoS protection configuration, use the command **show dos** in the Privileged EXEC mode. For the status of DoS protection on each interface, use the command **show dos interface** in the Privileged EXEC mode.

```
Switch# show dos
```

```
Switch# show dos interface {/IF_PORTS}
```

show dos

Syntax

```
x show dos interface {/IF_PORTS}
```

Parameter **interface{/IF_PORTS}** An interface ID or the list of interface

IDs Mode Privileged EXEC

The following example shows the global DoS protection configuration.

```
Switch# show dos
```

Example

e

```
Switch# show dos
Type                               | State (Length)
-----
DMAC equal to SMAC                 | enabled
Denial (DIP = SIP)                 | enabled
UDP Blast (DSPORT = SSPORT)        | enabled
TCP Blast (DSPORT = SSPORT)        | enabled
SYN (Range of Deaths)              | enabled
IPV6 Min Fragment Size              | enabled (1024 Bytes)
ICMP Fragment Packets               | enabled
IPV6 Ping Max Packet Size           | enabled (612 Bytes)
IPV6 Ping Max Packet Size           | enabled (612 Bytes)
Smart Attack                         | enabled (Netmask Length: 0)
TCP Min Header Length               | enabled (20 Bytes)
TCP Syn (SPOOF < 1024)             | enabled
Null Scan Attack                    | enabled
Flood Scan Attack                   | enabled
TCP SYN-FIN Attack                  | enabled
TCP SYN-RST Attack                  | enabled
TCP Fragment (offset = 1)           | enabled
```

DYNAMIC ARP INSPECTION

A switch can use DAI (Dynamic ARP Inspection) to prevent certain types of attacks that leverage the use of IP ARP messages. DAI is a security feature that validates ARP packets in a network. DAI intercepts, logs, and discards ARP packets with invalid IP-to-MAC address bindings. This capability protects the network from some man-in-the-middle attacks.




Fig 8.1 Dynamic ARP Inspection Setup

DAI ensures that only valid ARP requests and responses are

relayed. The switch performs these activities:

- Intercepts all ARP requests and responses on untrusted ports
- Verifies that each of these intercepted packets has a valid IP-to-MAC address binding before updating the local ARP cache or before forwarding the packet to the appropriate destination
- Drops invalid ARP packets

DAI determines the validity of an ARP packet based on valid IP-to-MAC address bindings stored in a trusted database, the DHCP snooping binding database. This database is built by DHCP snooping if DHCP snooping is enabled on the VLANs and on the switch. If the ARP packet is received on a trusted interface, the switch forwards the packet without any checks. On untrusted interfaces, the switch forwards the packet only if it is valid.

DAI can validate ARP packets against user-configured ARP access control lists (ACLs) for hosts with statically configured IP addresses.

8.1 IP ARP INSPECTION

Use the **ip arp inspection** command to enable Dynamic Arp Inspection function. Use the “**no**” form of this command to disable.

```
Switch#configure terminal
```

```
Switch(config)#ip arp inspection
```

```
Switch(config)#no ip arp inspection
```

Syntax **ip arp inspection**

x **no ip arp inspection**

Default Dynamic Arp inspection is

disabled Mode Global Configuration

The example shows how to enable Dynamic Arp Inspection on VLAN 2. You can verify settings by the following show ip arp inspection command.

```
Switch#configure terminal
```

```
Switch(config)# ip arp inspection
```

Example Switch(config)# ip arp inspection vlan

```
2 switch# show ip arp inspection
```

```
Switch# configure terminal
Switch(config)# ip arp inspection
Switch(config)# ip arp inspection vlan 2
Switch(config)#
Switch# show ip arp inspection
Dynamic ARP Inspection : enabled
Enable on Vlans       : 2
```

8.2 IP ARP INSPECTION VLAN

Use the **ip arp inspection vlan** command to enable VLANs on Dynamic Arp Inspection function. Use the “no” form of this command to disable VLANs on Dynamic Arp Inspection function.

Switch#**configure terminal**

Switch(config)# **ip arp inspection vlan** {*VLAN-LIST*}

Switch(config)# **no ip arp inspection vlan** {*VLAN-LIST*}

	ip arp inspection vlan { <i>VLAN-LIST</i> }
Syntax	
x	no ip arp inspection vlan { <i>VLAN-LIST</i> }
Parameter	<i>VLAN-LISTS</i> Specify VLAN ID or a range of VLANs to enable or disable dynamic Arp inspection
Default	Default is disabled on all
VLANs Mode	Global Configuration

The example shows how to enable VLAN 1-100 on Dynamic Arp Inspection, and then disable VLAN 30-40 on Dynamic Arp Inspection. You can verify settings by the following show ip arp inspection command.

Switch#**configure terminal**

Switch(config)# **vlan** 1-100

Example Switch(config)# **ip arp inspection**

e

Switch(config)# **ip arp inspection vlan** 1-100

Switch# **show ip arp inspection**

```
Switch# configure terminal
Switch(config)# vlan 1-100
Switch(config-vlan)# exit
Switch(config)# ip arp inspection
Switch(config)# ip arp inspection vlan 1-100
Switch(config)# exit
Switch# show ip arp inspection
Dynamic ARP Inspection    : enabled
Enable on VLANs          : 1-100
```

8.3 IP ARP INSPECTION TRUST

Use the **ip arp inspection trust** command to set trusted interface. The switch does not check ARP packets that are received on the trusted interface; it simply forwards it. Use the “**no**” form of this command to set untrusted interface.

```
Switch#configure terminal
```

```
Switch(config)# ip arp inspection trust
```

```
Switch(config)# no ip arp inspection
```

trust

Syntax
x **ip arp inspection trust**
 no ip arp inspection trust

Default Dynamic Arp inspection trust is

disabled Mode Interface Configuration

The example shows how to set interface gi1 to trust. You can verify settings by the following **show ip arp inspection interface** command.

```
Switch#configure terminal
```

```
Switch(config)# interface gi2
```

Example
e Switch(config)# ip arp inspection trust

```
Switch#show ip arp inspection interface gi2
```



```
Switch#configure terminal
Switch(config)# interface gi2
Switch(config)# ip arp inspection trust
Switch(config)#
Switch#show ip arp inspection interface gi2
Interface | Trust State | Rate (pps) | SMO Check | SMO Check | IP Check/Allow Deny
-----|-----|-----|-----|-----|-----
gi2      | Trusted      | None       | disabled  | disabled  | disabled/enabled
```

8.4 IP ARP INSPECTION VALIDATE

Use the **ip arp inspection validate** command to enable validate function on interface. The **"src-mac"** drop ARP requests and reply packets that arp-sender-mac and ethernet-source-mac is not match. The **"dst-mac"** drops ARP reply packets that arp-target-mac and ethernet-dst-mac is not match. The **"ip"** drop ARP request and reply packets that sender-ip is invalid such as broadcast multicast all zero IP address and drop ARP reply packets that target-ip is invalid. The **"allow-zeros"** means won't drop all zero IP address. Use the **"no"** form of this command to disable validation.

```
Switch#configure terminal
```

```
Switch(config)# ip arp inspection validate src-mac
```

```
Switch(config)# ip arp inspection validate dst-mac
```

```
Switch(config)# ip arp inspection validate ip [allow-zeros]
```

```
Switch(config)# no ip arp inspection validate src-mac
```

```
Switch(config)# no ip arp inspection validate dst-mac
```

```
Switch(config)# no ip arp inspection validate ip [allow-zeros]
```

```
ip arp inspection validate src-
```

```
mac ip arp inspection validate
```

```
dst-mac
```

Syntax

```
x ip arp inspection validate ip [allow-zeros]
```

```
no ip arp inspection validate src-mac
```

```
no ip arp inspection validate dst-mac
```

```
no ip arp inspection validate ip [allow-zeros]
```

Default Default is disabled of all

validation Mode Interface Configuration

The example shows how to set interface gi1 to validate “src-mac”, “dst-mac” and “ip”, “allow zeros”. You can verify settings by the following show ip arp inspection interface command.

```
Switch#configure terminal
```

```
Switch(config)# interface gi2
```

```
Switch(config-if)# ip arp inspection validate src-mac
```

Example

```
Switch(config-if)# ip arp inspection validate dst-ma
```

```
Switch(config-if)# ip arp inspection validate ip allow-
```

```
zeros Switch(config)# do show ip arp inspection
```

```
interface gi2
```

```
Switch(config)# interface gi2
Switch(config-if)# ip arp inspection validate src-mac
Switch(config-if)# ip arp inspection validate dst-mac
Switch(config-if)# ip arp inspection validate ip allow-zeros
Switch(config-if)# do show ip arp inspection interface gi2
Interface | Trust State | Rate (pps) | SMAC Check | DMAC Check | IP Check/Alli
v RARP |
-----|-----|-----|-----|-----|-----|
gi2 | Trusted | None | enabled | enabled | enabled/enable
```

8.5 IP ARP INSPECTION RATE-LIMIT

Use the **ip arp inspection rate-limit** command to set rate limitation on interface. The switch drop ARP packets after receives more than configured rate of packets per second. Use the “no” form of this command to return to default settings.

Switch#**configure terminal**

Switch(config)# **ip arp inspection rate-limit <1-50>**

Switch(config)# **no ip arp inspection rate-limit**

ip arp inspection rate-limit <1-50>

Syntax

x **no ip arp inspection rate-limit**

Parameter **<1-50>**Set 1 to 50 PPS of DHCP packet rate

limitation Default Default is un-limited of ARP packet

Mode Interface Configuration

The example shows how to set rate limit to 30 pps on interface gi2. You can verify settings by the following show ip arp inspection interface command.

Switch#**configure terminal**

Switch(config)# **interface gi2**

Example

e

Switch(config)# **ip arp inspection rate-limit 30**

Switch(config)# **do show ip arp inspection interface gi2**

```
Switch(config)# interface gi2
Switch(config-if)# ip arp inspection rate-limit 30
Switch(config-if)# do show ip arp inspection interface gi2
-----
Interface | Trust State | Rate (pps) | DHCP Check | MAC Check | IP Check/Allow Deny
-----
gi2       | Trust      | 30         | enabled    | enabled    | enabled/enable
```

8.6 CLEAR IP ARP INSPECTION STATISTICS

Use the **clear ip arp inspection interfaces statistics** command to clear statistics that are recorded on interface.

Switch#**clear ip arp inspection interfaces *{IF_PORTS}* statistics**

Syntax **clear ip arp inspection interfaces *{IF_PORTS}***

statistics Parameter *IF_PORTS* specifies ports to clear

statistics

Mode Privileged EXEC

The example shows how to clear statistics on interface gi1. You can verify settings by the following show ip arp inspection interface statistics command.

switch# **clear ip arp inspection interfaces gi2 statistics**

Example

switch# **show ip arp inspection interfaces gi2**

```
Switch# show ip arp inspection interfaces gi2
-----
Interface  Trust  State  Rate  Type  SBC Check  SBC Check  IP Check/Allow Deny
-----
gi2        Trust  State  disabled  disabled  disabled/disabled
```

8.7 SHOW IP ARP INSPECTION

Use the **show ip arp inspection** command to show settings of Dynamic Arp

Inspection. Switch#**show ip arp inspection**

Syntax **show ip dhcp snooping**

Mode Privileged EXEC

The example shows how to show settings of Dynamic Arp Inspection

Example Switch# **show ip arp inspection**

```
Switch# show ip arp inspection
Dynamic ARP Inspection : enabled
Enable on Vlan#       : 1-100
```

8.8 SHOW IP ARP INSPECITON INTERFACE

Use the `show ip arp inspection interfaces` command to show settings or statistics of interface. Switch#`show ip arp inspection interfaces {IF_PORTS}`

Switch#`show ip arp inspection interfaces {IF_PORTS} statistics`

```
show ip arp inspection interfaces {IF_PORTS}
```

Synta
X `show ip arp inspection interfaces {IF_PORTS}`
`statistics`

Parameter `IF_PORTS` specifies ports to show

statistics Mode Privileged EXEC

```
switch# show ip arp inspection
```

Example

```
Switch# show ip arp inspection
Switch ARP Inspection    : enabled
Enable on VLAN          : 1-100

Switch# show ip arp inspection interface gi2
Interfaces | Trust State | Base Ip(s) | SMC Check | DMC Check | IP Check/Allow Deny
-----
gi2        | Trusted       | 30         | enabled  | enabled  | enabled/enabled
```

GVRP (GARP VLAN Registration Protocol)

9.1 GVRP (GLOBAL)

GARP VLAN Registration Protocol (GVRP) is a Generic Attribute Registration Protocol (GARP) application that provides 802.1Q-compliant VLAN pruning and dynamic VLAN creation on 802.1Q trunk ports.



Fig 9.1 GVRP Participant List

With GVRP, the switch can exchange VLAN configuration information with other GVRP switches, prune unnecessary broadcast and unknown unicast traffic, and dynamically create and manage VLANs on switches connected through 802.1Q trunk ports. You must enable GVRP globally before any GVRP processing occurs on the switch. Enabling GVRP globally enables GVRP to perform VLAN pruning on IEEE 802.1Q trunk links. Pruning occurs only on GVRP-enabled trunks.




Fig 9.2 GVRP VLAN sharing

Disable **gvrp** will clear all learned dynamic vlan entry and do not learn dynamic vlan anymore. Use **'show gvrp'** to show configuration.

Switch#**configure terminal**

Switch(config)# **gvrp**

Switch(config)# **no gvrp**

gvrp

Synta

x **no gvrp**

Default GVRP is disabled

Mode Global

Configuration

The following example specifies that set global gvrp test.

Switch#configure terminal

Switch(config)# gvrp

Example Switch# show gvrp

```
Switch(config)# gvrp
Switch(config)# exit
Switch# show gvrp

      GVRP      Status
-----
GVRP              : Enabled
Join time         : 200 ms
Leave time        : 600 ms
LeaveAll time     : 10000 ms
```

9.2 GVRP (INTERFACE)

'no gvrp' will remove dynamic port from vlan. 'gvrp' must work at port mode is trunk.

```
Switch#configure terminal
```

```
Switch(config)# gvrp
```

```
Switch(config)# no gvrp
```

```
Switch# show gvrp configuration interfaces gi2
```

	gvrp
Synta	
x	no gvrp
Default	GVRP is disabled on
interface Mode	Interface mode

The following example specifies that set port gvrp test. The port gvrp enable must set port mode is trunk firstly.

```
Switch#configure terminal
```

```
Switch(config)#interface gi2
```

```
Switch(config-if)# switchport mode
```

Examp

```
e trunk Switch(config)#gvrp
```

```
Switch# show gvrp configuration interfaces gi2
```

```
Switch(config)# interface gi2
Switch(config-if)# switchport mode trunk
Switch(config-if)# exit
Switch(config)# gvrp
Switch(config)# exit
Switch# show gvrp configuration interfaces gi2
Port | GVRP-Status | Registration | Dynamic VLAN Creation
-----|-----|-----|-----
gi2   | Disabled    | Normal      | Enabled
```

9.3 GVRP REGISTRATION-MODE

When set registration-mode is fixed or forbidden, will remove the port from vlan which is dynamic port and not learning vlan.

Switch#**configure terminal**

Switch(config)#**interface** *{interface-ID}*

Switch(config-if)# **gvrp registration-mode** (normal | fixed | forbidden)

Syntax **gvrp registration-mode** (normal | fixed | forbidden)

Parameter (normal | fixed | forbidden) normal: register dynamic vlan, and transmit all vlan attribute. fixed: do not register dynamic vlan, and only transmit static vlan attribute. forbidden: do not register dynamic vlan, and only transmit default vlan attribute.

Mode Interface mode

The following example specifies that set gvrp registration mode test.

Switch#**configure terminal**

Switch(config)# **interface** gi2

Switch(config-if)# **gvrp registration-mode** fixed

Example

Switch# **show gvrp configuration interfaces** gi2

```
Switch(config)# gvrp
Switch(config)# interface gi2
Switch(config-if)# gvrp registration-mode fixed
Switch(config-if)#
Switch# show gvrp configuration interfaces gi2
Port | GVRP-Status | Registration | Dynamic VLAN Creation
-----|-----|-----|-----
gi2   | Disabled    | Fixed      | Enabled
```

9.4 GVRP VLAN-CREATE-FORBID

'gvrp vlan-creation-forbid' will not remove dynamic port from vlan

immediate. Switch#configure terminal

Switch(config)#interface *{interface-ID}*

Switch(config-if)# gvrp vlan-creation-forbid

Switch(config-if)# no gvrp vlan-creation-

forbid

	gvrp vlan-creation-forbid
Synta	
x	no gvrp vlan-creation-forbid

Mode Interface mode

The following example specifies that set port gvrp vlan-creation-forbid test.

Switch#configure terminal

Switch(config)#interface gi2

ExampleSwitch(config-if)# gvrp vlan-creation-forbid

Switch(config-if)#exit

Switch# show gvrp configuration interfaces gi2

```
Switch# configure terminal
Switch(config)# interface gi2
Switch(config-if)# gvrp vlan-creation-forbid
Switch(config-if)#
Switch# show gvrp configuration interface gi2
Port | GVRP-Status | Registration | Dynamic VLAN Creation
-----|-----|-----|-----
gi2   | Disabled    | Flased       | Disabled
```

9.5 CLEAR GVRP STATISTICS

This command will clear the ports error statistics or statistics info.

Switch# **clear gvrp (error-statistics | statistics) [interfaces *{IF_PORTS}*]**

Syntax **clear gvrp (error-statistics | statistics) [interfaces *{IF_PORTS}*]**

Parameter (error-statistics | statistics) [interfaces IF_PORTS] Error-statistics: error gvrp packet statistics Statistics: gvrp event message statistics Specifies posts to clear statistics

Mode Privileged EXEC

The following example specifies that clear gvrp error statistics and statistics

test. Switch# **clear gvrp statistics**

Switch# **clear gvrp error-statistics**

Example

```
Switch# clear gvrp statistics
Switch# clear gvrp error-statistics
Switch# sh gvrp statistics
Port id      : all
Total RX    : 0
JoinEmpty RX : 0
JoinIn RX   : 0
JoinOut RX  : 0
Empty RX    : 0
LeaveIn RX   : 0
LeaveEmpty RX : 0
LeaveAll RX  : 0
Total TX    : 0
JoinEmpty TX : 0
JoinIn TX   : 0
JoinOut TX  : 0
Empty TX    : 0
LeaveIn TX   : 0
LeaveEmpty TX : 0
LeaveAll TX  : 0
```

9.6 SHOW GVRP STATISTICS

This command will display the ports error statistics or statistics info.

Switch# **show gvrp (statistics | error-statistics) [interfaces**

{IF_PORTS}]

Syntax **show gvrp (statistics | error-statistics) [interfaces {IF_PORTS}]**

none Display all ports (statistics| error- statistics) [interfaces *IF_PORTS*]

Parameter

statistics – GVRP statistics error-statistics GVRP error statistics Specifies posts

Default Display all ports statistics

info Mode Privileged EXEC

The following example specifies that display gvrp error statistics and statistics test.

Switch# **show gvrp statistics**

Example

```
Switch# show gvrp statistics
Port Id      : g11
Total RX    : 0
CollRspiry RX : 0
Missin RX   : 0
Empty RX    : 0
Learnin RX  : 0
LearnEmpty RX : 0
Total TX    : 0
CollRspiry TX : 0
Missin TX   : 0
Empty TX    : 0
Learnin TX  : 0
LearnEmpty TX : 0
Total RX    : 0
Total TX    : 0
Port Id      : g12
Total RX    : 0
CollRspiry RX : 0
Missin RX   : 0
Empty RX    : 0
Learnin RX  : 0
LearnEmpty RX : 0
Total RX    : 0
Total TX    : 0
```

9.7 SHOW GVRP

This command will display the gvrp global

info. Switch# **show gvrp**

Syntax **show gvrp**

Mode Privileged EXEC

The following example specifies that display gvrp test.

Example Switch# **show gvrp**

```
Switch# show gvrp
      GVRP      Status
-----
GVRP           : Enabled
Join time      : 200 ms
Leave time      : 400 ms
LeaveAll time   : 10000 ms
```

9.8 SHOW GVRP CONFIGURATION

This command will display the ports configuration

info. Switch# **show gvrp configuration**

Syntax **show gvrp configuration** [interface *{IF_PORTS}*]

Parameter **none** [interfaces *IF_PORTS*] Display all ports configuration Display Specifies posts configuration

Mode Privileged EXEC

The following example specifies that display gvrp port configuration

test. Switch# **show gvrp configuration**

Example

```
Switch# show gvrp configuration
Port | GVRP-Status | Registration | Dynamic VLAN Creation
-----|-----|-----|-----
G1/1  Disabled    Normal      Enabled
G1/2  Disabled    Flooding   Disabled
G1/3  Disabled    Normal      Enabled
G1/4  Disabled    Normal      Enabled
G1/5  Disabled    Normal      Enabled
G1/6  Disabled    Normal      Enabled
G1/7  Disabled    Normal      Enabled
G1/8  Disabled    Normal      Enabled
G1/9  Disabled    Normal      Enabled
G1/10 Disabled    Normal      Enabled
G1/11 Disabled    Normal      Enabled
G1/12 Disabled    Normal      Enabled
G1/13 Disabled    Normal      Enabled
G1/14 Disabled    Normal      Enabled
G1/15 Disabled    Normal      Enabled
G1/16 Disabled    Normal      Enabled
G1/17 Disabled    Normal      Enabled
G1/18 Disabled    Normal      Enabled
G1/19 Disabled    Normal      Enabled
G1/20 Disabled    Normal      Enabled
G1/21 Disabled    Normal      Enabled
G1/22 Disabled    Normal      Enabled
```

IGMP SNOOPING

Syntax `show ip igmp snooping router [(dynamic | forbidden |static)]`

none Show ip igmp router include dynamic and static and forbidden

Parameter **(dynamic | forbidden | static)** Display Ip igmp router info for different type

Mode Privileged EXEC

The following example specifies that show ip igmp snooping

router. Switch# `show ip igmp snooping router`

Example

```
Switch# show ip igmp snooping router
Dynamic Router Table
VID | Port | Expiry Time(Sec)
-----
Total Entry 0

Static Router Table
VID | Port Mask
-----
1 | G11-2

Total Entry 1

Forbidden Router Table
VID | Port Mask
-----
Total Entry 0
```

10.30 SHOW IP IGMP SNOOPING QUERIER

This command will display all of the static vlan ip igmp,querier

info. Switch# **show ip igmp snooping querier**

Syntax **show ip igmp snooping querier**

Mode Privileged EXEC

The following example specifies that show ip igmp snooping querier test.

Switch# **show ip igmp snooping querier**

Example

e

```
Switch# show ip igmp snooping querier
-----
VID | State | Status | Version | Querier IP
-----|-----|-----|-----|-----
1 | Disabled | Non-Querier | No | -----
2 | Disabled | Non-Querier | No | -----
5 | Disabled | Non-Querier | No | -----
-----
Total Entry 3
```

10.31 SHOW IP IGMP SNOOPING

This command will display ip igmp snooping global info.

Switch# show ip igmp snooping

Syntax show ip igmp snooping

Mode Privileged EXEC

The following example specifies that show ip igmp snooping test.

Switch# show ip igmp snooping

Example

```
Switch# show ip igmp snooping
IGMP Snooping Status
-----
Snooping           : Disabled
Report Suppression : Enabled
Operation Version  : v2
Forward Method     : mac
Unknown IP Multicast Action : Flood

Packet Statistics
Total RX           : 10
Valid RX           : 0
Invalid RX         : 10
Other RX           : 0
Leave RX            : 0
Report RX          : 0
General Query RX   : 0
Special Group Query RX : 0
Special Group & Source Query RX : 0
Leave TX            : 0
Report TX          : 0
General Query TX   : 0
Special Group Query TX : 0
Special Group & Source Query TX : 0
```

10.32 SHOW IP IGMP SNOOPING VLAN

This command will display ip igmp snooping vlan

info. Switch# **show ip igmp snooping vlan** [*VLAN-LIST*]

Syntax **show ip igmp snooping vlan** [*VLAN-LIST*]

none Show all ip igmp snooping vlan info

Parameter [*VLAN-LIST*] Show specifies vlan ip igmp snooping info

Mode Privileged EXEC

The following example specifies that show ip igmp snooping vlan test.

Switch# **show ip igmp snooping vlan 1**

Example

```
Switch# show ip igmp snooping vlan 1
IGMP Snooping is globally disabled
IGMP Snooping VLAN 1 admin : enabled
IGMP Snooping operation mode : disabled
IGMP Snooping nonclassifiers admin 3 oper 2
IGMP Snooping query interval: admin 100 sec oper 125 sec
IGMP Snooping query max response : admin 12 sec oper 10 sec
IGMP Snooping last member query count: admin 2 oper 2
IGMP Snooping last member query interval: admin 1 sec oper 1 sec
IGMP Snooping immediate leaves: disabled
IGMP Snooping automatic learning of multicast router ports: enabled
```

10.33 SHOW IP IGMP SNOOPING FORWARD-ALL

This command will display ip igmp snooping forward all info.

Switch#**show ip igmpsnooping forward-all** [*vlan VLAN-LIST*]

Syntax **show ip igmp snooping forward-all** [*vlan VLAN-LIST*]

Parameter **none** Show all ip igmp snooping vlan forward-all info
[vlan VLAN-LIST] Show specifies vlan of ip igmp forward info.

Mode Privileged EXEC

The following example specifies that show ip igmp snooping forward-all test.

Example Switch# **show ip igmp snooping forward-all vlan 2**
e

```
Switch# show ip igmp snooping forward-all vlan 2
IGMP Snooping VLAN      : 2
IGMP Snooping static port : None
IGMP Snooping forbidden port : None
```

10.34 SHOW IP IGMP PROFILE

This command will display ip igmp profile info.

Switch# **show ip igmp profile** [*<1-128>*]

Syntax **show ip igmp profile** [*<1-128>*]

none Show all ip igmp snooping profile

Paramet

er info [*<1-128>*] Show specifies index

profile info

Mode Privileged EXEC

The following example specifies that show ip igmp profile test.

Examp_l Switch# **show ip igmp profile**

e

```
Switch# show ip igmp profile
IP igmp profile index: 1
IP igmp profile action: permit
Range low ip: 224.0.0.0
Range high ip: 224.1.1.1
```

10.35 SHOW IP IGMP FILTER

This command will display ip igmp port filter

info. Switch# **show ip igmp filter** *[interfaces*

IF_PORTS]

Syntax **show ip igmp filter** *[interfaces IF_PORTS]*

none Show all port filter

Parameter **[interfaces IF_PORTS]** Show specifies ports filter

Mode Privileged EXEC

The following example specifies that show ip igmp filter test. Switch# **show ip igmp filter**

Example

```
Switch# show ip igmp filter
Port ID | Profile ID
-----
g11 : None
g12 : None
g13 : None
g14 : None
g15 : None
g16 : None
g17 : None
g18 : None
g19 : None
g110 : None
g111 : None
g112 : None
g113 : None
g114 : None
g115 : None
g116 : None
g117 : None
g118 : None
g119 : None
g120 : None
g121 : None
g122 : None
--More--
```

10.36 SHOW IP IGMP MAX-GROUP

This command will display ip igmp port max-group.

```
Switch# show ip igmp max-group [interfaces  
IF_PORTS]
```

Syntax **show ip igmp max-group** [*interfaces IF_PORTS*]

none Show all port max-group

Parameter [*interfaces IF_PORTS*] Show interfaces

Mode Privileged EXEC

The following example specifies that show ip igmp max-group test.

```
Switch#configure terminal
```

```
Switch(config)#interface {Interface-ID}
```

```
Switch(config-if)#ip igmp max-groups
```

Example 50 Switch# show ip igmp max-group

```
Switch(config)# interface GigabitEthernet  
Switch(config-if)# ip igmp max-groups 50  
Switch(config-if)# exit  
Switch# show ip igmp max-group  
Port ID | Max Group  
-----  
g11 | 256  
g12 | 50  
g13 | 256  
g14 | 256  
g15 | 256  
g16 | 256  
g17 | 256  
g18 | 256  
g19 | 256  
g110 | 256  
g111 | 256  
g112 | 256  
g113 | 256  
g114 | 256  
g115 | 256  
g116 | 256  
g117 | 256  
g118 | 256  
g119 | 256  
g120 | 256  
g121 | 256  
g122 | 256
```

10.37 SHOW IP IGMP MAX-GROUP ACTION

This command will display ip igmp port max-group action.

```
Switch# show ip igmp max-group action [interfaces  
IF_PORTS]
```

Syntax `show ip igmp max-group action [interfaces IF_PORTS]`

`none` Show all port max-group action

Parameter [`interfaces IF_PORTS`] Show specifies ports max-group action

Mode Privileged EXEC

The following example specifies that show ip igmp max-group action test.

```
Switch#configure terminal
```

```
Switch(config)#interface gi2
```

```
Switch(config-if)#ip igmp max-groups action replace
```

Example Switch# show ip igmp max-group action

```
Switch# configure
Switch(config)# interface gi2
Switch(config-if)# ip igmp max-group action replace
Switch(config-if)# exit
Switch# show ip igmp max-group action
Port ID | Max-Group Action
-----|-----
gi1 | deny
gi2 | replace
gi3 | deny
gi4 | deny
gi5 | deny
gi6 | deny
gi7 | deny
gi8 | deny
gi9 | deny
gi10 | deny
gi11 | deny
gi12 | deny
gi13 | deny
gi14 | deny
gi15 | deny
gi16 | deny
gi17 | deny
gi18 | deny
gi19 | deny
gi20 | deny
gi21 | deny
gi22 | deny
-----|-----
```

IP SOURCE GUARD

IP SOURCE GUARD

IP Source Guard is a security feature that restricts IP traffic on untrusted Layer 2 ports by filtering traffic based on the DHCP snooping binding database or manually configured IP source bindings. This feature helps prevent IP spoofing attacks when a host tries to spoof and use the IP address of another host. Any IP traffic coming into the interface with a source IP address other than that assigned (via DHCP or static configuration) will be filtered out on the untrusted Layer 2 ports.



Fig 11.1 IP Source Guard Concept

The IP Source Guard feature is enabled in combination with the DHCP snooping feature on untrusted Layer 2 interfaces. It builds and maintains an IP source binding table that is learned by DHCP snooping or manually configured (static IP source bindings). An entry in the IP source binding table contains the IP address and the associated MAC and VLAN numbers. The IP Source Guard is supported on Layer 2 ports only, including access and trunk ports.

IP Source Guard prevents IP and/or MAC address spoofing attacks on untrusted layer two interfaces. When IP source guard is enabled, all traffic is blocked except for DHCP packets. Once the host gets an IP address through DHCP, only the DHCP-assigned source IP address is permitted. You can also configure a static binding instead of using DHCP.

Dynamic ARP Inspection	IP Source Guard
<ul style="list-style-type: none"> - DHCP Snooping creates IP to MAC bindings - DAI intercepts all ARP requests - Intercepted ARP is validated against IP to MAC binding - Does not switch ARP packets with invalid source address - Used primarily to prevent MITM attacks 	<ul style="list-style-type: none"> - Initially all traffic blocked - Snoops DHCP Address - Creates IP to MAC binding - Installs per port VACL to deny traffic other than snooped source - Protects against IP and MAC spoofing - Will not prevent a MITM attack
Dynamic ARP Inspection	IP Source Guard

Comparison between DAI and IP Source Guard:-

Fig 11.2 Comparison between DAI and IP Source Guard

11.1 IP SOURCE VERIFY

Uses the ip source verify command to enable IP Source Guard function. Default IP Source Guard filter source IP address. The “**mac-and-ip**” filters not only source IP address but also source MAC address. Use the no form of this command to disable. You can verify settings by the show ip source interfaces command.

```
Switch#configure terminal
```

```
Switch(config)# interface {Interface-ID}
```

```
Switch(config-if)# ip source verify [mac-and-
```

```
ip] Switch(config-if)# no ip source verify
```

Syntax	ip source verify [mac-and-ip]
x	no ip source verify

Parameter	mac-and-ip Verify by mac and ip address bundle
-----------	---

Default	IP Source Guard is disabled on interface. Default is that verifying ip
---------	--

address only. Mode	Port Configuration
--------------------	--------------------

The example shows how to enable IP Source Guard with source IP address filtering on interface gi1.

```
Switch#configure terminal
```

```
Switch(config)# interface gi2
```

Example	Switch(config-if)# ip source verify
---------	--

```
Switch(config-if)# ip source verify mac-and-ip
```

```
Switch(config-if)# do show ip source interfaces gi1-2
```

```
Switch(config)# interface g12
Switch(config-if)# ip source verify mac-and-ip
Switch(config-if)# do show ip source interface g1-2
Port | Status | Max Entry | Current Entry
-----|-----|-----|-----
g11 | disabled | No limit | 0
g12 | Verify MAC+IP | No limit | 0
```

11.2 IP SOURCE BINDING

Use the ip source binding command to create a static IP source binding entry has an IP address, its associated MAC address, VLAN ID interface. Use the “no” form of this command to delete static entry.You can verify settings by the “show ip source binding” command.

Switch#configure terminal

Switch(config)# ip source binding {A:B:C:D:E:F} vlan <1-4094> (A.B.C.D) interface {IF_PORT}

Switch(config)# no ip source binding {A:B:C:D:E:F} vlan <1-4094> (A.B.C.D) interface {IF_PORT}

Syntax
x

```
ip source binding {A:B:C:D:E:F} vlan <1-4094> (A.B.C.D) interface {IF_PORT}
no ip source binding {A:B:C:D:E:F} vlan <1-4094> (A.B.C.D) interface {IF_PORT}
```

Parameter

A:B:C:D:E:F Specify a MAC address of a binding entry

VLAN <1-4094> Specify a VLAN ID of a binding entry

A.B.C.D Specify IP address and MASK of a binding entry.

IF_PORT Specify interface of a binding entry.

Mode Global Configuration

The example shows how to add a static IP source binding entry.

Switch#configure terminal

Example

```
Switch(config)# ip source binding 00:11:22:33:44:55 vlan 1 192.168.1.55
interface
GigabitEthernet 1
```

Switch(config)# do show ip source binding



```
Switch#show ip source binding
Switch#show ip source binding
Port      MAC Address      IP              Type      Learn Time
-----
1         00:11:22:33:44:55  192.168.1.55   Static    1:00
```

11.3 SHOW IP SOURCE INTERFACE

Use the show ip source interface command to show settings of IP Source Guard of interface. Switch# **show ip source interfaces** *{IF_PORTS}*

Syntax **show ip source interfaces**

IF_PORTS Parameter *IF_PORTS* specifies

ports to show Mode Privileged EXEC

The example shows how to show settings of IP Source Guard of interface gi1

Examp^l Switch# **show ip source interfaces gi2**
e

```
Switch# show ip source interfaces gi2
Port | Status | Max Entry | Current Entry
-----|-----|-----|-----
gi2 | disabled | No Limit | 0
```

11.4 SHOW IP SOURCE BINDING

Use the show ip source binding command to show binding entries of IP Source

Guard. Switch# show ip source binding *[(dynamic|static)]*

Syntax show ip source binding [(dynamic|static)]

dynamic Show entries that added by DHCP snooping

Parameter

learn static Show entries that added by user

Mode Privileged EXEC

The example shows how to show static binding entries of IP Source Guard.

Example Switch# show ip source binding

```
Switch# show ip source binding
IP Table:
-----
IP Address | Type | Lease Time
```


LINK AGGREGATION

LACP, a sub component of IEEE 802.3ad, provides additional functionality for link aggregation groups (LAGs). Use the link aggregation feature to aggregate one or more Ethernet interfaces to form a logical point-to-point link, known as a LAG, virtual link, or bundle. The MAC client can treat this virtual link like a single link.

Link aggregation increases bandwidth, provides graceful degradation as failure occurs, and increases availability. It provides network redundancy by load-balancing traffic across all available links. If one of the links fails, the system automatically load-balances traffic across all remaining links.

When LACP is not enabled, a local LAG might attempt to transmit packets to a remote single interface, which causes the communication to fail. When LACP is enabled, a local LAG cannot transmit packets unless a LAG with LACP is also configured on the remote end of the link.

A typical LAG deployment includes aggregate trunk links between an access switch and a



distribution switch or customer edge (CE) device.

Fig 12.1 Link aggregation Concept

12.1 LAG

Link aggregation group function allows you to aggregate multiple physical ports into one logic port to increase bandwidth. This command makes normal port join into the specific LAG logic port with static or dynamic mode. Use “**no lag**” to leave the LAG logic port.

```
Switch#configure terminal
```

```
Switch(config)# lag load-balance (src-dst-mac | src-dst-mac-ip)
```

```
Switch(config)# interface {Interface-ID}
```

```
Switch(config-if)# lag <1-8> mode (static | active | passive)
```

```
Switch(config-if)# no lag
```

Note:-Use static mode to enable LAG on Ports.

Syntax	lag <1-8> mode (static active
x	passive) no lag
	<1-8> Specify the LAG id for the interface
	static Specify the LAG to be static mode and join the interface into this LAG.
Parameter	active Specify the LAG to be dynamic mode and join the interface into this LAG with LACP active port.
	passive Specify the LAG to be dynamic mode and join the interface into this LAG with LACP passive port
Mode	Interface Configuration

This example shows how to create a dynamic LAG and join fa1-fa3 to this LAG.

Switch#**configure terminal**

Switch(config)# **lag load-balance src-dst-mac-ip**

Switch(config)# **interface**

GigabitEthernet 1 Switch(config-if)# **lag**

1 mode static

Switch(config)# **interface**

GigabitEthernet 3 Switch(config-if)# **lag**

1 mode static

To show current LAG status. Use command **show lag**

Switch# **show lag**

```
Switch# show lag
Load Balancing: src-dst-mac-ip.
-----
Group ID | Type | Ports
-----
1 | Static | Active: g11,g13
2 | ----- |
3 | ----- |
4 | ----- |
5 | ----- |
6 | ----- |
7 | ----- |
8 | ----- |
```

Examp
le

12.3 LACP

Link Aggregation Control Protocol (LACP) is part of the IEEE specification

(802.3az) that enables you to bundle several physical ports together to form

a single logical

channel (LAG). The Link Aggregation Control Protocol (LACP) provides a method to control the bundling of several physical ports together to form a single logical channel. LAGs multiply the bandwidth, increase port flexibility, and provide

link redundancy between two

devices. Two types of LAGs are

supported:

Static LAG : A LAG is static if the LACP is disabled on it. The group of

ports assigned to a static LAG are always active members.

Dynamic LAG : In Dynamic LAG LACP is enabled on it. The group of ports

assigned to dynamic LAG determines which ports are active member ports. The non-active ports are standby ports ready to replace any failing active member ports.

Load Balancing Traffic forwarded to a LAG is load-balanced across the active member ports, thus achieving an effective bandwidth close to the aggregate bandwidth of all the active member ports of the LAG. Traffic load balancing over the active member ports of a LAG is managed by a hash-based distribution function that distributes Unicast and Multicast traffic based on Layer 2 or Layer 3 packet header information.

The device supports two modes of load balancing:

MAC Addresses :Based on the Destination and Source MAC addresses of all packets.

IP and MAC Addresses: Based on the Destination and Source IP addresses for IP packets, and Destination and Source MAC addresses for non-IP packets.

Timeout: The Timeout controls the period between BPDU transmissions. Long will transmit LACP packets each second, while Short will wait for 30 seconds before sending a LACP packet.

Port Priority: It controls the priority of the ports. If the LACP partner wants to form a larger group than is supported by this device then this parameter will control which ports will be active & which ports will be in backup role. Lower the number means greater the priority. By default system priority for LACP is 32768.

LAG is treated by the system as a single logical port. In particular, the LAG has port attributes similar to a regular port, such as state and speed.

The device supports 8 LAGs with up to 8 ports in a LAG group. Link Aggregation Control Protocol (LACP) provides a standardized means for exchanging information between Switches connected by multiple links that require high-speed redundant links.

Switch#**configure terminal**

Switch(config)# lag load-balance (src-dst-mac | src-dst-mac-ip)

Switch(config)# interface {Interface-ID}

Switch(config-if)# lag <1-8> mode (static | active | passive)

Switch(config-if)# no lag

Note:-Use active and passive mode to enable LACP on Ports.

Syntax	lag <1-8> mode (static active passive) no lag
Parameter	<1-8> Specify the LAG id for the interface static Specify the LAG to be static mode and join the interface into this LAG. active Specify the LAG to be dynamic mode and join the interface into this LAG with LACP active port. passive Specify the LAG to be dynamic mode and join the interface into this LAG with LACP passive port
Mode	Interface Configuration

This example shows how to create a dynamic LAG and join fa1-fa3 to this LAG.

Switch#configure terminal

Switch(config)# lag load-balance src-dst-mac-ip

Switch(config)# interface

GigabitEthernet 1 Switch(config-if)# lag

1 mode active Switch(config)# interface

GigabitEthernet 3

Switch(config-if)# lag 1 mode active

Example

This example shows how to show current LAG status.

Switch# show lag

```
Switch# show lag
LAG Balancing: src-dst-mac-ip.
Group ID | Type | Ports
-----|-----|-----
1 | LACP | Active: g11,g12
2 | -----|-----
3 | -----|-----
4 | -----|-----
5 | -----|-----
6 | -----|-----
7 | -----|-----
8 | -----|-----
```

Switch# show lacp neighbor

```
Switch# show lacp neighbor
LAG
-----
Serial Detailed neighbor information
Switch# show lacp neighbor
Flags: D - Device is sending Fast LACPDU
       F - Device is sending Fast LACPDU
       A - Device is in Active mode   P - Device is in Passive mode
Channel group 1 neighbors
Portname's information:
Port  Flags  Priority  Dev ID  Lp  Admin Oper  Port  Port
-----|-----|-----|-----|----|-----|-----|-----|-----
g11  SF  1  8010.faa2.001e  Fa  Admin  Admin  g11  g11
g12  SF  1  8010.faa2.001e  Fa  Admin  Admin  g12  g12
```

12.3 LACP PORT-PRIORITY

LACP port priority is used for two connected DUT to select aggregation ports. Lower port priority value has higher priority. And the port with higher priority will be selected into LAG first.

```
Switch#configure terminal
```

```
Switch(config)# interface { Interface-ID}
```

```
Switch(config-if)# lacp port-priority <1-
```

```
65535> Switch(config-if)# no lacp port-
```

```
priority
```

```
lacp port-priority <1-65535>
```

Syntax

```
x no lacp port-priority
```

Parameter <1-65535> Specify port priority

value Default Default port priority is 1.

Mode Interface Configuration

This example shows how to configure interface GigabitEthernet 3 with lacp port priority to 1.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
Example GigabitEthernet 3 Switch(config-if)#
```

```
e lacp port-priority 1 Switch# show lacp
```

```
neighbor detail
```


12.4 LACP SYSTEM-PRIORITY

LACP system priority is used for two connected DUT to select master switch. Lower system priority value has higher priority. And the DUT with higher priority can decide which ports are able to join the LAG. Use “no lacp system-priority” to restore to the default priority value.

```
Switch#configure terminal
```

```
Switch(config)# lacp system-priority <1-65535>
```

```
Switch(config)# no lacp system-priority
```

```
lacp system-priority <1-65535>
```

Synta

```
x no lacp system-priority
```

Parameter<1-65535>Specify system priority

value Default Default system priority is

32768.


Mode Global Configuration

This example shows how to configure lacp system priority to 32768.

```
Switch#configure terminal
```

```
Switch(config)# lacp system-priority 32768
```

Examp e Switch# show lacp neighbor detail



12.5 LACP TIMEOUT

LACP need to send LACP packet to partner switch to check the link status. This command configure the interval of sending LACP packets.

```
Switch#configure terminal
```

```
Switch(config)# interface {Inteface-ID}
```

```
Switch(config-if)# lacp timeout (long |
```

```
short) Switch(config-if)# no lacp timeout
```

lacp timeout (long | short)

Synta

x **no lacp timeout**

long Send LACP packet every 30 seconds.

Paramet

er **short** Send LACP packet every 1 second

Default Default LACP timeout is

long. ModelInterface Configuration

This example shows how to configure interface GigabitEthernet 3 lacp timeout to long.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 3 Switch(config-if)#
```

Examp

```
e lacp timeout long Switch# show lacp
```

```
internal detail
```


12.6 SHOW LACP

Use “**show lacp sys-id**” command to displays the system identifier that is being used by LACP. The system identifier is made up of the LACP system priority and the switch MAC address.

Use “**show lacp counter**” command to display LACP statistic information. Use “**show lacp internal**” command to display local information.

Use “**show lacp neighbor**” command to display remote Information State of the specific port. These are the allowed values:

bndl Port is attached to an aggregator and bundled with

other ports. **Susp** Port is in a suspended state; it is not

attached to any aggregator. **hot-sby** Port is in a hot-standby state.

1indiv Port is incapable of bundling with any other port.

1indep Port is in an independent state (not bundled but able to switch data traffic. In this case, LACP is not running on the partner port).

Down-Port is down.

State variables for the port, encoded as individual bits within a single octet with these meanings:

- bit0 LACP_Activity
- bit1 LACP_Timeout
- bit2 Aggregation
- bit3 Synchronization
- bit4 Collecting
- bit5 Distributing
- bit6 Defaulted
- bit7 Expired

Switch# **show lacp sys-id**

Switch# **show lacp [<1-8>] counters**

Switch# **show lacp [<1-8>] (internal | neighbor) [detail]**

show lacp sys-id

Synta show lacp [*<1-8>*] counters

X

show lacp [*<1-8>*] (internal | neighbor) [detail]

Mode Privileged EXEC

This example shows how to show LACP statistics.

Switch# show lacp counters

```
Switch# show lacp counters
```

Port	Sens	Recv	LACPDU	Pkts Err
Channel group 1				
Gi1/1	46	32	0	
Gi1/2	15	23	0	

Switch# show lacp internal

Example

```
Switch# show lacp internal
```

Port	Flags	State	Desired	Actual	Oper	Pris	Pris2
Channel group 1							
Gi1/1	SA	stand	1	stand	stand	1	1
Gi1/2	SA	stand	1	stand	stand	1	1

This example shows how to show LACP remote information.

Switch# show lacp neighbor

```
Switch# show lacp neighbor
```

Port	Flags	Priority	Port ID	Age	Oper	Pris	Pris2
Channel group 1							
Gi1/1	SA	1	1000	0:00:00:00:00:00	stand	1	1
Gi1/2	SA	1	1000	0:00:00:00:00:00	stand	1	1

12.7 SHOW LAG

Use “**show lag**” command to show current LAG load balance algorithm and members

active/inactive status. Switch# **show lag**

Syntax **show lag**

Mode Privileged EXEC

This example shows how to show current LAG status.

Switch# **show lag**

Example

```
Switch# show lag
Load Balancing: src-dst-mac-ip.
-----
Group ID | Type | Ports
-----|-----|-----
1        | Static | Active: gi1,gi3
2        | -----|-----
3        | -----|-----
4        | -----|-----
5        | -----|-----
6        | -----|-----
7        | -----|-----
8        | -----|-----
```

LLDP

LLDP (Link Layer Discovery Protocol) is an IEEE (Institute of Electrical and Electronics Engineers) standard protocol (IEEE 802.1AB) that defines messages, encapsulated in Ethernet frames for the purpose of giving devices a means of announcing basic device information to other devices on the LAN (Local Area Network) through periodic retransmissions out each port every 30 seconds by default.




Fig 13.1 Link Layer Discovery Protocol

Concept What is the need for LLDP?

With all kinds of devices connecting to the network these days, installing, tracking and managing each of them can be quite difficult in large networks.

There are many applications for LLDP. Some of them are,

- To automate the deployment of access devices like IP Phones, Wireless Access Points, etc.
- To help troubleshoot network attached devices.
- To automate firmware management
- To discover the type and location (switch port) of a network device, connected anywhere on the network.
- To build a complete network topology (which is also automatically updated after adds/moves/changes).
- To identify and place a device (like IP phone) on the correct VLAN meant for it, automatically.
- To identify how a device can be powered up (from the main line, from an external source, etc) and how much power it needs.
- To get information like hardware revision, firmware version, serial no, manufacturer/model name, etc from LLDP supported devices connected to the network.

13.1 LLDP

Use “**lldp**” command to enable LLDP RX/TX ability. The LLDP enable status is displayed by “**show lldp**” command. Use the “**no**” form of this command to disable the LLDP. When LLDP is disabled, the behavior of receiving LLDP PDU would be decided by “**lldp**” command.

Switch# **configure terminal**

Switch (config)#**lldp**

Switch (config)#**no lldp**

lldp
Syntax
x **no lldp**

Mode Global Configuration

The following example sets LLDP enable/disable.

Switch# **configure terminal**

Switch (config)# **lldp**

Switch# **show lldp**

Example
e

```
Switch# configure terminal
Switch(config)# lldp
Switch(config)#
Switch# show lldp
State: Enabled
Timer: 30 seconds
Hold multiplier: 4
Maxim. delay: 2 seconds
Tx delay: 2 seconds
LLDP packet handling: Flooding
Port | State | Optional TLVs | Address
-----|-----|-----|-----
G11 | RX,TX | | 192.168.0.1
G12 | RX,TX | | 192.168.0.1
G13 | RX,TX | | 192.168.0.1
G14 | RX,TX | | 192.168.0.1
G15 | RX,TX | | 192.168.0.1
G16 | RX,TX | | 192.168.0.1
G17 | RX,TX | | 192.168.0.1
G18 | RX,TX | | 192.168.0.1
G19 | RX,TX | | 192.168.0.1
G20 | RX,TX | | 192.168.0.1
G21 | RX,TX | | 192.168.0.1
G22 | RX,TX | | 192.168.0.1
G23 | RX,TX | | 192.168.0.1
G24 | RX,TX | | 192.168.0.1
G25 | RX,TX | | 192.168.0.1
G26 | RX,TX | | 192.168.0.1
G27 | RX,TX | | 192.168.0.1
G28 | RX,TX | | 192.168.0.1
```

13.2 LLDP RX

Use “**lldprx**” command to enable the LLDP PDU RX ability. The configuration could be shown by “**show lldp**” command. Use the “**no**” form of this command to disable the RX ability.

Switch# **configure terminal**

Switch(config)#**interface** *{Interface-*

ID} Switch(config-if)# **lldprx**

Switch(config-if)# **no lldprx**

Synta
x **lldprx**
no lldprx

Mode Port Configuration

This example sets port gi1 to enable LLDP TX, port gi2 to disable RX but enable TX, port gi3 to enable RX but disable TX, port gi4 to disable RX and TX.

Switch# **configure terminal**

Switch(config)# **interface range g1-**

10 Switch(config-if-range)# **lldp rx**

Switch(config-if-range)# **lldp tx**

Switch# **show lldp interfaces g1-**

Examp
e **10**

```
Switch# configure terminal
Switch(config)# interface range g1-10
Switch(config-if-range)# lldp rx
Switch(config-if-range)# lldp tx
Switch(config-if-range)#
Switch# show lldp interfaces g1-10

State: Enabled
Timer: 30 Seconds
Hold multiplier: 4
Reinit delay: 2 Seconds
TX delay: 2 Seconds
LLDP packet handling: Flooding

Port | State | Optional TLVs | Address
-----+-----+-----+-----
gi1 | RX, TX | | 192.168.0.1
gi2 | RX, TX | | 192.168.0.2
gi3 | RX, TX | | 192.168.0.1
gi4 | RX, TX | | 192.168.0.1
gi5 | RX, TX | | 192.168.0.1
gi6 | RX, TX | | 192.168.0.1
gi7 | RX, TX | | 192.168.0.2
gi8 | RX, TX | | 192.168.0.1
gi9 | RX, TX | | 192.168.0.1
gi10 | RX, TX | | 192.168.0.1

Port ID: gi1
802.3 optional TLVs:
802.1 optional TLVs:
MVID: Enabled
```

13.3 LLDP TX-INTERVAL

Use “**lldptx-interval**” command to configure the LLDP TX interval. It should be noticed that both “**lldptx-interval**” and “**lldptx-delay**” affects the LLDP PDU TX time. The larger value of the two configurations decides the TX interval. The configuration could be shown by “**show lldp**” command. Use the “**no**” form of this command to restore the interval to default value.

Switch# **configure terminal**

Switch(config)# **lldp tx-interval** <5-

32768> Switch(config)# **no lldp tx-**

interval

lldptx-interval <5-32768>

Synta

x **no lldptx-interval**

Parameter <5-32768>

Specify the LLDP PDU TX interval in unit of second

Default Default TX interval is 30

seconds Mode Global Configuration

This example sets LLDP TX interval to 100 seconds.

Switch# **configure terminal**

Switch(config)# **lldp tx-interval 100**

Examp
le

Switch# **show lldp**

```
Switch# configure terminal
Switch(config)# lldp tx-interval 100
Switch(config)#
Switch# show lldp
State: Enabled
Timer: 100 Seconds
Hold multiplier: 4
Hello delay: 2 Seconds
Tx delay: 2 Seconds
LLDP packet handling: Flooding
```

13.4 LLDP REINIT-DELAY

Use “**lldpreinit-delay**” to configure the LLDP re-initials delay. This delay avoids LLDP generate too many PDU if the port is up and down frequently. The delay starts to count when the port links down. The port would not generate LLDP PDU until the delay counts to zero. The configuration could be shown by “**show lldp**” command. Use the “**no**” form of this command to restore the delay to default value.

Switch# **configure terminal**

Switch(config)# **lldp reinit-delay** <1-10>

Switch(config)# **no lldp reinit-delay**

Lldp reinit-delay <1-10>

Syntax

x **no lldp reinit-delay**

Parameter <1-10>

Specify the LLDP re-initial delay time in unit of second.

Default Default reinital delay is 2

seconds Mode Global Configuration

This example sets LLDP re-initial delay to 5

seconds. Switch# **configure terminal**

Switch(config)# **lldp reinit-delay** 5

Example

e Switch# **show lldp**

```
Switch# configure terminal
Switch(config)# lldp reinit-delay 5
Switch(config)#
Switch# show lldp
State: Enabled
Timer: 180 Seconds
Hold multiplier: 4
Reinit delay: 5 Seconds
Tx delay: 2 Seconds
LLDP packet handling: Flooding
```

13.5 LLDP HOLDTIME-MULTIPLIER

Use “**lldp holdtime-multiplier**” command to configure the LLDP PDU hold multiplier that decides time-to-live (TTL) value sent in LLDP advertisements: $TTL = (tx\text{-interval} * holdtime\text{-multiplier})$. The configuration could be shown by “**show lldp**” command. Use the “**no**” form of this command to restore the multiplier to default value.

Switch# **configure terminal**

Switch(config)# **lldp holdtime-multiplier <2-10>**

Switch(config)# **no holdtime-multiplier**

lldp holdtime-multiplier <2-10>

Syntax

x **no holdtime-multiplier**

Parameter <2-10> Specify the LLDP hold time

multiplier Default lldpholdtime-multiplier 4

Mode Global Configuration

This example sets LLDP hold time multiplier to

3. Switch# **configure terminal**

Switch(config)# **lldp holdtime-multiplier 3**

Example

Switch# **show lldp**

```
Switch# configure terminal
Switch(config)# lldp holdtime-multiplier 3
Switch(config)#
Switch# show lldp
State: Enabled
Timer: 100 Seconds
Hold multiplier: 3
Hello delay: 3 Seconds
Tx delay: 2 Seconds
LLDP packet handling: Flooding
```

13.6 LLDP LLDPDU

Use “**lldp lldpdu**” command to configure the LLDP PDU handling behavior when LLDP is globally disabled. It should be noticed that if LLDP is globally enabled and per port LLDP RX status is configured to disabled, the received LLDP PDU would be dropped instead of taking the global disable behavior. The configuration could be shown by “**show lldp**” command. Use the “**no**” form of this command to restore the behavior to default.

Switch# **configure terminal**

Switch(config)# **lldp lldpdu (filtering|flooding|bridging)**

Syntax **lldp lldpdu (filtering|flooding|bridging)**

bridging When LLDP is globally disabled, LLDP packets are bridging (bridging LLDP PDU to VLAN member ports).

Parameter **filtering** When LLDP is globally disabled, LLDP packets are filtered (deleted).

flooding When LLDP is globally disabled, LLDP packets are flooded (forwarded to all interfaces).

Default Default LLDP PDU handling behavior when LLDP disabled is

flooding Mode Global Configuration

This example sets LLDP disable action to bridging.

Switch# **configure terminal**

Switch(config)# **lldp lldpdu bridging**

Example

Switch# **show lldp**

```
Switch# configure terminal
Switch(config)# lldp lldpdu bridging
Switch(config)#
Switch# show lldp
State: Enabled
Timer: 100 Seconds
Hold multiplier: 3
Receive delay: 0 seconds
Tx delay: 0 seconds
LLDP packet handling: Bridging
```

13.7 LLDP MED

Use “**lldp med**” to configure the LLDP MED enable status. If LLDP MED is enabled, LLDP MED

capability TLV and other selected MED TLV would be attached. The configuration could be shown by “**show lldp med**” command. Use the “**no**” form of this command to disable the LLDP MED status.

```
Switch# configure terminal
```

```
Switch(config)# interface {Interfac-ID}
```


13.8 LLDP MED FAST-START-REPEAT-COUNT

Use “**lldp med fast-start-repeat-count**” command to configure the LLDP PDU fast start TX repeat count. When port links up, it will send LLDP PDU immediately to notify link partner. The number of LLDP PDU sends when it links up depends on fast-start-repeat-count configuration. The LLDP PDU fast-start transmits in interval of one second. The fast start behavior works no matter LLDP MED is enabled or not. The configuration could be shown by “**show lldp med**” command. Use the “**no**” form of this command to restore count to default.

Switch# **configure terminal**

Switch(config)# **lldp med fast-start-repeat-count <1-10>**

Switch(config)# **no lldp med fast-start-repeat-count**

lldp med fast-start-repeat-count <1-10>

Syntax

x **no lldp med fast-start-repeat-count**

Parameter **<1-10>** LLDP PDU fast start TX repeat

counts. Default Default fast start TX repeat count

is 3

Mode Global Configuration

This example sets fast start repeat count to 10.

Switch# **configure terminal**

Switch(config)# **lldp med fast-start-repeat-count**
10

Example

e Switch# **show lldp med**

```
Switch# show lldp med
Fast Start Repeat Count: 10
Port | Capabilities | Network Policy | Location | Inventory | PDU PDU
-----|-----|-----|-----|-----|-----
G1/1 | Yes | Yes | No | No | No
G1/2 | Yes | Yes | No | No | No
G1/3 | Yes | Yes | No | No | No
G1/4 | Yes | Yes | No | No | No
G1/5 | Yes | Yes | No | No | No
G1/6 | Yes | Yes | No | No | No
G1/7 | Yes | Yes | No | No | No
```

13.9 LLDP MED LOCATION

Use “**lldp med location**” command to configure the LLDP MED location data. The “**coordinate**”, “**civic- address**”, “**ecs-elin**” locations are independent, so at most three location TLVs could be sent if their data are not empty. The configuration of location could be shown by “**show lldp interface PORT med**” command. Use the “**no**” form of this command to clear location data.

```
Switch# configure terminal
```

Switch(config)#**interface** *{Interface-ID}*

Switch(config-if)# **lldp med location** (coordination|civic-address|ecs-elin) ADDR

Switch(config-if)# **no lldp med location** (coordination|civic-address|ecs-elin)

Syntax
x **lldp med location** (coordination|civic-address|ecs-elin)
ADDR no lldp med location (coordination|civic-address|ecs-elin)

Parameter
Co-ordination civic-address ecs-elin ADDR Location type to be configured. "ecs-elin" is abbreviation of emergency call service – emergency location identifier number
Specify the location data. Input format is hexadecimal values without colon (for example: 1234AB). For coordination location type, the length of ADDR is 16 bytes. For civic-address, the length is 6 to 160 bytes.
For ecs-elin, the length is 10 to 25 bytes.

Default **Default** Default is no location

data. Mode Mode Port Configuration

This example sets location data for interface gi1.

Switch# **configure terminal**

Switch(config)# **interface** gi1

Switch(config-if)# **lldp med location coordinate**
112233445566778899AABBCCDDEEFF00

Example
Switch(config-if)# **lldp med location civic-address**
112233445566 Switch(config-if)# **lldp med location ecs-elin**
112233445566778899AA Switch# **show lldp interfaces gi1 med**

```
Switch(config)# interface GigabitEthernet 0
Switch(config-if)# link speed location coordinate 11223945566778939A8BCC0DEFF70
Switch(config-if)# link speed location cirt-address 11223945566
Switch(config-if)# link speed location ext-addr 11223945566778939A
Switch(config-if)# end
Switch# show link interfaces gi 0/0

Port | Capabilities | Network Policy | Location | Inventory | PoE PSE
-----+-----+-----+-----+-----+-----
gi | Yes | Yes | No | No | N/A

Port ID: gi
Network policies:
Location:
Coordinates: 11223945566778939A8BCC0DEFF70
Cirt-address: 11223945566
Ext-addr: 11223945566778939A
```

13.10 LLDP MED NETWORK-POLICY

Use “**lldp med network-policy**” command to configure the LLDP MED network policy table and add a network policy entry that can be bind to ports. If LLDP MED network policy voice auto mode is enabled, “**voice**” type network policy cannot be created since it is in auto mode. The network policy table configuration could be shown by “**show lldp med**” command.

Use the “**no**” form of this command to remove network policy entry of specific index. A network policy can be removed only when it is not bind to any port.

Switch# **configure terminal**

```
Switch(config)# lldp med network-policy <1-32> app (voice|voice-signaling|guest-voice|guest-voice-signaling|softphone-voice|video-conferencing|streaming-video|video-signaling) vlan <1-4094> vlan-type (tag|untag) priority <0-7> dscp <0-63>
```

```
Switch(config)# no lldp med network-policy <1-32>
```

Syntax
x

```
lldp med network-policy <1-32> app (voice|voice-signaling|guest-voice|guest-voice-signaling|softphone-voice|video-conferencing|streaming-video|video-signaling) vlan <1-4094> vlan-type (tag|untag) priority <0-7> dscp <0-63>
```

```
no lldp med network-policy <1-32>
```

<1-32>Specify the network policy index.

voice-signaling Specify the network policy application type.

Parameter <1-4094>Specify the VLAN IDtag untag Specify the VLAN tag status

<0-7>Specify the L2 priority

<0-63>Specify the DSCP value

Mode Global Configuration

13.11 LLDP MED NETWORK-POLICY (INTERFACE)

Use “**lldp med network-policy**” command to bind the network policy to port interface. The bonded network policy of one port should be with different types. If network policy TLV is selected over a port, the bonded network policies would be attached in LLDP MED PDU. The configuration of network policy binding could be shown by “**show lldp med**” command.

Switch# **configure terminal**

Switch(config)# **interface** *{Interface-ID ranges}*

Switch(config-if-range)#**lldp med network-policy** (add|remove) *<1-32>*

Syntax **lldp med network-policy** (add|remove) *<1-32>*

addAdd network policy binding for ports.

Parameter**remove**Remove network policy binding for ports.

<1-32> Specify the network policy

index Mode Port Configuration

This example binds network policy for interface gi1 and gi2.

Switch# **show lldp med**

Switch# **configure terminal**

Switch(config)# **interface range** g1-10

Example
e Switch(config-if-range)#**lldp med network-policy** add

1 Switch# **show lldp interfaces** g1-10 med

```
Switch# configure terminal
Switch(config)# interface range g1-10
Switch(config-if-range)# lldp med network-policy add 1
Switch# show lldp interfaces g1-10 med
Name | Operability | Network Policy | Location | Intensity | Port Size
-----|-----|-----|-----|-----|-----
gi1 | Yes | Yes | No | No | No
gi2 | Yes | Yes | No | No | No
gi3 | Yes | Yes | No | No | No
gi4 | Yes | Yes | No | No | No
gi5 | Yes | Yes | No | No | No
gi6 | Yes | Yes | No | No | No
gi7 | Yes | Yes | No | No | No
gi8 | Yes | Yes | No | No | No
gi9 | Yes | Yes | No | No | No
gi10 | Yes | Yes | No | No | No
```

13.12 LLDP MED TLV-SELECT

Use “**lldp med tlv-select**” command to configure the LLDP MED TLV selection. It should be noticed that even no MED TLV is selected, MED capability TLV would be attached if LLDP MED is enable. The configuration could be shown by “**show lldp med**” command. Use the “**no**” form of this command to remove all selected MED TLV over the dedicated ports.

Switch# **configure terminal**

Switch(config)# interface {Interface-ID}

Switch(config-if)# lldp med tlv-select MEDTLV [MEDTLV] [MEDTLV] [MEDTLV]

Switch(config-if)# no lldp med tlv-select

Synta x lldp med tlv-select MEDTLV [MEDTLV] [MEDTLV] [MEDTLV] no

x lldp med tlv-select

Parameter MEDTLV MED optional TLV. Available optional TLVs are : network-policy, location, poe- pse, inventory.

Default network-policy TLV

Mode Port Configuration

This example sets port gi1-2 to select LLDP MED network policy, location, POE-PSE, inventory TLVs, and it sets port gi3-4 to un-select all LLDP MED TLVs.

Switch# configure terminal

Switch(config)# interface g1

Switch(config-if)# lldp med tlv-select network-policy location inventory

Switch(config)# interface g2

Example Switch(config-if)# no lldp med tlv-

select Switch# show lldp interfaces

g1-2 med

```
Switch# configure terminal
Switch(config)# interface g1
Switch(config-if)# lldp med tlv-select network-policy location inventory
Switch(config-if)# exit
Switch(config)# interface g2
Switch(config-if)# no lldp med tlv-select
Switch(config-if)#
Switch# show lldp interfaces gi1-2 med
```

Port	Capabilites	Network Policy	Location	Inventory	PoE PSE
gi1	Yes	Yes	Yes	Yes	No
gi2	Yes	No	No	No	No

13.13 LLDP TLV-SELECT

Use “**lldptlv-select**” command to attach selected TLV in PDU. The configuration could be shown by “**show lldp**” command. Use the “**no**” form of this command to remove all selected TLV.

```
Switch# configure terminal
```

```
Switch(config)# interface {Interface-ID ranges}
```

```
Switch(config-if-range)# lldp tlv-select TLV [TLV] [TLV] [TLV] [TLV] [TLV] [TLV] [TLV]
```

```
Switch(config-if-range)# no lldp tlv-select
```

	lldp tlv-select TLV [TLV] [TLV] [TLV] [TLV] [TLV] [TLV] [TLV] [TLV]
Syntax	no lldp tlv-select
Parameter	TLV Specify the selected optional TLV. Available optional TLVs are : sys-name (system name), sys-desc (system description), sys-cap (system capability), mac-phy (802.3 MAC- PHY), lag (802.3 link aggregation), max- frame-size (802.3 max frame size), and management- addr (management address).
Mode	Port Configuration

This example selects system name, system description, system capability,

802.3 MAC-PHY, 802.3 link aggregation, 802.3 max frame size, and management address TLVs for interface gi1 and gi3.

```
Switch# configure terminal
```

```
Switch(config)# interface range g 1,3
```

```
Switch(config-if-range)# lldp tlv-select port-desc sys-name sys-desc sys-cap mac-  
phy lag max-frame-size
```

```
Switch(config-if-range)# end
```

Example

```
Switch# show lldp interfaces g 1,3
```

```
Switch# configure terminal
Switch(config)# interface range g 1,3
Switch(config-if-range)#
Switch# show lldp interfaces g 1,3

State: Enabled
Timer: 100 Seconds
Hold multiplier: 3
Transmit delay: 0 Seconds
TX delay: 2 Seconds
LLDP packet handling: Bridging

Peer | State | Optional TLVs | Address
-----+-----+-----+-----
g11 | EX, TX | PD, SN, SD, SC | 192.168.0.1
g13 | EX, TX | PD, SN, SD, SC | 192.168.0.1
```

13.14 LLDP TLV-SELECT PVID

Use “**lldptlv-select pvid**” command to configure the 802.1 PVID TLV attachenable status. The configuration could be shown by “**show lldp**” command. Use the “**no**” form of this command to restore the pvid to default value.

```
Switch# configure terminal
```

```
Switch(config)# interface {Interface-ID}
```

```
Switch(config-if)# lldp tlv-select pvid
```

```
(disable|enable) Switch(config-if)# no lldp tlv-
```

```
select pvid
```

	Lldp tlv-select pvid
Syntax	
x	(disable enable) no lldp tlv-select
	pvid
Parameter	Disable Disable LLDP 802.1 PVID TLV attach state
er	Enable Enable LLDP 802.1 PVID TLV attach state
Mode	Port Configuration

This example sets port gi1 PVID TLV attaches status to disable and port gi2 to

enable. Switch# **configure terminal**

```
Switch(config)# interface gi1
```

```
Switch(config-if)# lldp tlv-select pvid
```

```
disable Switch(config-if)# interface gi2
```

```
Switch(config-if)# lldp tlv-select pvid
```

```
Example enable Switch# show lldp interfaces  
e
```

g

i1,g12

```
Switch# configure terminal
Switch(config)# interface gi1
Switch(config-if)# link-speed prd disable
Switch#
Switch# configure terminal
Switch(config)# interface gi1
Switch(config-if)# link-speed prd disable
Switch#
Switch# configure terminal
Switch(config)# interface gi1
Switch(config-if)# link-speed prd disable
Switch#
Switch# configure terminal
Switch(config)# interface gi1
Switch(config-if)# link-speed prd disable
Switch#
Switch# configure terminal
Switch(config)# interface gi2
Switch(config-if)# link-speed prd enable
Switch#
Switch# show link interface gi1,gi2

State: Enabled
Timer: 100 Seconds
RUI multiplier: 3
Result delay: 1 Seconds
Tx delay: 2 Seconds
LSP packet handling: Stripping

Port      State | Optional TTY | Address
-----
gi1 | RX, TX | FD, SW, SD, SC | 192.168.0.1
gi2 | RX, TX | | 192.168.0.1

Port ID: gi1
CPU: 3 optional TTYs, 002.3-memphy, 002.3-lsp, 002.3-mse-frame-size
CPU: 4 optional TTYs
PROM: disabled
VLAN: 1

Port ID: gi2
CPU: 3 optional TTYs
CPU: 4 optional TTYs
PROM: disabled
VLAN: 1
```

13.15 LLDP TLV-SELECT VLAN-NAME

Use “**lldp tlv-select vlan-name**” command to add or remove VLAN list for 802.1 VLAN-NAME TLV. The configuration could be shown by “**show lldp**” command.

```
Switch# configure terminal
```

```
Switch(config)# interface {Interface-ID}
```

```
Switch(config-if)# lldp tlv-select vlan-name (add|remove) {VLAN-LIST}
```

Syntax **lldp tlv-select vlan-name (add|remove) *{VLAN-LIST}***

Parameter **add *VLAN-LIST*** Add VLAN list for LLDP 802.1 VLAN-NAME TLV on the specific interface. The configured ports should be member of all the specified VLANs or the VLAN- LIST is not valid.

remove *VLAN-LIST* Remove VLAN list of LLDP 802.1 VLAN-NAME TLV from interface

Mode Port Configuration

This example add VLAN 100 to VLAN-NAME TLV for port gi10.

Switch# configure terminal

Switch(config)# vlan 100

Switch(config-vlan)# exit

Switch(config)# interface g2

Switch(config-if)# switchport trunk allowed vlan add 1,100

Switch(config-if)# lldp tlv-select vlan-name add 100

Switch(config-if)# end

Example

Switch# show lldp interfaces gi1

Switch# show lldp interfaces g2

```
Switch# configure terminal
Switch(config)# interface g1
Switch(config-if)# switchport trunk allowed vlan add 1,100
Switch(config-if)# lldp tlv-select vlan-name add 100
Switch(config-if)#
Switch# show lldp interfaces gi1
State: Enabled
Timer: 100 Seconds
Hold multiplier: 3
Heart delay: 5 Seconds
Tx delay: 2 Seconds
LLDP packet handling: Bridging

Port | State | Optional TLVs | Address
-----+-----+-----+-----
gi1 | RX, TX | FD, SN, SD, SC | 192.168.0.1

Port ID: gi1
MII-3 optional TLVs: MII-3-mac-phy, MII-3-lag, MII-3-max-frame-size
MII-1 optional TLV
PVID: Enabled
VLAN: 1

Switch# show lldp interfaces g2
State: Enabled
Timer: 100 Seconds
Hold multiplier: 3
Heart delay: 5 Seconds
Tx delay: 2 Seconds
LLDP packet handling: Bridging

Port | State | Optional TLVs | Address
-----+-----+-----+-----
gi2 | RX, TX | | 192.168.0.1

Port ID: gi2
MII-3 optional TLVs:
MII-1 optional TLV
PVID: Enabled
VLAN: 1,100
```

13.16 LLDP TX

Use “**lldp tx**” command to enable the LLDP PDU TX ability. The configuration could be shown by “**show lldp**” command. Use the “**no**” form of this command to disable the TX ability.

```
Switch# configure terminal
```

```
Switch(config)# interface {Interface-
```

```
ID} Switch(config-if)# lldp tx
```

```
Switch(config-if)# no lldp tx
```

	lldp tx
Synta	
x	no lldp tx

Mode	Port Configuration
------	--------------------

This example sets port gi1 to enable LLDP TX, port gi2 to disable RX but enable TX, port gi3 to enable RX but disable TX, port gi4 to disable RX and TX.

```
Switch# configure terminal
```

```
Switch(config)# interface g1
```

```
Switch(config-if)# lldp rx
```

```
Switch(config-if)# lldp tx
```

```
Switch(config-if)# interface
```

```
g2 Switch(config-if)# no lldp
```

```
rx Switch(config-if)# lldp tx
```

```
Switch(config-if)# interface
```

```
g3
```

```
Switch(config-if)# lldp rx
```

```
Switch(config-if)# no lldp tx
```

Example

```
Switch(config-if)# interface
```

```
g4 Switch(config-if)# no lldp
```

```
rx Switch(config-if)# no lldp
```

```
tx Switch(config-if)# end
```

```
Switch# show lldp interfaces g 1-4
```

```

Switch# configure terminal
Switch(config)# interface g1
Switch(config-if)# lldp tx
Switch(config-if)# lldp rx
Switch(config-if)# interface g2
Switch(config-if)# no lldp tx
Switch(config-if)# lldp tx
Switch(config-if)# interface g3
Switch(config-if)# lldp rx
Switch(config-if)# no lldp tx
Switch(config-if)# interface g4
Switch(config-if)# no lldp tx
Switch(config-if)# no lldp rx
Switch(config-if)# end
Switch# show lldp interfaces g 1-4

State: Enabled
Timer: 100 Seconds
Hold multiplier: 9
Restart delay: 5 Seconds
Tx delay: 2 Seconds
LLDP packet handling: Bridging

Port | State | Optional TLVs | Address
-----+-----+-----+-----
g1 | RX, TX | PD, SN, SD, SC | 192.168.0.1
g2 | TX | | 192.168.0.1
g3 | RX | PD, SN, SD, SC | 192.168.0.1
g4 | Disable | | 192.168.0.1

Port ID: g1
802.3 optional TLVs: 802.3-mac-phy, 802.3-lag, 802.3-max-frame-size
802.1 optional TLVs:
PVID: Enabled
VLAN: 1

Port ID: g2
802.3 optional TLVs:
802.1 optional TLVs:
PVID: Enabled
VLAN: 1,100

```

13.17 LLDP TX-DELAY

Use “**lldp tx-delay**” command to configure the delay in seconds between successive LLDP frame transmissions. The delay starts to count in any case LLDP PDU is sent such as by LLDP PDU advertise routine, LLDP PDU content change, port link up, etc. The configuration could be shown by “**show lldp**” command. Use the “**no**” form of this command to restore the delay to default value.

Switch# **configure terminal**

Switch(config)# **lldp tx-delay <1-**

8192> Switch(config)# **no lldp tx-**

delay

lldp tx-delay <1-8192>

Syntax

x **no lldp tx-delay**

Parameter **<1-8192>** Specify the LLDP tx delay in unit of seconds.

Default Default TX delay is 2

seconds Mode Global

Configuration

This example sets LLDP PDU TX delay to 10

seconds. Switch# **configure terminal**

Switch(config)# **lldp tx-delay 1**

Switch# **show lldp**

Example

```
Switch(config)# lldp tx-delay 1
Switch(config)# exit
Switch# show lldp
State: Enabled
Timer: 10 Seconds
Hold Multiplier: 3
Minimum delay: 5 Seconds
TX delay: 1 Seconds
LLDP packet handling: Bridging
Port | State | Optional TLVs | Address
-----|-----|-----|-----
gi1 | EX, TX | FD, SN, SD, SC | 192.168.100.93
gi2 | TX | | 192.168.100.93
gi3 | EX | FD, SR, SD, SC | 192.168.100.93
gi4 | Disable | | 192.168.100.93
gi5 | EX, TX | | 192.168.100.93
gi6 | EX, TX | | 192.168.100.93
gi7 | EX, TX | | 192.168.100.93
gi8 | EX, TX | | 192.168.100.93
gi9 | EX, TX | | 192.168.100.93
gi10 | EX, TX | | 192.168.100.93
gi11 | EX, TX | | 192.168.100.93
```


show lldp local-device

Syntax

x show lldp interfaces *{IF_NMLPORTS}* local-device

Parameter *IF_NMLPORTS* Specify the ports to display information

Mode Privileged EXEC

This example displays the local device information.

Switch# **show lldp local-device**

Example

```
Switch# show lldp local-device
LLDP Local Device Information:
Chassis Type : Mac Address
Chassis ID   : 00:E0:4C:00:00:00
System Name  : Switch
System Description : RT1882M
System Capabilities Support : Bridge, Router
System Capabilities Enable  : Bridge, Router
Management Address : 192.168.100.93 (IPv4)
Management Address : fe80::2e0:4c00:fe00:0 (IPv6)
```

13.20 SHOW LLDP MED

Use “**show lldp med**” command to display the LLDP MED configuration

information. Switch# **show lldp med**

Switch# **show lldp interfaces {IF_NMLPORTS}med**

show lldp med

Syntax

x **show lldp interfaces {IF_NMLPORTS}med**

Parameter *IF_NMLPORTS* Specify the ports to display information

Mode Privileged EXEC

This example displays the LLDP MED

information. Switch# **show lldp med**

Example

```
Switch# show lldp med
Fast Start Repeat Count: 10
-----
Network policy 1
-----
Application type: Voice Signaling
VLAN ID: 2 tagged
Layer 2 priority: 3
DSCP: 4
-----
Network policy 32
-----
Application type: Conferencing
VLAN ID: 8 tagged
Layer 2 priority: 3
DSCP: 43
-----
Port | Capabilities | Network Policy | Location | Inventory | R/E M/E
-----
g13 | Yes | Yes | Yes | Yes | N/A
g12 | No | No | No | No | N/A
g13 | Yes | Yes | No | No | N/A
g14 | Yes | Yes | No | No | N/A
g15 | Yes | Yes | No | No | N/A
g16 | Yes | Yes | No | No | N/A
g17 | Yes | Yes | No | No | N/A
-----
```

13.21 SHOW LLDP NEIGHBOR

Use “**show lldp neighbor**” command to display the received neighbor LLDP PDU information. When LLDP PDU is received on LLDP RX enable ports, system would store the PDU information in database until time to live of the PDU counts down to zero.

```
Switch# show lldp neighbor
```

```
Switch# show lldp interfaces {IF_NMLPORTS} neighbor
```

```
show lldp neighbor
```

Syntax

```
x show lldp interfaces {IF_NMLPORTS} neighbor
```

Parameter *IF_NMLPORTS* Specify the ports to display information

Mode Privileged EXEC

This example displays the neighbor

Example information. Switch# **show lldp neighbor**



Port	Device ID	Port ID	System	Capability	TTL
Gi0/24	192.168.1.2	24	S24	FP	37
Gi0/24	192.168.1.2	24	S24	FP	37

13.23 SHOW LLDP STATISTICS

Use “**show lldp statistics**” command to display the LLDP RX/TX statistics.

Switch# **show lldp statistics**

Switch# **show lldp interfaces {IF_NMLPORTS}statistics**

show lldp statistics

Syntax

x **show lldp interfaces {IF_NMLPORTS}statistics**

Parameter *IF_NMLPORTS* Specify the ports to display information

Mode Privileged EXEC

This example display the LLDP

statistics. Switch# **show lldp statistics**

Example

```
Switch# show lldp statistics
LLDP Port Statistics:
Port | RX Frames | TX Frames | RX Errors | TX Errors | RX Discards | TX Discards | Total
-----|-----|-----|-----|-----|-----|-----|-----
Gi1/0/1 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/2 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/3 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/4 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/5 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/6 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/7 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/8 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/9 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/10 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/11 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/12 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/13 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/14 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/15 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/16 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/17 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/18 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/19 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/20 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/21 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/22 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/23 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Gi1/0/24 | 0 | 0 | 0 | 0 | 0 | 0 | 0
```

Switch(config)# **show lldp interfaces gi1 statistics**

```
Switch# show lldp interfaces gi1 statistics
LLDP Port Statistics:
Port | RX Frames | TX Frames | RX Errors | TX Errors | RX Discards | TX Discards | Total
-----|-----|-----|-----|-----|-----|-----|-----
Gi1/0/1 | 0 | 0 | 0 | 0 | 0 | 0 | 0
```

13.24 CLEAR LLDP STATISTICS

Use “**clear lldp globle statistics**” command to clear the LLDP RX/TX

statistics. Switch# **clear lldp globle statistics**

Syntax **clear lldp globle statistics**

Mode Privileged EXEC

This example shows how to clear LLDP statistics.

Examp

e Switch# **clear lldp statistics**

13.25 SHOW LLDP TLV-OVERLOADING

The LLDP PDU is composed by TLVs and selected number TLVs may compose a large PDU that the system cannot handle. The maximum PDU length is to take the smaller number of jumbo frame size minus 30 bytes (30 bytes kept for header) or 1488 bytes. Use “**show lldptlv-overloading**” command to display the length of LLDP TLVs and if the TLVs overload the PDU length. The TLVs with status marked “**overload**” would not be transmitted.

Switch# **show lldp interfaces {IF_NMLPORTS} tlv-**

overloading Syntax show lldp

interfaces {IF_NMLPORTS} tlv-overloading

Parameter *IF_NMLPORTS* Specify the ports to display

information Mode Privileged EXEC

This example display the LLDP TLVs overloading status of port gi1.

Switch# **show lldp interfaces gi1 tlv-overloading**

Example

```
Switch# show lldp interfaces gi1 tlv-overloading
gi1:
-----+-----+-----+-----+
TLV Group | Bytes | Status
-----+-----+-----+-----+
Mandatory | 21 | Transmitted
LLDP-MED Capabilities | 9 | Transmitted
LLDP-MED Location | 33 | Transmitted
LLDP-MED Network Policies | 30 | Transmitted
802.3 | 30 | Transmitted
Optional | 40 | Transmitted
LLDP-MED Inventory | 74 | Transmitted
802.1 | 25 | Transmitted
-----+-----+-----+-----+
Total: 272 bytes
Left: 1216 bytes
```

LOGGING

Almost all information technology systems generate a log, which serves as a record of all the activity that the system conducted in its operation. Such logs are generated by network infrastructure devices (firewalls, switches, domain name service devices, routers, load balancers), computer platforms (servers, appliances, and smartphones), operating systems (Windows, Linux, iOS) and applications (client/server, web applications, cloud-based utilities).

In an application, a network log is typically a file that contains a record of events that occurred in the application. It contains the record of user and process access calls to objects, attempts at authentication, and other activity. Generally, an event is categorized as an error, a warning, or an informational activity. The specific format and data that are in a log are typically determined by the application designer, to meet various application requirements, and then implemented by the application developer.

14.1 CLEAR LOGGING

To clear the log messages from the internal logging buffer and flash, use command “**clear logging**”

in the Privileged EXEC mode.

Switch# **clear logging**

Syntax **clear logging**

buffered Clear the log messages stored in the RAM.

Parameter

file Clear the log messages stored in the Flash.

Mode Privileged EXEC

The following example clear the log messages stored in RAM and Flash.

Example

Switch# **clear logging buffered**

Switch# **clear logging file**

14.2 LOGGING

To enable logging service on the switch, use the command logging in the Global Configuration mode. Otherwise, use the no form of the command to disable the logging service on the switch. The status of global logging server is available from the command show logging in the Privileged EXEC mode. When the logging service is enabled, logging on and off at each destination rule can be individually configured by the command logging console, logging buffered, logging file, and logging host in the Global Configuration mode. If the logging service is disabled, no messages will be sent to these destinations.

```
Switch#configure terminal
```

```
Switch(config)# logging
```

```
Switch(config)# no logging
```

logging

Syntax

x **no logging**

Default Logging service is

enabled Mode Global

Configuration

The following example disables and enables the logging service on the switch.

```
Switch#configure terminal
```

```
Switch(config)# no logging
```

Example

```
Switch(config)# logging
```



14.3 LOGGING HOST

To define the logging server, use the command `logging host` to add the remote logging server in the Global Configuration mode. Otherwise, use the command `no logging host` to remove the remote logging rules. For the host name configuration, logging service would try translating the host name to IP address directly. Add the logging host would be failed on the failure of host name translating.

Switch# **configure terminal**

Switch(config)# **logging host (ip-addr|hostname) [facility facility] [port port] [severity sev]**

Switch(config)# **no logging host (ip-addr|hostname)**

Syntax
x **logging host (ip-addr|hostname) [facility facility] [port port] [severity sev] no logging host (ip-addr|hostname)**

ipv4-addr IPv4 address of the remote logging server.

hostname Hostname of the remote logging server.

facility facility Specify the facility of the logging messages. It can be on of the following value: local0, local1, local2, local3, local4, local5, local6, and local7. The default value of facility is local7.

Parameter **port** port Specify the port number of the remote logging server. The valid range is from 0 to 65535, and the default value is 512.

severity sev Specify the minimum severity of the logging messages. The valid range is from 0 to 7, and the number 0 to 7 represents emerg, alert, critical, error, warning, notice, info, and debug individually. The default value of minimum severity level is 5 (emerg, alert, crit, error, warning, notice)


Mode Global Configuration

Example

The following example adds the remote logging rules by IP and

Hostname. Switch# **configure terminal**

Switch(config)# **logging host 192.168.0.20**



```
Switch# configure terminal
Switch(config)# logging host 192.168.0.20
Switch(config)#
```

14.4 LOGGING SEVERITY

To set the minimum severity for the messages that are logged to RAM, console, or Flash, use the command logging severity in the Global Configuration mode. Use the “no” form of the command to remove the mechanism of logging to RAM, console, or Flash individually.

```
Switch# configure terminal
```

```
Switch(config)# logging (buffered|console|file) [severity sev]
```

```
Switch(config)# no logging (buffered|console|file)
```

```
logging (buffered|console|file) [severity sev]
```

Synta

```
x no logging (buffered|console|file)
```

buffered Log messages to RAM.

console Log messages to console

buffer. **file** Log messages to Flash.

Parameter **severity** sev Specify the minimum severity of the logging messages.

er

The valid range is from 0 to 7, and the number 0 to 7 represents emergency, alert, critical, error, warning, notice, info, and debug individually. The default minimum severity of the logging severity configuration is 5

(emerg, alert, crit, error, warning, notice).

Default Logging to buffered and console is enabled, and the default minimum severity level is 5 (emerg, alert, crit, error, warning, notice).


Mode Global Configuration

Example

The following example sets the minimum severity level of logging to RAM and Flash as debugging.

Switch# configure terminal

Switch(config)# logging buffered severity 2



14.5 SHOW LOGGING

To display the global logging configuration, and the logging messages stored in the RAM and Flash, use the command `show logging` in the Privileged EXEC mode.

Switch# `show logging [buffered|file]`

Syntax `show logging [buffered|file]`

Buffered Display the log messages stored in the RAM.
File Display the log messages stored in the Flash.

Mode Privileged EXEC

The following example shows the global logging configuration.

Switch# `show logging`

Example

```
Switch# show logging
Logging service is enabled
Aggregation: enabled
Aggregation expiry timer: 300 sec
Console logging: level notice
Buffer logging: level crit
File logging: disabled
Logging server: 1.1.1.4, port 524, level notice, facility local?
Logging server: 10.100.100.10, port 524, level notice, facility local?
Buffer logging
-----
Mon 10 2018 17:51:30: AAA-3-COMMIT: New temp connection for user admin, source 10.148.101.49 ACCEPTED
```

Switch# `show logging buffered`

```
Switch# show logging buffered
Logging service is enabled
Aggregation: enabled
Aggregation expiry timer: 300 sec
Console logging: level notice
Buffer logging: level crit
File logging: disabled
Logging server: 1.1.1.4, port 524, level notice, facility local?
Logging server: 10.100.100.10, port 524, level notice, facility local?
Buffer logging
-----
Mon 10 2018 17:51:30: AAA-3-COMMIT: New temp connection for user admin, source 10.148.101.49 ACCEPTED
```

MAC ADDRESS TABLE

A MAC address table, sometimes called a Content Addressable Memory (CAM) table, is used on Ethernet switches to determine where to forward traffic on a LAN. Now let's break this down a little bit to understand how the MAC address table is built and used by an Ethernet switch to help traffic move along the path to its destination.




Fig 15.1 MAC Address Table

Normally your switch will automatically learn MAC addresses and fill its MAC address table (CAM table) by looking at the source MAC address of incoming frames and flooding frames if it doesn't know where to forward the frame.

```
Switch# sh mac address-table
VID | MAC Address | Type | Ports
-----|-----|-----|-----
1 | 00:00:4C:00:00:00 | Management | CPU
1 | 8C:02:FA:02:00:3E | Dynamic | lag1
1 | E0:00:58:32:0A:92 | Dynamic | lag1
Total number of entries: 3
```

15.1 CLEAR MAC ADDRESS-TABLE

To clear the dynamic (learned) MAC entries from the MAC address table, the specific interface, or the specific VLAN, use the command `clear mac address-table` in the Privileged EXEC mode.

Switch# `clear mac address-table dynamic [interfaces IF_PORTS] vlan vlan-id]`

Syntax `clear mac address-table dynamic [interfaces IF_PORTS]vlan vlan-id]`

Interfaces IF_PORTS Delete all dynamic addresses learned on the specific interface.

vlan vlan-id Delete all source addresses learned on the specific

VLAN Mode Privileged EXEC

The following example clears the learned MAC addresses on the interface

gi1. Switch# `clear mac address-table dynamic interfaces gi1`

Example

```
Switch# show mac address-table
VLO | MAC Address | Type | Ports
-----|-----|-----|-----
1 | 00:ED:4C:00:00:00 | Management | CPU
1 | 0C:02:FA:02:00:0E | Dynamic | la0/1
1 | E0:05:18:32:81:92 | Dynamic | la0/1

Total number of entries: 3
Switch#
Switch# clear mac address-table dynamic interfaces gi1
Switch# show mac address-table
VLO | MAC Address | Type | Ports
-----|-----|-----|-----
1 | 00:ED:4C:00:00:00 | Management | CPU
1 | E0:05:18:32:81:92 | Dynamic | la0/1

Total number of entries: 2
```

15.2 MAC ADDRESS-TABLE AGING-TIME

To set the aging time of the MAC address table, use the command `macAddress-table aging-time` in the Global Configuration mode.

Switch# **configure terminal**

Switch(config)# **mac address-table aging-time**

{seconds} Syntax **mac address-table aging-time**

seconds

Parameter Seconds The time in seconds that an entry remains in the MAC address table. Its valid range is from 10 to 630 seconds, and the default value is 300 seconds.

Default The default aging time is 300

seconds. Mode Global Configuration

The following example set the aging time to 500

seconds. Switch# **configure terminal**

Example Switch(config)# **mac address-table aging-time 500**

e

Switch# **show mac address-table aging-time**

```
Switch(config)# mac address-table aging-time 500
Switch(config)# exit
Switch# show mac address-table aging-time
Mac Address Table aging time: 500 sec
```

15.3 MAC ADDRESS-TABLE STATIC

To add a static address to the MAC address table, use the command `mac address-table static` in the Global Configuration mode. For the unicast MAC address filtering, use the command `mac address-table static` with parameter `drop` to drop the packets with the specified source or destination unicast MAC address. To delete the static entry from the MAC address table, use the “no” form of the command.

```
Switch# configure terminal
```

```
Switch(config)# mac address-table static mac-addr vlan vlan-id interfaces {IF_PORTS}
```

```
Switch(config)# mac address-table static mac-addr vlan vlan-id drop
```

```
Switch(config)# no mac address-table static mac-addr vlan vlan-id
```

```
mac address-table static mac-addr vlan {vlan-id} interfaces {IF_PORTS}
```

Syntax `mac address-table static mac-addr vlan {vlan-id}`

x

```
drop no mac address-table static mac-addr vlan
```

```
vlan-id
```

mac-addr MAC address.

vlan vlan-id Specify the VLAN ID for the interface.

Parameter **Interface IF_PORTS** Specify the interface ID or a list of interface IDs.

drop Drop the packets with the specified source or destination unicast MAC address.

Mode Global Configuration

The following example adds a static address into MAC address table.

```
Switch#configure terminal
```

```
Switch(config)# mac address-table static 00:11:22:33:44:55 vlan 1 interfaces gi5
```

Example

e

```
Switch(config)# mac address-table static 00:11:22:33:44:55 vlan 1 drop
```

```
Switch# configure terminal
Switch(config)# mac address-table static 0011:22:33:44:55 vlan 1 interface g1/5
Switch(config)# mac address-table static 0011:22:33:44:55 vlan 1 drop
mac entry exists in static table
Switch(config)#
Switch# show mac address-table static vlan 1
VLAN | MAC Address | Type | Ports
-----|-----|-----|-----
1 | 0011:22:33:44:55 | Static | g1/5
Total number of entries: 1
Switch#
```

15.4 SHOW MAC ADDRESS-TABLE

To show the entry in the MAC address table, use the command `show macaddress-table` in the Privileged EXEC mode.

```
Switch# show mac address-table [dynamic|static] [interface IF_PORTS] [vlan vlan-id]
```

```
Switch# show mac address-table [mac-addr] [vlan vlan-id]
```

Syntax
X `show mac address-table [dynamic|static] [interface IF_PORTS] [vlan vlan-id]`

X `show mac address-table [mac-addr] [vlan vlan-id]`

dynamic Display only dynamic MAC addresses

static Display only static MAC addresses

Parameter **Interface *IF_PORTS*** Display the MAC addresses entries for a specific interface.

vlan *vlan-id* Display the MAC address entries for a specific VLAN.

mac-addr Display entries for a specific MAC

address Mode Privileged EXEC

The following example displays the entire MAC address

table. Switch# `show mac address-table`

```
Switch# show mac address-table
Vlan MAC Address      Type      Ports
---  ---
1 | 00:00:00:00:00:00 | Management | CPU
1 | 00:00:00:00:00:00 | Dynamic   | gi1/1
1 | 00:11:22:33:44:55 | Static   | gi1
1 | 00:15:00:00:00:00 | Dynamic   | gi1/2
1 | 00:25:00:00:00:00 | Dynamic   | gi1/3
1 | 3C:15:00:00:00:00 | Dynamic   | gi1/4
1 | 28:78:27:00:00:00 | Dynamic   | gi1/5
1 | 3C:87:8A:17:88:00 | Dynamic   | gi1/6
1 | 48:00:00:00:00:00 | Dynamic   | gi1/7
1 | 40:00:00:00:00:00 | Dynamic   | gi1/8
1 | 44:01:00:00:00:00 | Dynamic   | gi1/9
1 | 44:01:00:00:00:00 | Dynamic   | gi1/10
1 | 44:01:00:00:00:00 | Dynamic   | gi1/11
1 | 44:01:00:00:00:00 | Dynamic   | gi1/12
1 | 44:01:00:00:00:00 | Dynamic   | gi1/13
1 | 48:88:CA:68:08:79 | Dynamic   | gi1/14
1 | 00:00:00:00:00:00 | Dynamic   | gi1/15
1 | 70:14:00:00:00:00 | Dynamic   | gi1/16
1 | 88:11:00:00:00:00 | Dynamic   | gi1/17
1 | 00:20:00:00:00:00 | Dynamic   | gi1/18
1 | 00:09:CF:79:28:A1 | Dynamic   | gi1/19
```

Example

e Switch# `show mac address-table static interfaces gi1`

```
Switch# show mac address-table static interfaces gi1
Vlan MAC Address      Type      Ports
---  ---
1 | 00:11:22:33:44:55 | Static   | gi1
Total number of entries: 1
```

Switch# `show mac address-table 00:11:22:33:44:55 vlan 100`

```
Switch# show mac address-table 00:11:22:33:44:55 VLAN 100
VID | MAC Address | Type | Port
-----|-----|-----|-----
Total number of entries: 0
```

15.5 SHOW MAC ADDRESS-TABLE COUNTERS

To display the total entries in the MAC address table, use the command `show mac address-table counters` in the Privileged EXEC mode.

```
Switch# show mac address-table
```

counters Syntax `show mac address-`

table counters Mode Privileged EXEC

The following example display numbers of addresses in the address table.

Example

```
Switch# show mac address-table counters
```

```
Switch# show mac address-table counters  
Total number of entries: 39
```

15.6 SHOW MAC ADDRESS-TABLE AGING-TIME

To show MAC address aging time, use the command `show mac address-table aging-time` in the Privileged EXEC mode.

Switch# **show mac address-table aging-**

time Syntax **show mac address-table**

aging-time Mode Privileged EXEC

The following example displays aging time for the MAC address table.

Example
Switch# **show mac address-table aging-time**

```
Switch# show mac address-table aging-time  
Mac Address Table aging time: 900 sec
```

MAC VLAN

MAC VLAN :-The **MAC**-based **VLAN** feature allows incoming untagged packets to be assigned to a **VLAN** and thus classify traffic based on the source **MAC** address of the packet. You define a **MAC** to **VLAN** mapping by configuring an entry in the **MAC** to **VLAN** table

16.1 VLAN MAC-VLAN GROUP (GLOBAL)

Use the `vlan mac-vlan group` command to create MAC address group. Use the “no” form of this command to delete specify group.

Switch#**configure terminal**

Switch(config)# **vlan mac-vlan group** <1- 2147483647> **mac-address mask** <9-48>

Switch(config)# **no vlan mac-vlan group mac-address mask** <9-48>

vlan mac-vlan group <1- 2147483647> **mac-address mask** <9-48>

Synta

x **no vlan mac-vlan group mac-address mask** <9-48>

<1-2147483647>Specify the group ID

Parameter**mac-address**Specify the MAC address to be mapped.

<9-48>Specify the mask length of MAC address.

Mode Global Configuration

The following example shows how to create a MAC group with group ID 3.

Switch#**configure terminal**

Switch(config)# **vlan mac-vlan group** 333 22:33:44:55:66:77 mask 48

Examp

e Switch# **show vlan mac-vlan groups**

```
Switch#
Switch#configure terminal
Switch(config)# vlan mac-vlan group 333 22:33:44:55:66:77 mask 48
Switch(config)#
Switch#show vlan mac-vlan groups
  Mac Address      Mask      Group Id
  -----
22:33:44:55:66:77  48        333
Total 1 Entry
```

16.2 VLAN MAC-VLAN GROUP (INTERFACE)

Use the “**vlan mac-vlan group**” to create mapping of group and VLAN ID of an interface. Use the “**no**”

form of this command to delete

mapping. Switch#**configure terminal**

Switch(config)# **interface** {Interface-

ID}

Switch(config-if)# **vlan mac-vlan group** <1- 2147483647> **vlan** <1-4094>

Switch(config-if)# **no vlan mac-vlan** [group <1- 2147483647>]

vlan mac-vlan group <1- 2147483647> **vlan** <1-4094>

Syntax

no vlan mac-vlan [group <1- 2147483647>]

x

Parameter

<1-2147483647> Specify the group ID. (optional in no form) Delete all mapping group if not specify.

<1-4094> Specify the VLAN ID to give to match packet

Mode

Interface Configuration

The following example shows how to mapping group id 333 to VLAN 100 on interface GigabitEthernet 1.

Switch#

Switch# **configure terminal**

Switch(config)# **interface** GigabitEthernet 3

Switch(config-if)# **switchport mode hybrid**

Example

Switch(config-if)# **vlan mac-vlan group** 333

vlan 2 Switch(config-if)#

Switch#

show vlan mac-vlan groups

```
Switch# configure terminal
Switch(config)# interface GigabitEthernet 3
Switch(config-if)# switchport mode hybrid
Switch(config-if)# vlan mac-vlan group 333 vlan 2
Switch(config-if)#
Switch# show vlan mac-vlan groups

```

MAC Address	Mask	Group ID
22:33:44:55:66:77	48	333

```
Total: 1 Entry
```

Image not found or type unknown

Image not found or type unknown

16.3 SHOW VLAN MAC-VLAN GROUPS

Use the show vlan mac-vlan groups command to display mac groups configuration. Switch# **show vlan mac-vlan groups**

Syntax **show vlan mac-vlan groups**

Mode Privileged EXEC

This following example shows how to display mac group.

Example Switch# **show vlan mac-vlan groups**

```
Switch# show vlan mac-vlan groups
-----
Mac Address      Mask      Group Id
-----
02:00:0c:00:00:00  40        932
-----
Switch#
```

16.4 SHOW VLAN MAC-VLAN INTERFACES

Use the show vlan mac-vlan interface command in EXEC mode to display the mac-vlan interfaces setting. Switch# **show vlan mac-vlan [interfaces *IF_PORTS*]**

Syntax **show vlan mac-vlan [interfaces *IF_PORTS*]**

Parameter *IF_PORTS*(Optional) Specify interfaces mac vlan to display. Display all ports if not

specif. Mode Privileged EXEC

The following example shows how to display the MAC-Based VLAN interfaces

Example setting Switch# **show vlan mac-vlan interfaces GigabitEthernet 1**
e

```
Switch# show vlan mac-vlan interfaces GigabitEthernet 1
Interface g11 Mac based VLANs:
Group ID   Vlan ID
-----

```

MANAGEMENT ACL

An Access Control List (ACL) is a set of rules that is usually used to filter network traffic. ACLs can be configured on network devices with packet filtering compatibilities, such as routers and firewalls.

ACLs contain a list of conditions that categorize packets and help you determine when to allow or deny network traffic. They are applied on the interface basis to packets leaving or entering an interface

Access-list (ACL) is a set of rules defined for controlling the network traffic and reducing network attack. ACLs are used to filter traffic based on the set of rules defined for the incoming or outgoing of the network.

ACL features –

- The set of rules defined are matched serial wise i.e matching starts with the first line, then 2nd, then 3rd and so on.
- The packets are matched only until it matches the rule. Once a rule is matched then no further comparison takes place and that rule will be performed.
- There is an implicit deny at the end of every ACL, i.e., if no condition or rule matches then the packet will be discarded.

Once the access-list is built, then it should be applied to inbound or outbound of the interface:




Fig 17.1 ACL Feature

Also there are two categories of access list,

- Numbered access list – These are the access list which cannot be deleted specifically once created i.e. if we want to remove any rule from an Access-list then this is not permitted in the case of numbered access list. If we try to delete a rule from access list then the whole access list

will be deleted. The numbered access list can be used with both standard and extended access list.

- Named access list – In this type of access list, a name is assigned to identify an access list. It is allowed to delete a named access list unlike numbered access list. Like numbered access list, these can be used with both standard and extended access list.

Rules for ACL –

- The standard Access-list is generally applied close to the destination (but not always).
- The extended Access-list is generally applied close to the source (but not always).
- We can assign only one ACL per interface per protocol per direction, i.e., only one inbound and outbound ACL is permitted per interface.
- We can't remove a rule from an Access-list if we are using numbered Access-list. If we try to remove a

rule then whole ACL will be removed. If we are using named access lists then we can delete a specific rule.

- Every new rule which is added into the access list will be placed at the bottom of the access list therefore before implementing the access lists, analyses the whole scenario carefully.
- As there is an implicit deny at the end of every access list, we should have at least a permit statement in our Access-list otherwise all traffic will be denied.
- Standard access lists and extended access lists cannot have the same name.

Advantages of ACL –

- Improve network performance.
- Provides security as administrator can configure the access list according to the needs and deny the unwanted packets from entering the network.
- Provides control over the traffic as it can permit or deny according to the need of network.

17.1 MANAGEMENT ACCESS-LIST

Use the management access-list command to create a management access list and to enter management access-list configuration mode. The name of ACL must be unique that cannot have same name with other management ACL. Use the “no” form of this command to delete.

```
Switch#configure terminal
```

```
Switch(config)# management access-list [NAME]
```

```
Switch(config)#no management access-list [NAME]
```

```
management access-list NAME
Synta
x      no management access-list NAME
```

ParameterNAME The name of management

ACL Mode Global Configuration

The following example shows how to add a management ACL with name “test”

```
Switch#configure terminal
Examp
e      Switch(config)# management access-list test
```

```
Switch(config)# management access-list test
Switch(config-mgmt)# end
Switch# show management access-list test

test
-----
 (Note: all other access implicitly denied)
```

17.2 MANAGEMENT ACCESS-CLASS

Use the management access-class command to activate a management ACL. Use the “no” form of this command to delete.

Switch#**configure terminal**

Switch(config)# **management access-class** *[NAME]*

Switch(config)# **no management access-class**

management access-class *[NAME]*

Syntax

x **no management access-class**

ParameterNAME The name of management ACL to

be used Mode Global Configuration

The following example shows how to add a management ACL with name “test”

Example Switch#**configure terminal**

Switch(config)# **management access-class test**

```
Switch# configure terminal
Switch(config)# management access-list test
ip 1.1.1.1/255.255.255.255 interfaces 0/2 service all
```

17.3 DENY

Use the deny command to add deny rules that drop those packets hit the

rule. Switch#**configure terminal**

```
Switch(config)# management access-list [NAME]
```

```
Switch(config-macl)# sequence <1-65535> deny interfaces {IF_PORTS}service  
(all|http|https|snmp|ssh|telnet)
```

```
Switch(config-macl)#[sequence <1-65535> deny ip A.B.C.D/A.B.C.D interfaces {IF_PORTS}  
service (all|http|https|snmp|ssh|telnet)
```

```
Switch(config-macl)# [sequence <1-65535> deny ipv6 X:X::X:X/<0-128> interfaces  
{IF_PORTS}  
service (all|http|https|snmp|ssh|telnet)
```

```
[sequence <1-65535> deny interfaces {IF_PORTS}service
```

```
(all|http|https|snmp|ssh|telnet) [sequence <1-65535> deny ip A.B.C.D/A.B.C.D
```

Syntax **interfaces** *{IF_PORTS}*

x

```
service (all|http|https|snmp|ssh|telnet)
```

```
[sequence <1-65535> deny ipv6 X:X::X:X/<0-128> interfaces {IF_PORTS}
```

```
service (all|http|https|snmp|ssh|telnet)
```

<1-65535> (Optional) Specify sequence index of ACL entry, the sequence index represent the priority of an entry in ACL. If not specified, the switch assigns a number from 1 in ascending order.

interfaces IF_PORTS Specify the interface ID or a list of interface IDs.

Parameter

ipA.B.C.D/A.B.C.DSpecify the source IP address and mask of packet.

ipv6 X:X::X:X/*<0-128>* Specify the source IPv6 address and prefix length of packet.

(all|http|https|snmp|ssh|telnet) Specify the type of services

Mode Management Access-List Configuration

The following example shows how to add a deny rule to drop all types of services packets that source ip is 1.1.1.1 from interface gi2.

Switch#**configure terminal**

Switch(config)# **management access-list** commando

Examp
le

Switch(config-macl)#**sequence1 deny ip 10.10.10.10/255.255.255.255 interfaces gi2 service all**

```
Switch# configure terminal
Switch(config)# management access-list commando
Switch(config-macl)# sequence1 deny ip 10.10.10.10/255.255.255.255 interfaces gi2 service all
```

Switch# sh management access-list commando

```
Switch# sh management access-list commando
-----
sequence 1 deny ip 10.10.10.10/255.255.255.255 interfaces gi2 service all
*Note: all other access configurations deleted
```

17.4 PERMIT

Use the permit command to add permit rules that bypass those packets

hit the rule. Switch#configure terminal

```
Switch(config)# management access-list [NAME]
```

```
Switch(config-macl)# sequence <1-65535>] permit interfaces {IF_PORTS}  
service(all|http|https|snmp|ssh|telnet)
```

```
Switch(config-macl)# [sequence <1-65535>] permit ip A.B.C.D/A.B.C.D interfaces  
{IF_PORTS}  
service (all|http|https|snmp|ssh|telnet)
```

```
Switch(config-macl)# [sequence <1-65535>] permit ipv6 X:X::X:X/<0-128> interfaces  
{IF_PORTS}  
service (all|http|https|snmp|ssh|telnet)
```

```
[sequence <1-65535>] permit interfaces {IF_PORTS} service
```

```
(all|http|https|snmp|ssh|telnet)
```

Syntax
x [**sequence** <1-65535>] **permit** **ip** A.B.C.D/A.B.C.D **interfaces** *{IF_PORTS}*
service (all|http|https|snmp|ssh|telnet)

```
[sequence <1-65535>] permit ipv6 X:X::X:X/<0-128> interfaces
```

```
{IF_PORTS} service (all|http|https|snmp|ssh|telnet)
```

<1-65535> (Optional) Specify sequence index of ACL entry, the sequence index represent the priority of an entry in ACL. If not specified, the switch assigns a number from 1 in ascending order.

interfaces *IF_PORTS* Specify the interface ID or a list of interface IDs.

Parameter **ip** A.B.C.D/A.B.C.D Specify the source IP address and mask of packet.

ipv6 X:X::X:X/<0-128> Specify the source IPv6 address and prefix length of

packet. (**all|http|https|snmp|ssh|telnet**) Specify the type of services

Mode Management Access-List Configuration

The following example shows how to add a permit rule to bypass http service packets that source ip is 2.2.2.2 from interface gi2.

```
Switch#configure terminal
```

```
Switch(config)# management access-list test
```

Example

```
Switch(config-macl)# sequence 2 permit ip 2.2.2.2/255.255.255.255 interfaces gi2  
service http
```

```
Switch(config)#configure terminal  
Switch(config)# management access-list test  
Switch(config-macl)# sequence 2 permit ip 2.2.2.2/255.255.255.255 interfaces gi2 service http
```

```
Switch# management access-list test  
test  
sequence 1 deny ip 1.1.1.1/255.255.255.255 interface gi2 service All  
sequence 2 permit ip 2.2.2.2/255.255.255.255 interface gi2 service http
```

17.5 NO SEQUENCE

Use the “no” sequence command to delete an entry in management ACL.

```
Switch#configure terminal
```

```
Switch(config)# management access-list [NAME]
```

```
Switch(config-macl)# no sequence <1-65535>
```

Syntax **no sequence** <1-65535>

Parameter <1-65535>Specify sequence index of ACL entry to

delete. Mode Management Access-List Configuration

The following example shows how to delete an

entry. Switch#configure terminal

```
Switch(config)# management access-list test
```

Example
e Switch(config-macl)# sequence 10 deny interfaces gi1
service all

```
Switch#
Switch#configure terminal
Switch(config)# management access-list test
Switch(config-macl)# sequence 10 deny interfaces gi1 service all
Switch(config-macl)#
Switch# management access-list test
Switch#
Switch#
Switch# deny ip 1.1.1.1/255.255.255.255 interfaces gi1 service all
Switch# permit ip 2.2.2.2/255.255.255.255 interfaces gi1 service deny
Switch# deny interfaces gi1 service all
Switch# all other access implicitly permit
```

17.6 SHOW MANAGEMENT ACCESS-CLASS

Use the show management access-class command to show the active management access-list. Switch# **show management access-class**

Syntax **show management access-class**

Mode Privileged EXEC

The example shows how to show management

```
Switch0001#  
Switch0# show management access-class  
Management access-class is enabled, using access-list test
```

access-class ExampleSwitch# **show management access-class**

17.7 SHOW MANAGEMENT ACCESS-LIST

Use the show management access-list command to show management

ACL. Switch# **show management access-list** *[NAME]*

Syntax **show management access-list** *[NAME]*

Parameter *NAME* Specify the name of management ACL to displayed

Mode Privileged EXEC

The example shows how to show management

access-list Switch# **show management access-list 1**

Example

```
Switch# show management access-list test
test
-----
deny ip 1.1.1.1/255.255.255.255 interfaces g1/ service http
deny ip any interfaces g1/ service all
! (Note: All other access implicitly denied)
list does not exist
Switch#
```

MIRROR

You can analyze network traffic passing through ports by using Switched Port Analyzer (SPAN). This sends a copy of the traffic to another port on the switch that has been connected to a SwitchProbe device, another Remote Monitoring (RMON) probe or security device. SPAN mirrors receive or transmit (or both) traffic on one or more source ports to a destination port for analysis.

Remote SPAN (RSPAN) extends SPAN by enabling RMON of multiple switches across your network. The traffic for each RSPAN session is carried over a user-specified RSPAN VLAN that is dedicated for that RSPAN session in all participating switches. The SPAN traffic from the sources is copied onto the RSPAN VLAN through a reflector port and then forwarded over trunk ports carrying the RSPAN VLAN to any RSPAN destination session monitoring the RSPAN VLAN.

SPAN and RSPAN do not affect the switching of network traffic on source ports. A copy of the packets received or sent by the source interfaces are sent to the destination interface. Except for traffic that is required for the SPAN or RSPAN session, reflector ports and destination ports do not receive or forward traffic.




Fig 18.1 Mirror and Analyzer Port

18.1 MIRROR SESSION DESTINATION INTERFACE

Use the “**mirror session destination interface**” command to start a destination interface of a port mirror session. Use the “**no**” form of this command to stop a destination interface of a port mirroring session. Use the “**no mirror session**” command to disable all mirror sessions or specific mirror session.

```
Switch#configure terminal
```

```
Switch(config)# mirror session <1-4> destination interface IF_NMLPORT [allow-
```

```
ingress] Switch(config)# no mirror session <1-4> destination interface IF_NMLPORT
```

```
Switch(config)# no mirror session ( <1-4>| all)
```

mirror session <1-4> destination interface IF_NMLPORT [allow-ingress]

Synta
x

no mirror session <1-4> destination interface IF_NMLPORT

no mirror session (<1-4>| all)

<1-4> Specify the mirror session to configure

Parameter

IF_NMLPORT Specify the SPAN destination. A destination must be a physical port
allow- ingress Enable ingress traffic forwarding.

Default

No monitor sessions are configured.

Mode

Global Configuration

The following example shows how to create a local session 1 to monitor both sent and received traffic on source port GigabitEthernet2.

Switch#**configure terminal**

Switch(config)#**mirror session 1 destination interface GigabitEthernet 11 allow-ingress**

```
Switch# configure terminal
Switch(config)# mirror session 1 destination interface GigabitEthernet 11 allow-ingress
```

Example

```
Switch# show mirror session 1
Session 1 Configuration
Mirrored source : Not Config
Destination port : g11
Ingress State: enabled
```

To disable Mirror session

Switch#**configure terminal**

Switch(config)#**no mirror session 1 destination interface GigabitEthernet 11**

Switch(config)# **no mirror session all**

18.2 MIRROR SESSION SOURCE INTERFACE

Use the “**mirror session source interface**” command to start a port mirror session. Use the “**no**” form of this command to stop a port mirroring session. Use the “**no mirror session**” command to disable all mirror sessions or specific mirror session.

Switch#**configure terminal**

Switch(config)# **mirror session <1-4> source interfaces IF_PORTS (both | rx | tx)**

Switch(config)# **no mirror session <1-4>source interfaces IF_PORTS (both | rx | tx)**

Switch(config)# **no mirror session (<1-4>| all)**

mirror session <1-4> source interfaces IF_PORTS (both | rx | tx)

Syntax
x
no mirror session <1-4>source interfaces IF_PORTS (both | rx | tx) no mirror session (<1-4>| all)

<1-4> Specify the mirror session to configure

IF_PORTS Specify the source interface, Valid interfaces include physical ports and port channels.

Parameter

both Mirror tx and rx

direction rx Mirror rx

direction only

tx Mirror tx direction only

Mode

Global Configuration

Example

The following example shows how to create a local

SPAN session 1 to monitor both sent and received rate on source port gi3-5.

```
Switch#configure terminal
```

```
Switch(config)# mirror session 1 source interfaces GigabitEthernet 3-5 both
```

```
Switch(config)# mirror session 1 destination interface GigabitEthernet 2
```

```
Switch# show mirror session 1
```

```
Switch(config)# mirror session 1 source interface GigabitEthernet 3-5 both
Switch(config)# mirror session 1 destination interface GigabitEthernet 2
Switch(config)# exit
Switch# show mirror session 1

Session 1 Configuration
Source RX Port : gi3-5
Source TX Port : gi3-5
Destination port : gi2
Mirror State: disabled
```

18.3 SHOW MIRROR

Use the show mirror command to display mirror session configuration.

Switch#show mirror [session <1-4>]

Syntax show mirror [session <1-4>]

Parameter <1-4>Specify the mirror session to

display Mode Privileged EXEC

This following example shows how to display mirror session configuration

Switch# show mirror

Example

```
Switch# show mirror
Session 1 Configuration
Source RX Port : gi3-5
Source TX Port : gi3-5
Destination port : gi2
Egress State: disabled

Session 2 Configuration
Mirrored source : Not Config
Destination port : Not Config

Session 3 Configuration
Mirrored source : Not Config
Destination port : Not Config

Session 4 Configuration
Mirrored source : Not Config
Destination port : Not Config
```

MLD SNOOPING

Syntax
x `ipv6 mld filter <1-128>`
 `no ipv6 mld filter`

Parameter
er `<1-128>` specifies profile ID
 `[interfaces IF_PORTS]` Specifies interfaces to display

Mode Port Configuration

The following example specifies that set ipv6 mld filter test.

Example
e `Switch#configure terminal`
 `Switch(config)# interface gi1`
 `Switch(config-if)# ipv6 mld filter`
 `1`

```
Switch# configure terminal
Switch(config)# interface gi1
Switch(config-if)# ipv6 mld filter 1
```

19.23 IPV6 MLD MAX-GROUPS

Use the `ipv6 mld max-groups` command to limit port learning max group number. When the port has reach limitation, new group will not add this port. Static group is excluded. Use the “**no**” form of this command to restore to default. You can verify settings by the `show ipv6 mld max-groups` command.

Switch#**configure terminal**

Switch(config)#**ipv6 mld max-groups <0-1024>**

Switch(config)# **no ipv6 mld max-groups**

ipv6 mld max-groups <0-1024>

Synta

x **no ipv6 mld max-groups**

Parameter *<0-1024>* specifies

profile ID Default Default is 1024

Mode Port Configuration

The following example specifies that set ipv6 mld max-groups test.

Switch#**configure terminal**

Examp
e Switch(config)# **interface gi1**

Switch(config-if)# **ipv6 mld max-groups 10**

```
Switch# configure terminal
Switch(config)# interface gi1
Switch(config-if)# ipv6 mld max-groups 10
```

19.24 IP IGMP MAX-GROUPS ACTION

Use the `ipv6 mld max-groups action` command to set the action when the numbers of groups reach the limitation. Use the “no” form of this command to restore to default. You can verify settings by the `show ipv6 mld max-groups` command.

```
Switch#configure terminal
```

```
Switch(config)# interface {INTERFACE-ID}
```

```
Switch(config-if)#ipv6 mld max-groups action (deny | replace)
```

Syntax `ipv6 mld max-groups action (deny | replace)`

Parameter (deny | replace) Deny: current port igmp group arrived max-groups, don't add group.
Replace: current port igmp group arrived max-groups, remove port for rand group, and add port to new group.

Default Default action is

deny Mode Interface mode

The following example specifies that set action replace test.

```
Switch#configure terminal
```

Example Switch(config)# interface gi1

```
Switch(config-if)#ipv6 mld max-groups action replace
```

```
Switch# configure terminal
Switch(config)# interface gi1
Switch(config-if)# ipv6 mld max-groups action replace
```

19.25 CLEAR IPV6 MLD SNOOPING GROUPS

This command will clear the ipv6 mld groups for dynamic or static or all of type. You can verify settings by the show ipv6 mld snooping groups command.

Switch#**clear ipv6 mld snooping groups [(dynamic | static)]**

Syntax **clear ipv6 mld snooping groups [(dynamic | static)]**

None Clear ipv6 mld groups include dynamic and
Parameter static (dynamic | static) ipv6 mld group type is
dynamic or static

Mode Privileged EXEC

The following example specifies that clear ipv6 mld snooping
Example groups test.
Switch# **clear ipv6 mld snooping groups static**

19.26 CLEAR IPV6 MLD SNOOPING STATISTICS

This command will clear the igmp statistics. You can verify settings by the show ipv6 mld snooping command.

```
Switch#clear ipv6 mld snooping
```

```
statistics Syntaxclear ipv6 mld
```

```
snooping statistics Mode
```

Privileged EXEC

The following example specifies that clear ipv6 mld snooping statistics

Example^{test}.

```
Switch# clear ipv6 mld snooping statistics
```

19.27 SHOW IPV6 MLD SNOOPING GROUPS COUNTERS

This command will display the ipv6 mld group counter include static group. Switch#**show ipv6 mld snooping groups counters**

Syntax **show ipv6 mld snooping groups counters**

Mode Privileged EXEC

The following example specifies that display ipv6 mld snooping group counter test.

ExampleSwitch# **show ipv6 mld snooping group counters**

Total ipv6 mld snooping group number: 1

```
Switch# show ipv6 mld snooping group counters
Total ipv6 mld snooping group number: 1
```

19.28 SHOW IPV6 MLD SNOOPING GROUPS

This command will display the ipv6 mld groups for dynamic or static or all of type.

Switch#**show ipv6 mld snooping groups [(dynamic | static)]**

Syntax **show ipv6 mld snooping groups [(dynamic | static)]**

none Show ipv6 mld groups include dynamic and static

Parameter

(dynamic | static) Display ipv6 mld group type is dynamic or static

Default display all ipv6 mld

groups Mode Privileged EXEC

The following example specifies that show ipv6 mld snooping groups

Example. Switch# **show ipv6 mld snooping groups**

```
Switch# show ipv6 mld snooping groups
-----
Type | Group ID Address | Type | Lifetime | Port
-----
1 | ff03::1:3::1 | Static | 0:0:0:0 | 0:0:0:0:0:0
Total Number of Entry = 1
```

19.29 SHOW IPV6 MLD SNOOPING ROUTER

This command will display the ipv6 mld router info.

Switch#show ipv6 mld snooping router [(dynamic | forbidden |static)]

Syntax show ipv6 mld snooping router [(dynamic | forbidden |static)]

none Show ipv6 mld router include dynamic and static and forbidden

Parameter (dynamic |forbidden | static)Display ipv6 mld router info for different type

Mode Privileged EXEC

The following example specifies that show ipv6 mld snooping router

test. Switch# show ipv6 mld snooping router

Example

```
Switch# show ipv6 mld snooping router
Dynamic Router Table
VFD | Port | Expiry Time(Sec)
-----
Total Entry 0

Static Router Table
VFD | Port Mask
-----
1 | 211.010

Total Entry 1

Forbidden Router Table
VFD | Port Mask
-----
Total Entry 0
```

19.30 SHOW IPV6 MLD SNOOPING

This command will display ipv6 mld snooping global info.

Switch#show ipv6 mld snooping

Syntax show ipv6 mld snooping

Mode Privileged EXEC

The following example specifies that show ipv6 mld snooping test.

Switch# show ipv6 mld snooping

Example
e

```
Switch# show ipv6 mld snooping
-----
MLD Snooping Status
-----
Snooping                : Disabled
Report Suppression      : Enabled
Operation Version        : v1
Forward Method           : mac
Unknown IPv6 Multicast Action : Flood

-----
Packet Statistics
-----
Total RX                 : 0
Valid RX                 : 0
Invalid RX               : 0
Total TX                 : 0
Leave RX                 : 0
Report RX                : 0
General Query RX        : 0
Special Group Query RX  : 0
Special Group & Source Query RX : 0
Leave TX                 : 0
Report TX                : 0
General Query TX        : 0
Special Group Query TX  : 0
Special Group & Source Query TX : 0
```

19.31 SHOW IPV6 MLD SNOOPING VLAN

This command will display ipv6 mld snooping vlan info.

Switch#**show ipv6 mld snooping vlan**

Syntax **show ipv6 mld snooping vlan**

none Show all ipv6 mld snooping vlan
Paramet
er info Show specifies vlan ipv6 mld
snooping info

Default Show all ipv6 mld snooping vlan

info Mode Privileged EXEC

The following example specifies that show ipv6 mld snooping vlan

test. Switch# **show ipv6 mld snooping vlan 1**

Exampl
e

```
Switch# show ipv6 mld snooping vlan 1
IPv6 Snooping is globally disabled
IPv6 Snooping VLAN 1 admin : disabled
IPv6 Snooping oper mode : disabled
IPv6 Snooping robustness: admin 2 oper 2
IPv6 Snooping query interval: admin 125 sec oper 125 sec
IPv6 Snooping query RMR response : admin 10 sec oper 10 sec
IPv6 Snooping last member query counter: admin 2 oper 2
IPv6 Snooping last member query interval: admin 1 sec oper 1 sec
IPv6 Snooping immediate leave: disabled
IPv6 Snooping automatic learning of Multicast router ports: enabled
```

19.32 SHOW IPV6 MLD SNOOPING FORWARD-ALL

This command will display ipv6 mld snooping forward all info.

Switch#**show ipv6 mld snooping forward-all [vlan]**

Syntax **show ipv6 mld snooping forward-all [vlan]**

none Show all ipv6 mld snooping vlan forward-all info
Parameter [vlan] Show specifies vlan of ipv6 mld forward info

Default Show all vlan ipv6 mld forward all

info Mode Privileged EXEC

The following example specifies that show ipv6 mld snooping forward-all test.

Example Switch# **show ipv6 mld snooping forward-all**
e

```
Switch# show ipv6 mld snooping forward-all
MLD Snooping VLAN      : 1
MLD Snooping static port : g13-5
MLD Snooping forbidden port : None
```

19.33 SHOW IPV6 MLD PROFILE

This command will display ipv6 mld profile

info. Switch#**show ipv6 mld profile**[<1-128>]

Syntax **show ipv6 mld profile**[<1-128>]

none Show all ipv6 mld snooping profile
Parameter info [<1-128>] Show specifies index
profile info

Default Show all ipv6 mld profile

info Mode Privileged EXEC

The following example specifies that show ipv6 mld profile test. Switch# **show ipv6 mld profile**
Example

```
Switch# show ipv6 mld profile
IPv6 MLD Profile: none
IPv6 MLD Profile Action: permit
Range low spi: 00000000
Range high spi: 00000000
```

19.34 SHOW IPV6 MLD FILTER

This command will display ipv6 mld port filter info.

Switch#**show ipv6 mld filter** [interfaces *{IF_PORTS}*]

Syntax **show ipv6 mld filter** [interfaces *{IF_PORTS}*]


none Show all port filter

Parameter [interfaces *{IF_PORTS}*] Show specifies ports filter

Mode Privileged EXEC

The following example specifies that show ipv6 mld filter test. Switch# **show ipv6 mld filter**

Example



```
Switch# show ipv6 mld filter
-----
011 1
012 1
013 1
014 1
015 1
016 1
017 1
018 1
019 1
020 1
021 1
022 1
023 1
024 1
025 1
026 1
027 1
028 1
029 1
030 1
031 1
032 1
033 1
034 1
035 1
036 1
037 1
038 1
039 1
040 1
041 1
042 1
043 1
044 1
045 1
046 1
047 1
048 1
049 1
050 1
```


none group action

Show all
port max- [interfaces *{IF_PORTS}*] Show specifies ports max-group action

Default Show all ports ipv6 mld max-group

action Mode Privileged EXEC

Multicast VLAN Registration (MVR)

Syntax
x `mvr vlangroupinterfaces {IF_PORTS}`
`no mvr vlan < VLAN-ID>groupinterfaces {IF_PORTS}`

VLAN-ID specifies MVR VLAN ID for static

Parameter
group *ip-addr* Specifies multicast MVR group
address *IF_PORTS* specifies port list to set or
remove

Mode Global Configuration

The following example specifies that set mvr static group test.

The configure must configure mvr receiver port firstly.(eg. mvr port type)

Example
e `Switch(config)#`
`mvr vlan 2 group 224.1.1.1 interfaces gi2`
`Switch# show mvr members`

```
Switch(config)# mvr vlan 2 group 224.1.1.1 interfaces gi2
Switch(config)#
Switch# show mvr members
Group IP Address | Type | LifeSec | Port
-----
224.1.1.1 | Static | -- | gi2
Total Number of Entry = 1
```

20.9 CLEAR MVR MEMBERS

This command will clear the mvr groups for selected type.

`Switch#clear mvr members [dynamic|static]`

Syntax `clear mvr members [dynamic|static]`

Parameter

dynamic dynamic group
specifies MVR **static** specifies MVR static group

Default Clear all of mvr

group Mode Privileged

EXEC

The following example specifies that clear all mvr groups test.

Example

Switch# **clear mvr members**

```
Switch# clear mvr members
```

20.10 SHOW MVR MEMBERS

This command will display the mvr groups for all of type.

Switch#**show mvr members**

Syntax **show mvr members**

Mode Privileged EXEC

The following example specifies that show mvr groups test.

ExampleSwitch# **show mvr members**

```
Switch# show mvr members
Group IP Address | Type | Life(Sec) | Port
-----
224.1.1.1 | Static | 0 | g12
Total Number of Entry = 1
```

20.11 SHOW MVR INTERFACE

This command will display mvr port type and port immediate status.

Switch# **show mvr interface** *{IF_PORTS}*

Syntax **show mvr interface** *{IF_PORTS}*

Parameter *IF_PORTS* Show specifies port list

configuration Mode Privileged EXEC

The following example specifies that show mvr interface test.

Switch# **show mvr interface**

Example

```
Switch# show mvr interface
Port      Type      Immediate Level
-----
0/11      Source    Disabled
0/12      Remote    Disabled
0/13      Home      Disabled
0/14      Home      Disabled
0/15      Home      Disabled
0/16      Home      Disabled
0/17      Home      Disabled
0/18      Home      Disabled
0/19      Home      Disabled
0/20      Home      Disabled
0/21      Home      Disabled
0/22      Home      Disabled
0/23      Home      Disabled
0/24      Home      Disabled
0/25      Home      Disabled
0/26      Home      Disabled
0/27      Home      Disabled
0/28      Home      Disabled
0/29      Home      Disabled
0/30      Home      Disabled
0/31      Home      Disabled
0/32      Home      Disabled
0/33      Home      Disabled
0/34      Home      Disabled
0/35      Home      Disabled
0/36      Home      Disabled
0/37      Home      Disabled
0/38      Home      Disabled
0/39      Home      Disabled
0/40      Home      Disabled
0/41      Home      Disabled
0/42      Home      Disabled
0/43      Home      Disabled
0/44      Home      Disabled
0/45      Home      Disabled
0/46      Home      Disabled
0/47      Home      Disabled
0/48      Home      Disabled
0/49      Home      Disabled
```

20.12 SHOW MVR

This command will display mvr global

information. Switch#**show mvr**

Syntax **show mvr**

Mode Privileged EXEC

The following example specifies that show mvr test.

```
Switch# show mvr
MVR Running : Enabled
MVR Multicast VSM : 2
MVR Group Range : 224.1.1.1 - 224.1.1.8
MVR Max Multicast Groups : 128
MVR Current Multicast Groups : 0
MVR Global query response time : 1 sec
MVR Mode : compatible
```

Example Switch# **show mvr**

21. PORT

The switch comes with default port settings that should allow you to connect to the Ethernet Ports without any necessary configuration. Should there be a need to change the name of the ports, Port State, negotiation settings or flow control settings etc., you can do this in the Port settings by below commands

21.1 BACK-PRESSURE

Use “**back-pressure**” command to make port to enable back pressure feature. Use “**no**” form of this command to disable back pressure feature. The only way to show this configuration is using “**show running- config**” command.

```
Switch#configure terminal
```

```
Switch(config-if)# back-pressure
```

```
Switch(config-if)# no back-
```

```
pressure
```

```
back-pressure
```

Synta

```
x no back-pressure
```

Default Default back pressure state is

enabled. Mode Interface Configuration

This example shows how to configure port gi1 and gi2 to be

protected port. Switch#**configure terminal**

```
Switch(config)# interface
```

Examp

```
e GigabitEthernet 1 Switch(config-if)#
```

```
back-pressure
```

```
Switch#configure terminal
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# back-pressure
```

Switch(config-if)# no back-pressure

21.2 CLEAR INTERFACE

Use “clear interface” command to clear statistic counters on specific ports. Switch#configure terminal

Switch(config)# clear interfaces *{IF_PORTS}* counters

Syntax clear interfaces *{IF_PORTS}* counters

Parameter *IF_PORTS* Specify port to clear counters

Default No default value for this command.

Mode Privileged EXEC

This example shows how to clear counters on port gi1.

Switch# **clear interfaces gi1 counters**

Example
e This example shows how to show current counters Switch# **show interfaces gi1**

```
Switch# show interfaces gi1
GigabitEthernet1 is down
Hardware is Gigabit Ethernet
Auto-negotiation is on
Media type is Copper
Flow-control is off
Negotiation is disabled
  0 packets input, 0 bytes, 0 throttles
Received 0 broadcasts (0 multicasts)
  0 runs, 0 giants, 0 throttles
  0 input errors, 0 CRC, 0 frame
  0 multibytes, 0 pause input
  0 input packets with dribble condition detected
  0 packets output, 0 bytes, 0 underrun
  0 output errors, 0 collisions
  0 babbles, 0 late collision, 0 deferred
  0 pause output
Switch#
```

21.3 DESCRIPTION

Use “**description**” command to give the port a name to identify it easily. If description includes space character, please use double quoted to wrap it. Use “**no**” form to restore description to empty string.

```
Switch#configure terminal
```

```
Switch(config)#interface {Interface-ID}
```

```
Switch(config-if)#description WORD<1-
```

```
32> Switch(config-if)#no description
```

```
description WORD<1-32>
```

Synta

x no description

ParameterWORD<1-32> Specify port description

string. Mode Interface Configuration

This example shows how to modify port descriptions.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

Examp

e

```
GigabitEthernet 1 Switch(config-if)#
```

```
description userport
```

```
Switch# configure terminal
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# description userport
```

```
Switch# show interfaces gig et
Port Name      Status      Vlan Duplex Speed Type
---
gig1 userport  connected  1    a-full a-1000M Copper
```

21.4 DUPLEX

Use “**duplex**” command to change port duplex configuration.

```
Switch#configure terminal
```

```
Switch(config)#interface {Interface-ID}
```

```
Switch(config-if)#duplex (auto | full |
```

```
half)
```

```
Syntax duplex (auto | full | half)
```

auto Specify port duplex to auto negotiation. Parameter **full** Specify port duplex to force full duplex. **half** Specify port duplex to force half duplex.

Default Default port duplex is

auto Mode Interface

Configuration

This example shows how to modify port duplex configuration.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 1 Switch(config-if)#
```

Example

```
duplex full Switch(config-if)# exit
```

This example shows how to show current interface link

s ed Switch# show interfaces status

p

e

```
Switch# conf t
Switch(config)# int g1
Switch(config-if)# duplex full
Switch(config-if)#
Switch# show interfaces g1 status
Port Name      Status      Vlan Duplex Speed  Type
g1  GigEport1  connected  1    Full  10000 Copper
```

21.5 EEE

Use “**eee**” command to make port to enable the energy efficient Ethernet Feature .Use “**no**” form of this command to disable eee. IEEE 802.3az Energy Efficient Ethernet (EEE) is a standard that allows physical layer transmitters to consume less power during periods of low data activity. The only way to show this configuration is using “**show running-config**” command.

```
Switch#configure terminal
```

```
Switch(config)#interface {Interface-
```

```
ID} Switch(config-if)# eee
```

```
Switch(config-if)#no eee
```

```
          eee  
Syntax  
x       no eee
```

```
ParameterNone
```

```
Default   Default eee state is
```

```
disabled Mode   Interface
```

```
Configuration
```

```
          This example shows how to configure port gi1 and gi2 to be  
          protected port. Switch#configure terminal
```

```
          Switch(config)# interface
```

```
Exampl GigabitEthernet 1 Switch(config-if)# eee
```

```
e       This example shows how to show current jumbo-frame size
```

```
          Switch# show running-config interface gi1
```

```
Switch# show running-config interfaces gi1
interface gi1
  no
  duplex full
  no back-pressure
!
Switch#
```

21.6 FLOWCONTROL

Use “**flowcontrol**” command to change port flow control configuration. Use “**no**” form to restore flow control to default (off) configuration.

Switch#**configure terminal**

Switch(config)#**interface** {Interface-ID}

Switch(config-if)#**flowcontrol** (auto | off |

on) Switch(config-if)#**no flowcontrol**

flowcontrol (auto | off | on)

Syntax

x **no flowcontrol**

auto Automatically enables or disables flow control on the interface.

Parameter **off** Disable port flow control.

on Enable port flow control.

Default Default port flow control is

off Mode Interface Configuration

This example shows how to modify port duplex configuration.

Switch(config)# **interface** GigabitEthernet 1

Switch(config-if)# **flowcontrol on**

This example shows how to show current flow control

Example

e configuration Switch# **show interfaces** GigabitEthernet 1

```
Switch# show interfaces GigabitEthernet 1
GigabitEthernet1 is down
Hardware is Gigabit Ethernet
Full-duplex, 1000-speed, media type is Copper
Flow-control is on
Back-pressure is disabled
  0 packets input, 0 bytes, 0 throttles
Received 0 broadcasts (0 multicasts)
  0 runs, 0 queues, 0 throttles
  0 input errors, 0 CRC, 0 frame
  0 multicast, 0 pause input
  0 input packets with disable condition detected
  0 packets output, 0 bytes, 0 underrun
  0 output errors, 0 collisions
  0 badlines, 0 late collision, 0 deferred
  0 PAM2 output
Switch#
```

21.7 JUMBO-FRAME

A **jumbo frame** is an Ethernet **frame** with a payload greater than the standard maximum transmission unit (MTU) of 1,500 bytes. **Jumbo frames** are used on local area networks that support at least 1 Gbps and can be as large as 10,000 bytes. Use “**jumbo-frame**” command to modify maximum frame size. The only way to show this configuration is using “**show running-config**” command.

Switch#configure terminal

Switch(config)#jumbo-frame <1518-

10000> Syntax jumbo-frame <1518-

10000>

Parameter <1518-10000>Specify the maximum frame size.

Default Default maximum frame size is

1522. Mode Global Configuration

This example shows how to modify maximum frame size on gi1 to 10000 bytes.

Switch#configure terminal

Switch(config)# jumbo-frame 9216

Examp

```
Switch# config t
Switch(config)# jumbo-frame
<1518-10000> Maximum frame size
```

e

This example shows how to show current jumbo-frame size

Switch# show running-config jumbo-frame 9216

```
Switch# sh run
Switch# sh run
SYSTEM CONFIG FILE is: BEGIN
System Description: KT-NOS RTL8382M Switch
System Version: vSoldierOS.2K.v1.4
System Name: Switch
System Up Time: 0 days, 3 hours, 9 mins, 27 secs
jumbo-frame 9216
```

21.8 MEDIA-TYPE

Use “**media-type**” command to change combo port media type. Use “**no**” form of this command to restore media type to default.

Switch#**configure terminal**

Switch(config)#**interface** {Interface-ID}

Switch(config-if)#**media-type** (auto-select | rj45 |

sfp) Switch(config-if)#**no media-type**

media-type (auto-select | rj45 | sfp)

Syntax

x **no media-type**

auto-select Select media automatically.

Parameter**rj45** Select copper media.

sfp Select fiber media.

Default Default media type is

auto. ModelInterface

Configuration

This example shows how to modify combo port media type to copper.

Switch#**configure terminal**

Example Switch(config)# **interface** gi25

Switch(config-if)# **media-type**

rj45

```
switch(config-if)# int gbs
switch(config-if)# media-type
auto-select Use whichever connector is attached
sfp Use SFP connector
copper Use copper connector
```

21.9 PROTECTED

Use “**protected**” command to make port to be protected. Protected port is only allowed to communicate with unprotected port. In other words, protected port is not allowed to communicate with another protected port. Use “**no**” form to make port unprotected.

```
Switch#configure terminal
```

```
Switch(config)#interface {Interface-
```

```
ID} Switch(config-if)# protected
```

```
Switch(config-if)#no protected
```

```
protected
Syntax
x no protected
```

Default Default protected state is no

protected. Mode Interface Configuration

This example shows how to configure port gi1 and gi2 to be protected port.

```
Switch#configure terminal
```

```
Switch(config)# interface range gi11-12
```

```
Switch(config-if-range)# protected
```

Example

This example shows how to show current protected port

```
state. Switch# show interfaces GigabitEthernet 11-12
```

```
protected
```

```
Switch# configure terminal
Switch(config)# interface range gi11-12
Switch(config-if-range)# protected
Switch(config-if-range)#
Switch# show interfaces GigabitEthernet 11-12 protected
Port    Protected State
-----
gi11    enabled
gi12    enabled
```

21.10 SHOW INTERFACE

Use “**show interface**” command to show detail port counters, parameters and status. Use “**show interface status**” command to show brief port status. Use “**show interface protected**” command to show protected status.

```
Switch# show interfaces {IF_PORTS}
```

```
Switch# show interfaces {IF_PORTS}status
```

```
Switch# show interfaces {IF_PORTS}protected
```

show interfaces *{IF_PORTS}*

Syntax
X show interfaces *{IF_PORTS}* status

show interfaces *{IF_PORTS}*

protected

Parameter *{IF_PORTS}* Specify port to show.

Mode Privileged EXEC

This example shows how to show current counters Switch# **show interfaces**

GigabitEthernet 1

```
Switch# show interfaces GigabitEthernet 1
GigabitEthernet1 is down
Hardware is Gigabit Ethernet
Full-duplex, Auto-speed, media type is Copper
Flow-control is on
back-pressure is disabled
  0 packets input, 0 bytes, 0 throttles
  Received 0 broadcasts (0 multicasts)
  0 runs, 0 giants, 0 throttles
  0 input errors, 0 CRC, 0 frame
  0 multicast, 0 pause input
  0 input packets with dribble condition detected
  0 packets output, 0 bytes, 0 underrun
  0 output errors, 0 collisions
  0 babble, 0 late collision, 0 deferred
  0 PRRSE output
Switch#
```

Example
e This example shows how to show current protected port state. Switch# **show interfaces** GigabitEthernet 1-2

protected

```
Switch# show interfaces GigabitEthernet 1-2 protected
Port | Protected State
-----|-----
gi1 | enabled
gi2 | enabled
Switch#
```

This example shows how to show current port status Switch# **show interfaces**

GigabitEthernet 1-2 status

```
Switch# show interfaces GigabitEthernet 1-2 status
Port Name      Status      Vlan Duplex Speed Type
---
gi1 uplink port notconnect 1 full auto Copper
gi2 uplink port notconnect 1 half auto Copper
Switch#
```

21.11 SPEED

Use “**speed**” command to change port speed configuration. The speed is only able to configure to the physical maximum speed. For example, in fast Ethernet port, speed 1000 is not available. You cannot configure the speed on the SFP module ports, but you can configure the speed to not negotiate (nonegotiate) if it is connected to a device that does not support autonegotiation.

Switch#**configure terminal**

Switch(config)#**interface** {Interface-

ID} Switch(config-if)# **speed (10 | 100**

| 1000)

Switch(config-if)# **speed auto [(10 | 100 | 1000 | 10/100)]**

Switch(config-if)#**speed nonegotiate**

Switch(config-if)#**no speed nonegotiate**

speed (10 | 100 | 1000)

speed auto [(10 | 100 | 1000 |

Syntax

x **10/100)] speed nonegotiate**

no speed nonegotiate

10 Specify port speed to force 10Mbps/s or auto with 10Mbps/s ability.

100 Specify port speed to force 100Mbps/s or auto with 100Mbps/s ability.

Parameter **1000**

Specify port speed to force 1000Mbps/s or auto with 1000Mbps/s ability.

10/100 Specify port speed to auto with 10Mbps/s and

100Mbps/s

Default Default port speed is auto with all available

abilities. Mode Interface Configuration

21.12 SHUTDOWN

Use “**shutdown**” command to disable port and use “**no shutdown**” to enable port. If port is error disabled by some reason, use “**no shutdown**” command can also recovery the port manually.

Switch#**configure terminal**

Switch(config)#**interface** {Interface-

ID} Switch(config-if)# **shutdown**

Switch(config-if)#**no shutdown**

shutdown

Synta

x **no shutdown**

Default Default port admin state is no

shutdown. Mode Interface Configuration

This example shows how to modify port duplex configuration.

Switch#**configure terminal**

Switch(config)# **interface**

gi1 Switch(config-if)#

shutdown

Example This example shows how to show current admin state configuration

Switch# **show running-config interfaces gi1**

```
Switch# show running-config interfaces GigabitEthernet 1
GigabitEthernet 1/0/1
  ip 1 mode static
  speed 100
  duplex full
  description 'Access'
  ip 1 add mac-group 10
  ip 1 add mac-group action replace
  ip 1 add filter 1
  ip 1 cbr-select port-desc app-name app-desc app-cap mac-phy lag mac-frame-size
  ip 1 cbr-select vlan-name 100
  ip 1 add cbr-select network-policy location inventory
  ip 1 add network-policy add 1
```

PORT ERROR DISABLE

When a **port** is in **error-disabled** state, it is effectively shut down and no traffic is sent or received on that **port**. The ErrDisable feature is implemented to handle critical situations where the switch detected excessive or late collisions on a port, port duplex misconfiguration, Ether Channel misconfiguration, Bridge Protocol Data Unit (BPDU) port-guard violation, UniDirectional Link Detection (UDLD), and other causes.

The error-disable function let the switch to shut down a port when it encounters physical, driver or configuration problems. A port being error-disabled is not by itself a cause for alarm, but for a reason of a problem that must be resolved.

When a port is in error-disabled state, it will shut down and no traffic is sent or received on that port.

22.1 ERRDISABLE RECOVERY CAUSE

Ports would be disabled because of the invalid actions detected by protocols. To enable the port error disable recovery from the specific cause, use the command `errdisable recovery cause` in the Global Configuration mode.

Switch#**configure terminal**

Switch(config)#**errdisable recovery cause(all|acl|arp-inspection |bpduguard| broadcast-flood|dhcp-rate-limit|psecure-violation|selfloop|unicast-flood|unknown-multicastflood)**

Switch(config)#**no errdisable recovery cause(all| acl| arpinspection |bpduguard|broadcast-flood|dhcp-rate-limit|psecure-violation| selfloop| unicast-flood|unknown-multicastflood)**

errdisable recovery cause(all| acl| arp-inspection| bpduguard| broadcast- flood| dhcp- rate-limit| psecure-violation| selfloop| unicast-flood| unknown-multicastflood)

Synta

x

no errdisable recovery cause(all| acl| arp inspection| bpduguard| broadcast- flood| dhcp- rate-limit| psecure-violation| selfloop| unicast-flood| unknown- multicastflood)

all Enable the auto recovery for port error disabled from all causes.

acl Enable the auto recovery for port error disabled from the ACL cause.

arp-inspection Enable the auto recovery for port error disabled from the ARP inspection cause.

bpduguard Enable the auto recovery for port error disabled from the STP BPDU Guard cause.

broadcast-flood Enable the auto recovery for port error disabled from the broadcast flooding cause.

Parameter

dhcp-rate-limit Enable the auto recovery for port error disabled from the DHCP rate limit cause.

psecure-violation Enable the auto recovery for port error disabled from the port security cause.

selfloop Enable the auto recovery for port error disabled from the STP self-loop cause.

unicast-flood Enable the auto recovery for port error disabled from the unicast flooding cause.

unknown-multicastflood Enable the auto recovery for port error disabled from the unknown multicast flooding cause.

Default Error disable recovery is disabled for all cause

Mode Global Configuration

The following example enables the port error disable recovery for the STP BPDU Guard and self-loop cause.

```
Switch#configure terminal
```

```
Switch(config)# errdisable recovery cause bpduguard
```

```
Switch(config)# errdisable recovery cause selfloop
```

Examp
le

```
Switch# configure terminal  
Switch(config)# errdisable recovery cause bpduguard  
Switch(config)# errdisable recovery cause selfloop
```

The following example To remove the port error disable recovery from the specific cause. Switch#configure terminal

```
Switch(config)# no errdisable recovery cause bpduguard
```

```
Switch(config)# no errdisable recovery cause selfloop
```

22.2 ERRDISABLE RECOVERY INTERVAL

To set the recovery time of the error disabled ports, use the command `errdisable recovery interval` in the Global Configuration mode.

```
Switch#configure terminal
```

```
Switch(config)# errdisable recovery interval
```

```
(seconds) Syntax errdisable recovery interval
```

seconds

Parameter **seconds** The time in seconds to recover from a specific error- disable state. The valid range is 0 to 86400 seconds, and the default value is 300 seconds.

Default The default recovery time is 300

seconds Mode Global Configuration

The following example set the aging time to 500 seconds.

```
Example        Switch#configure terminal
```

```
e
```

```
Switch(config)# errdisable recovery interval 60
```

22.3 SHOW ERRDISABLE RECOVERY

To show the error disable configuration and the interfaces in the error disabled state, use the command `show errdisable recovery` in the Privileged EXEC mode.

Switch# **show errdisable recovery**

Syntax **show errdisable**

recovery Mode Privileged EXEC

The following example shows the error disable configuration, and the interfaces in the error disabled state.

Switch# **show errdisable recovery**

Example

```
Switch# show errdisable recovery
ErrDisable Reason      | Timer Status
-----
bpdguard              | enabled
udld                   | enabled
sfploop               | enabled
broadcast-flood       | disabled
unknown-multicast-flood | disabled
multicast-flood       | disabled
sdl                    | disabled
secure-violation      | disabled
dhcp-rate-limit       | disabled
arp-inspection        | disabled

Timer Interval : 60 seconds

Interfaces that will be enabled at the next timeout:
Port | Error Disable Reason | Time Left
-----
```

PORT SECURITY

Port Security helps secure the network by preventing unknown devices from forwarding packets. When a link goes down, all dynamically locked addresses are freed. The port security feature offers the following benefits:

You can limit the number of MAC addresses on a given port. Packets that have a matching MAC address (secure packets) are forwarded; all other packets (unsecure packets) are restricted.

You can enable port security on a per port basis. Port security implements two traffic filtering methods, dynamic locking and static locking. These methods can be used concurrently.

Dynamic locking

you can specify the maximum number of MAC addresses that can be learned on a port. The maximum number of MAC addresses is platform dependent and is given in the software Release Notes. After the limit is reached, additional MAC addresses are not learned. Only frames with an allowable source MAC addresses are forwarded.

Dynamically locked addresses can be converted to statically locked addresses. Dynamically locked MAC addresses are aged out if another packet with that address is not seen within the age-out time. You can set the time out value. Dynamically locked MAC addresses are eligible to be learned by another port. Static MAC addresses are not eligible for aging.

Static locking

you can manually specify a list of static MAC addresses for a port. Dynamically locked addresses can be converted to statically locked addresses.

By using port security, a network administrator can associate specific MAC addresses with the interface, which can prevent an attacker to connect his device. This way you can restrict access to an interface so that only the authorized devices can use it. If an unauthorized device is connected, you can decide what action the switch will take, for example discarding the traffic and shutting down the port.

23.1 PORT-SECURITY (GLOBAL)

The “**port-security**” command enables the port security functionality globally. Use the “**no**” form of this command to disable. You can verify settings by the show port-security command.

Switch#**configure terminal**

Switch(config)# port-security

Switch(config)# no port-security

port-security

Synta

x no port-security

Default Default is disabled

Mode Global Configuration

The following example shows how to enable port security

Switch#configure terminal

ExampleSwitch(config)# port-security

Switch# show port-security

```
Switch# configure terminal
Switch(config)# port-security
Switch(config)#
Switch# show port-security
Port Security: Enabled
Port limit: 10 pps
Port  MacAddr  TotalAddr  ConfigAddr  Violation  Action
-----  -
```

23.2 PORT-SECURITY (INTERFACE)

The “**port-security**” command enables the port security functionality on this port. Use the “**no**” form of this command to disable. You can verify settings by the show port-security interface command.

```
Switch#configure terminal
```

```
Switch(config)# port-security
```

```
Switch(config)# no port-security
```

```
port-security
Syntax
x no port-security
```

```
Mode Port Configuration
```

The following example shows how to enable port security on interface GigabitEthernet 1

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
Example
e GigabitEthernet 1 Switch(config-if)#
```

```
port-security
```

```
Switch# show port-security interfaces GigabitEthernet 1
```

```
Switch#configure terminal
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# port-security
Switch(config-if)#
Switch# show port-security interface GigabitEthernet 1
Port      Status  Secure  Timeout  Configs  Violation
-----
Gi1/0/24 Security  1       0         0         0         Protect
```

23.3 PORT-SECURITY ADDRESS-LIMIT

Use the “**port-security address-limit**” command to set the learning-limit number and the violation action. Use the “**no**” form of this command to restore the default settings. You can verify settings by the show port- security interface command.

Switch#**configure terminal**

Switch(config)#**port-security address-limit <1-256> action (forward |discard |shutdown)**

Switch(config)#**no port-security address-limit**

Syntax
x **port-security address-limit <1-256>action (forward| discard| shutdown) no port-security address-limit**

<1-256>The learning-limit number. It specifies how many MAC addresses this port can learn.

forward Forward this packet whose SMAC is new to system and exceed the learning-limit number.

Parameter
discard Discard this packet whose SMAC is new to system and exceed the learning-limit number.

shutdown Shutdown this port when receives a packet whose SMAC is new to system and exceed the learning limit number.

Default The address-limit default is 1 and action is

“drop”. Mode Port Configuration

e

Example

The following example shows how to enable port security on port 1 and

set the learning limit number to 10.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 1
```

```
Switch(config-if)# port-security address-limit 1
```

```
Switch(config-if)# port-security violation protect
```

```
Switch# show port-security interfaces
```

```
GigabitEthernet 1
```

```
Switch# configure terminal
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# port-security address-limit 1
Switch(config-if)# port-security violation protect
Switch(config-if)#
Switch# show port-security interfaces GigabitEthernet 1
Port Status      MaxAddr  TotalAddr  ConfigAddr  Violation  Action
-----
G1 Security 1      0          0            0          Protect
```

23.4 SHOW PORT-SECURITY

Use “**show port-security**” command to show port-security global information. Switch# **show port-security**

Syntax **show port-security**

Mode Privileged EXEC

This example shows how to show port-security configurations.

Example Switch# **show port-security**

```
Switch# show port-security
Port Security Enabled
Data limit: 100 pps

Port  MaxAddr  TotalAddr  ConfigAddr  Violation  Action
-----
Gig1  1          0          0          0          Protect
```

23.5 SHOW PORT-SECURITY INTERFACE

Use “**show port-security interfaces**” command to show port-security information of the specified port. Switch# **show port-security interface** *{IF_PORTS}*

Syntax **show port-security interface** *{IF_PORTS}*


Parameter *{IF_PORTS}* Select port to show port-security

configurations Default No default value for this command.

Mode Privileged EXEC

This example shows how to show port-security configurations on interface GigabitEthernet

Example 1. Switch# **show port-security interfaces** GigabitEthernet 1



```
Switch# show port-security interfaces GigabitEthernet 1
Port      Status      Breach    TotalBrc  ConfigErr  Violation  Action
---      -
G1/0/24  Down        1         0         0         0         Protect
```

24. PROTOCOL VLAN

Protocol-based VLAN processes traffic based on protocol. You can use a protocol-based VLAN to define filtering criteria for untagged packets. If you do not change the port configuration or configure a protocol-based VLAN, switch assigns untagged packets to VLAN 1. You can override this default behavior by defining port-based VLANs, protocol-based VLANs, or both. Switch always processes tagged packets according to the 802.1q standard and does not forward them to protocol-based VLANs.

If you assign a port to a protocol-based VLAN for a specific protocol, switch assigns the protocol-based VLAN ID to untagged frames that it receives on the port for that protocol. For other protocols, switch assigns the port VLAN ID to untagged frames that it receives on the port, either the default PVID1 or a PVID that you assigned to the port.

You define a protocol based VLAN by creating a group. Each group has a one-to-one relationship with a VLAN ID, can include one to three protocol definitions, and can include multiple ports. When you create a group, you must specify a name. The smart switch assigns a group ID automatically.

24.1 VLAN PROTOCOL-VLAN GROUP (GLOBAL)

Use the `vlan protocol-vlan group` Global Configuration mode command to add protocol vlan group with specific proto type and value. Use the “no” form of this command to remove protocol vlan group setting. You can verify your setting by entering the `show vlan proto-vlan` Privileged EXEC command.

```
Switch# configure terminal
```

```
Switch(config)# vlan protocol-vlan group <1-8> frame-type (ethernet_ii |llc_other|snap_1042)  
protocol- value VALUE
```

```
Switch(config)# no vlan protocol-vlan group <1-8>
```

```
vlan protocol-vlan group <1-8>frame-type
```

```
Synta (ethernet_ii|llc_other|snap_1042)protocol-value
```

```
x
```

```
VALUE no vlan protocol-vlan group <1-8>
```

```
<1-8> Specify protocol vlan group to configure
```

```
Parameter(ethernet_ii|llc_other|snap_1042) Specify protocol based frame
```

type VALUE Specify protocol value to configure

Mode Global Configuration

The following example show how to configure protocol vlan

group: Switch# **configure terminal**

Switch(config)# **vlan protocol-vlan group 1 frame-type ethernet_ii protocol-value 0x806**

Example

Switch(config)# **vlan protocol-vlan group 2 frame-type llc_other protocol-value**

0x800 Switch# **show vlan protocol-vlan**

```
Switch# configure terminal
Switch(config)# vlan protocol-vlan group 1 frame-type ethernet_ii protocol-value 0x806
Switch(config)# vlan protocol-vlan group 2 frame-type llc_other protocol-value 0x800
Switch(config)#
Switch# show vlan protocol-vlan
```

Group ID	Status	Type	Value
1	Enabled	Ethernet_II	0x806
2	Enabled	llc_other	0x800
3	Disabled	--	--
4	Disabled	--	--
5	Disabled	--	--
6	Disabled	--	--
7	Disabled	--	--
8	Disabled	--	--

24.2 VLAN PROTOCOL-VLAN GROUP (INTERFACE)

Use the `vlan protocol-vlan binding` Interface Configuration mode command to binding protocol VLAN Group on specified interfaces. Use the “no” form of this command to cancel protocol VLAN Group Binding. You can verify your setting by entering the `show vlan protocol-vlan interfaces IF_PORTS` Privileged EXEC command

```
Switch# configure terminal
```

```
Switch(config-if)# vlan protocol-vlan group <1-8> vlan <1-4094>
```

```
Switch(config-if)# no vlan protocol-vlan group <1-8>
```

```
        vlan protocol-vlan group <1-8>vlan <1-4094>
```

Syntax

```
x        no vlan protocol-vlan group <1-8>
```

Parameter <1-8> Specify protocol vlan group to binding

Parameter <1-4094> Specifies the Proto VLAN ID to configure.

Mode Interface configuration

The following example how to configure Protocol VLAN function on specified interfaces.

```
Switch# configure terminal
```

```
Switch(config)# interface GigabitEthernet 1
```

```
Switch(config-if)# vlan protocol-vlan group 1 vlan
```

Example 2

```
e        Switch# show vlan protocol-vlan interfaces GigabitEthernet 1
```

```
Switch# configure terminal
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# vlan protocol-vlan group 1 vlan 2
Switch(config-if)#
Switch# show vlan protocol-vlan interfaces GigabitEthernet 1

Port g1/1
Group 1
  Status : Enabled
  VLAN ID : 2
Group 2
  Status : Disabled
Group 3
  Status : Disabled
Group 4
  Status : Disabled
Group 5
  Status : Disabled
Group 6
  Status : Disabled
Group 7
  Status : Disabled
Group 8
  Status : Disabled
```

24.3 SHOW VLAN PROTOCOL-VLAN

Use the show vlan proto-vlan command in EXEC mode to display Proto VLAN group configuration. Switch# **show vlan protocol-vlan[group <1-8>]**


Syntax **show vlan protocol-vlan[group <1-8>]**

Parameter <1-8> Specify protocol vlan group to

display Mode Privileged EXEC

The following example how to display Proto VLAN group configuration

Example
Switch# **show vlan protocol-vlan**



Group ID	Status	Type	Value
1	Enabled	Ethernet	0x2000
2	Enabled	LLD other	0x2000
3	Disabled	---	---
4	Disabled	---	---
5	Disabled	---	---
6	Disabled	---	---
7	Disabled	---	---
8	Disabled	---	---

24.4 SHOW VLAN PROTOCOL-VLAN INTERFACES

Use the show vlan protocol-vlan interface command in EXEC mode to display the Protocol VLAN interfaces setting.

Switch# show vlan protocol-vlan interfaces *{IF_PORTS}*

Syntax show vlan protocol-vlan interfaces *{IF_PORTS}*

Parameter *{IF_PORTS}* Specify interfaces protocol vlan to

display Mode Privileged EXEC

The following example shows how to display the Protocol VLAN interfaces setting

Switch# show vlan protocol-vlan interfaces GigabitEthernet 1

Example

```
Switch# show vlan protocol-vlan interfaces GigabitEthernet 1
Port g11 :
Group 1 :
Status : Enabled
VLAN ID : 2
Group 2 :
Status : Enabled
VLAN ID : 3
Group 3 :
Status : Disabled
Group 4 :
Status : Disabled
Group 5 :
Status : Disabled
Group 6 :
Status : Disabled
Group 7 :
Status : Disabled
Group 8 :
Status : Disabled
Switch#
```

QoS

A communications network forms the backbone of any successful organization. These networks transport a multitude of applications and data, including high-quality video and delay-sensitive data such as real-time voice. The bandwidth-intensive applications stretch network capabilities and resources, but also complement, add value, and enhance every business process. Networks must provide secure, predictable, measurable, and sometimes guaranteed services. Achieving the required Quality of Service (QoS) by managing the delay, delay variation (jitter), bandwidth, and packet loss parameters on a network becomes the secret to a successful end-to-end business solution. Thus, QoS is the set of techniques to manage network resources.

IP Precedence and DSCP Compared

The IP header is defined in RFC 791, including a 1-byte field called the Type of Service (ToS) byte. The ToS byte was intended to be used as a field to mark a packet for treatment with QoS tools. The ToS byte itself was further subdivided, with the high-order 3 bits defined as the *IP Precedence (IPP)* field. The complete list of values from the ToS byte's original IPP 3-bit field, and the corresponding names, is provided in Figure.




Fig 25.1 QoS in IP header with IP Precedence

Ethernet LAN Class of Service

Ethernet supports a 3-bit QoS marking field, but the field only exists when the Ethernet header includes either an 802.1Q or ISL trunking header. IEEE 802.1Q defines its QoS field as the 3 most significant bits of the 2-byte *Tag Control* field, calling the field the *user-priority bits*. ISL defines the 3 least-significant bits from the 1-byte *User* field, calling this field the *Class of Service (CoS)*.




Fig 25.2 QoS in IP header with LAN CoS Feilds

25.1 QOS

Use “**qos**” command to enable quality of service which according to basic trust type to assign queue for packets, and packets with higher priority are able to send first. Use “**no**” form of this command to disable quality of service.

Switch#**configure terminal**

Switch(config)#**qos**

Switch(config)# **no qos**

Syntax
x **qos**
 no qos

Mode Global Configuration

This example shows how to change qos to basic mode.

Switch#**configure terminal**

Example Switch(config)# **qos**

This example shows how to check current qos

mode. Switch# **show qos**

```
Switch# configure terminal
Switch(config)# qos
Switch(config)#
Switch# sh qos
QoS Mode: basic
QoS trust: qos
```

25.2 QOS COS

Sometimes, there is no qos information in the packets, such as CoS, DSCP, IP Precedence. But we still can give the priority for packets by configuring the interface default cos value. If there is no qos information in the packets, the device will use this default cos value and find the cos-queue map to get the final destination queue. Use “**qos cos**” command to assign port default cos value.

Switch#**configure terminal**

Switch(config)# **interface** {Interface-

ID} Switch(config-if)#**qos cos** <0-7>

Syntax **Qos cos** <0-7>

Parameter **cos** <0-7> Specify the CoS value for the

interface. Default Default CoS value for interface is 0.

Mode Interface Configuration

This example shows how to configure default cos value 7 on interface gi1.

Switch#**configure terminal**

Switch(config)# **interface**

Example GigabitEthernet 1 Switch(config-if)# **qos**
e **cos 7**

Switch(config-if)# **end**

Switch# **show qos interface** GigabitEthernet 1

```
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# qos cos 7
Switch(config-if)# end
Switch# show qos interface GigabitEthernet 1
  Port | Cos | Trust State | Remark Cos | Remark DSCP | Remark IP Preced
-----|----|-----|-----|-----|-----
  gi1  | 7   | enabled   | disabled  | disabled   | disabled
Switch#
```

25.3 QOS MAP

According to different trust type, packets will be assigned to different queue based on the specific qos map. For example, if the trust type is trust cos, the device will get the cos value in packet and reference the cos- queue mapping to assign the correct queue.

The queue to cos, dscp or precedence maps are used by remarking function. If the port remarking feature is enabled, the remarking function will reference these 3 tables to remark packets.

Switch#configure terminal

Switch(config)#qos map (cos-queue | dscp-queue | precedence-queue) SEQUENCE to

<1-8> Switch(config)#qos map (queue-cos | queue-precedence) SEQUENCE to <0-7>

Switch(config)#qos map queue-dscp SEQUENCE to <0-63>

qos map (cos-queue | dscp-queue | precedence-queue) SEQUENCE to <1-8>

Syntax qos map (queue-cos | queue-precedence) SEQUENCE to <0-7>

x qos map queue-dscp SEQUENCE to <0-63>

cos-queue Configure or show CoS to queue

map dscp-queue Configure or show DSCP to

queue map

precedence-queue Configure or show IP Precedence to

queue map. queue-cos Configure or show queue to CoS

map

queue-dscp Configure or show queue to DSCP map

Parameter queue-precedence Configure or show queue to IP Precedence map

SEQUENCE Specify the cos, dscp, precedence or queue with one or multiple values.

<1-8>Specify the queue id

<0-7>Specify the cos or precedence values

<0-63>Specify the dscp values

The default values of cos-queue are showing in the following table.

CoS	Queue ID
0	2
1	1
2	3
3	4
4	5
5	6
6	7
7	8

The default values of dscp-queue are showing in the following table.

DSCP	Queue ID
0-7	1
8-15	2
16-23	3
24-31	4
32-39	5
40-47	6
48-55	7
56-63	8

The default values of ip precedence are showing in the following table

IP Precedence	Queue ID
0	1
1	2
2	3
3	4
4	5
5	6
6	7
7	8

Default
t

The default values of queue-cos are showing in the following table.

Queue ID	CoS
1	1
2	0
3	2
4	3
5	4
6	5

The default values of queue-dscp are showing in the following table.

Queue ID	DSCP
1	0
2	8
3	16
4	24
5	32
6	40
7	48
8	56

The default values of queue-precedence are showing in the following table.

Queue ID	IP Precedence
1	0
2	1
3	2
4	3
5	4
6	5
7	6
8	7

Mode Global Configuration

This example shows how to map cos 6 and 7 to

queue 1. Switch#configure terminal

Switch(config)# qos map cos-queue 6 7 to 1

Switch# show qos map cos-queue

```
Switch# configure terminal
Switch(config)# qos map cos-queue 6 7 to 1
Switch(config)#
Switch# show qos map cos-queue

CoS to Queue mappings
-----
CoS   0  1  2  3  4  5  6  7
-----
Queue 2  1  3  4  5  6  1  1
```

Example

This example shows how to map queue 4 and 5 to cos 7.

Switch#configure terminal

Switch(config)# qos map queue-cos 4 5 to 7

Switch# show qos map queue-cos

```
Switch# configure terminal
Switch(config)# qos map queue-cos 4 5 to 7
Switch(config)#
Switch# show qos map cos-queue

CoS to Queue mappings
-----
CoS   0  1  2  3  4  5  6  7
-----
Queue 2  1  3  4  5  6  1  1
```

25.4 QOS QUEUE

The device support total 8 queues for QoS queuing. It is able to set the queue to be strict priority queue or weighted queue to prevent starvation. The queue with higher id value has higher priority.

First, you need to decide how many strict priority queue you need. The strict priority queue will always occupy the higher priority queue. For example, if you specify the strict priority number to be 2, then the queue 7 and 8 will be the strict priority queues and the others are weighted queues.

After you setup the number of strict priority queue, you need to setup the weight for the weighted queues by using “**qos queue weight**” command. And the bandwidth will shared by the weight you configured between these weighted queues.

Switch#**configure terminal**

Switch(config)#**qos queue strict-priority-**

num Switch(config)#**qos queue weight**

SEQUENCE Switch#**show qos queueing**

qos queue strict-priority-num <0-

Syntax **8> qos queue weight SEQUENCE**

x

show qos queueing

strict-priority-num <0-8> Specify the strict priority queue number weight

Parameter

SEQUENCE Specify the non-strict priority queue weight value. The valid queue weight value is from 1 to 127.

Default strict priority queue number is 8, it means all queues are strict priority queue. The default queue weight for each queue is shown in following table.

Default

5	5
6	9
7	13
8	15

Mode

Global Configuration

This example shows how to setup device with 3 strict priority queues and give other weighted queues with weight 5, 10, 15, 20, 25.

Switch#configure terminal

Switch(config)# qos queue strict-priority-num 3

Examp
le

Switch(config)# qos queue weight 5 10 15 20 25

Switch# show qos queueing

```
Switch# configure terminal
Switch(config)# qos queue strict-priority-num 3
Switch(config)# qos queue weight 5 10 15 20 25
Switch(config)#
Switch# show qos queueing
Queueing:  SF - Priority
1 - 5      dis- N/A
2 - 10     dis- N/A
3 - 15     dis- N/A
4 - 20     dis- N/A
5 - 25     dis- N/A
6 - N/A    cns- 6
7 - N/A    cns- 7
8 - N/A    cns- 8
```

25.5 QOS REMARK

QoS remarking feature allow you to change priority information in packets based on egress queue. For example, you want all packets egress from interface fa1 queue 1 to remark the cos value to be 5 for next tier of device, you can enable the cos remarking feature on fa1 and configure the queue-cos map for queue 1 map to cos 5.

Use “**qos remark**” command to enable remarking feature on specific type. And use “**no qos remark**” command to disable it.

Switch#**configure terminal**

Switch(config)#**qos remark (cos | dscp | precedence)**

Switch(config)# **no qos remark (cos | dscp | precedence)**

	qos remark (cos dscp precedence)
Synta	
x	no qos remark (cos dscp precedence)

cos Enable/Disable cos remarking.

Parameterdscp Enable/Disable dscp remarking.

precedence Enable/Disable precedence remarking

Defaul	Default CoS remarking is disabled. Default DSCP remarking is disabled.
--------	--

t	Default IP Precedence remarking is disabled.
---	--

Mode	Interface Configuration
------	-------------------------

This example shows how to enable remarking features on

interface gi1. Switch#**configure terminal**

Switch(config)# **interface** GigabitEthernet 1

Switch(config-if)# **qos remark cos**

Example Switch(config-if)# **qos remark dscp**

e

Switch(config-if)# **qos remark**

precedence

```
Switch# config t
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# qos remark cos
Switch(config-if)# qos remark dscp
Switch(config-if)# qos remark precedence
```

Switch# **show qos interface** GigabitEthernet 1

```
Switch# show qos interface GigabitEthernet 1
Port | CoS | Trust State | Remark CoS | Remark DSCP | Remark IP Precedence
-----|-----|-----|-----|-----|-----
gi1 | 0 | enabled | enabled | enabled | enabled
```

25.6 QOS TRUST

In QoS basic mode, there are 4 trust types for device to judge the appropriate queue of the packets. This command is able to switch between these trust types.

CoS

IEEE 802.1p defined 3bits priority value in vlan tag. Trust this value in packets and assign queue according to cos-queue map.

DSCP

IETF RFC2474 defined 6bits priority value in IP packet (highest 6bits in ToS field). Trust this value in packets and assign queue according to dscp-queue map.

IP Precedence

The highest 3bits priority value in IP packet ToS field. Trust this value in packets and assign queue according to precedence-queue map.

CoS-DSCP

Trust DSCP for IP packets and assign queue according to dscp-queue map. Trust CoS for non-IP packets and assign queue according to cos-queue map.

Switch#**configure terminal**

Switch(config)#**qos trust (cos | cos-dscp | dscp | precedence)**

Syntax **qos trust (cos | cos-dscp | dscp | precedence)**

cos Specify the device to trust CoS

cos-dscp Specify the device to trust DSCP for IP packets, and

Parametertrust CoS for non-IP packets.

dscp Specify the device to trust DSCP

precedence Specify the device to trust IP

Precedence Default Default QoS trust type is cos.

Mode Global Configuration

This example shows how to change qos basic mode trust types.

```
Switch#configure terminal
```

```
Switch(config)# qos trust cos
```

```
Switch(config)# qos trust cos-dscp
```

```
Example Switch(config)# qos trust dscp
```

e

```
Switch(config)# qos trust precedence
```

This example shows how to check current qos trust

type. Switch# show qos

```
Switch# config t
Switch(config)# qos trust cos
Switch(config)# qos trust cos-dscp
Switch(config)# qos trust dscp
Switch(config)# qos trust precedence
Switch(config)#
Switch# show qos
QoS Mode: basic
Basic trust: ip-precedence
```

25.7 QOS TRUST (INTERFACE)

Interface Configuration After QoS function is enabled in basic mode, the device also support per interface enable/disable the qos function. If the trust state on interface is enabled, all ingress packets of this interface will remap according to the trust type and the qos maps. Otherwise, all ingress packets will assign to queue 1.

Use “**qos trust**” to enable trust state on interface and use “**no qos trust**” to disable trust state on interface. Switch#**configure terminal**

Switch(config)#**qos trust**

Switch(config)# **no qos trust**

qos trust
Synta
x **no qos trust**

Default Default interface qos trust state is

enabled. Mode Interface Configuration

This example shows how to disable qos trust state on interface gi1.

Switch#**configure terminal**

Switch(config)# **interface**

Example
GigabitEthernet 1 Switch(config-if)#**qos trust**

Switch# **show qos interface** GigabitEthernet 1

```
Switch# configure terminal
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# no qos trust
Switch(config-if)#
Switch# show qos interface GigabitEthernet 1
Port | QoS | Trust State | Remark Coe | Remark DSCP | Remark IP Prece
-----|-----|-----|-----|-----|-----
gi1 | 0 | enabled | enabled | enabled | enabled |
```

25.8 SHOW QOS

Use “**show qos**” command to show qos state and trust type.

Switch#**show qos**

Syntax **show qos**

Mode Privileged EXEC

This example shows how to check current qos mode.

ExampleSwitch# **show qos**

```
Switch# show qos
QoS Mode: basic
Queue Size: 4096
```

25.9 SHOW QOS INTERFACE

Use “**show qos interfaces**” command to show port default cos, remarking state and remarking type state information.

Switch#**show qos interface** *{IF_PORTS}*

Syntax **show qos interface** *{IF_PORTS}*

Parameter *{IF_PORTS}* Select port to show qos

configurations Mode Privileged EXEC

This example shows how to show qos configurations on interface gi1.

Examp^l Switch# **show qos interface** GigabitEthernet 1
e

```
Switch# show qos interface GigabitEthernet 1
Port | QoS | Trans State | Remark Cos | Remark DSCP | Remark IP Preced
-----|-----|-----|-----|-----|-----
gi1 | 1 | disabled | enabled | enabled | disabled |
Switch#
```

25.10 SHOW QOS MAP

Use “**show qos map**” command to show all kinds of mapping for qos remapping and remarking features.

Switch#**show qos map [(cos-queue | dscp-queue | precedence-queue | queue-cos | queue-dscp | queue- precedence)]**

Syntax **show qos map [(cos-queue | dscp-queue | precedence-queue | queue-cos | queue-dscp | queue-precedence)]**

cos-queue Show CoS to queue map.

Parameter

dscp-queue Show DSCP to queue map. precedence-queue Show IP Precedence to queue map. queue-cos Show queue to CoS map.

queue-dscp Show queue to DSCP map.

queue-precedence Show queue to IP Precedence map.

Mode Privileged EXEC

This example shows how to show all qos maps.

Switch# **show qos map**

Example

```
Switch# show qos map
Cos to Queue mappings
-----
Cos      0  1  2  3  4  5  6  7
Queue    1  2  3  4  5  6  1  1

DSCP to Queue mappings
-----
DSCP     0  1  2  3  4  5  6  7  8  9
-----
0:      1  1  1  1  1  1  1  1  2  2
1:      2  2  2  2  2  3  3  3  3
2:      3  3  3  3  4  4  4  4  4  4
3:      4  4  5  5  5  5  5  5  5  5
4:      4  4  4  4  4  4  4  4  7  7
5:      7  7  7  7  7  8  8  8  8  8
6:      8  8  8  8

IP Precedence to Queue mappings
-----
IP Precedence  0  1  2  3  4  5  6  7
Queue          1  2  3  4  5  6  7  8

Queue to Cos mappings
-----
Queue          1  2  3  4  5  6  7  8
Cos            0  1  2  7  7  5  6  7

Queue to DSCP mappings
-----
Queue          1  2  3  4  5  6  7  8
DSCP           0  4  14  24  32  40  48  56

Queue to IP Precedence mappings
-----
Queue          1  2  3  4  5  6  7  8
IP Precedence  0  1  2  3  4  5  6  7

Applied
Switch#
```

25.11 SHOW QOS QUEUEING

Use “show qos queueing” command to show qos queueing information.

Switch#show qos queueing

Syntax show qos queueing

Mode Privileged EXEC

This example shows how to check current qos queueing information.

Example Switch# show qos queueing

```
Switch# show qos queueing
qid-weights  EF - Priority
1 - 5        dia- N/A
2 - 10       dia- N/A
3 - 15       dia- N/A
4 - 20       dia- N/A
5 - 25       dia- N/A
6 - N/A      ena- 6
7 - N/A      ena- 7
8 - N/A      ena- 8
Switch#
```

RATE LIMIT

Rate-limiting for all traffic operates on a per-port basis to allow only the specified bandwidth to be used for inbound or outbound traffic. When traffic exceeds the configured limit, it is dropped. This effectively sets a usage level on a given port and is a tool for enforcing maximum service level commitments granted to network users. This feature operates on a per-port level and is not configurable on port trunks. Rate-limiting is designed to be applied at the network edge to limit traffic from non-critical users or to enforce service agreements such as those offered by Internet Service Providers (ISPs) to provide only the bandwidth for which a customer has paid.




Fig 26.1 Leaky bucket Model

All traffic rate-limiting, Rate-limiting for all traffic operates on a per-port basis to allow only the specified bandwidth to be used for inbound or outbound traffic. When traffic exceeds the configured limit, it is dropped. This effectively sets a usage level on a given port and is a tool for enforcing maximum service level commitments granted to network users. This feature operates on a per-port level and is not configurable on port trunks. Rate-limiting is designed to be applied at the network edge to limit traffic from non-critical users or to enforce service agreements such as those offered by Internet Service Providers (ISPs) to provide only the bandwidth for which a customer has paid.

Uses:-

1. Rate-limiting can be applied by a RADIUS server during an authentication client session. Applying rate-limiting to desirable traffic is not recommended.
2. The switches also support ICMP rate-limiting to mitigate the effects of certain ICMP-based attacks. ICMP traffic is necessary for network routing functions. For this reason, blocking all ICMP traffic is not recommended.




Fig 26.2 Rate limiting on Aggregation Layer

26.1 RATE LIMIT EGRESS

Use the “**rate-limit egress**” command to configure the egress port shaper. Use the “**no**” form of this command to disable the shaper. You can verify your setting by entering the show running-config interfaces command.

```
Switch# configure terminal
```

```
Switch(config)# interface { Interface-ID}
```

```
Switch(config-if)#rate-limit egress <16-
```

```
1000000> Switch(config-if)#no rate-limit
```

```
egress
```

```
rate-limit egress <16-
```

Synta

```
x 1000000> no rate-limit egress
```

Parameter<16-1000000> Specify the committed

information rate. Default Default rate limit is disabled.

Mode Interface configuration

The following example shows how to configure ingress port rate limit and egress port shaper.

```
Switch# configure terminal
```

```
Switch(config)# interface gi1
```

```
Switch(config-if)# rate-limit egress
```

```
Example  
e 2048
```

```
Switch# show running-config interfaces gi1
```


Use the “**rate-limit ingress**” command to limit the incoming traffic rate on a port. Use the “**no**” form of this command to disable the rate limit. You can verify your setting by entering the `show running-config interfaces` command.

```
Switch# configure terminal
```

```
Switch(config)# interface { Interface-ID}
```

```
Switch(config-if)#rate-limit ingress<16-
```

```
1000000> Switch(config-if)#no rate-limit
```

```
ingress
```


RMON

Syntax **show rmon history** (<1-65535>|all)

Parameter <1-65535> specifies history index to show all Show all existed history

Mode Privileged EXEC

The example shows how to show RMON history entry.

```
switch(config)# rmon history 1 interface gi1 interval 30  
owner admin
```

Example switch# **show rmon history 1**



```
switch(config)# rmon history 1 interface gi1 interval 30 owner admin  
switch(config)#  
switch# show rmon history 1  
Rmon History Index : 1  
Rmon Collection Interface: gi1  
Rmon History Bucket : 50  
Rmon History Interval : 30  
Rmon History Owner : admin
```

27.10 SHOW RMON HISTORY STATISTIC

Use the show rmon history statistic command to show statistics that are recorded by

RMON history. Switch #**show rmon history <1-65535>statistic**

Syntax show rmon history <1-65535>statistic

Parameter <1-65535> specifies history index to show history statistic

Mode Privileged EXEC

The example shows how to show RMON history

Example statistics switch# **show rmon history 1 statistics**

```
Switch# show rmon history 1 statistic
```

SNMP

Simple Network Management Protocol (*SNMP*) is an Internet Standard protocol for collecting and organizing information about managed devices on IP networks and for modifying that information to change device behavior.

SNMP has been defined with four major functional areas to support the core function of allowing managers to manage agents:

Data Definition—The syntax conventions for how to define the data to an agent or manager. These specifications are called the Structure of Management Information (SMI).

MIBs—Over 100 Internet standards define different MIBs, each for a different technology area, with countless vendor-proprietary MIBs as well. The MIB definitions conform to the appropriate SMI version.

Protocols—The messages used by agents and managers to exchange management data.

Security and Administration—Definitions for how to secure the exchange of data between agents and managers.

Understanding SNMP



Fig 28.1 SNMP concept

SNMP Version

v1, -simple authentication with communities, but used MIB-I originally.

v2 Uses SMIv2, removed requirement for communities, added Get Bulk and Inform messages, but began with MIB-II originally. 2c Pseudo-release (RFC 1905) that allowed SNMPv1-style communities with SNMPv2; otherwise, equivalent to SNMPv2.

v3 Mostly identical to SNMPv2, but adds significantly better security, although it supports communities for backward compatibility. Uses MIB-II.




Fig 28.2 SNMP Community concept

28.1 SHOW SNMP

To show the status of Simple Network Management Protocol (SNMP), use the command `show snmp` in the Privileged EXEC mode.

Switch# **show snmp**

Syntax **show snmp**

Mode Privileged EXEC

The following example shows the SNMP status.

ExampleSwitch# **show snmp**

```
Switch# show snmp
SNMP is enabled.
```

28.2 SHOW SNMP COMMUNITY

To show the configuration of snmp communities, use the command `show snmp community` in the Privileged EXEC mode.

```
Switch# show snmp
```

```
community Syntax show
```

```
snmp community Mode
```

Privileged EXEC

The following example shows the SNMP communities configuration.

```
ExampleSwitch# show snmp community
```

```
Switch# show snmp community
Community Name      Group Name      View
-----
public              co              all
Total Entries: 1
```

28.3 SHOW SNMP ENGINEID

To show the SNMPv3 engine IDs defined on the switch, use the command `show snmp engine id` in the Privileged EXEC mode.

Syntax `show snmp engine id`

Mode Privileged EXEC

The following example shows the SNMP engine id information.

ExampleSwitch# `show snmp engineid`

```
Switch# show snmp engineid
Local SNMP3 Engine id: 8006a22030e4c000000
-----
IP address           Remote SNMP engineID
-----
Total Entries: 0
```

28.4 SHOW SNMP GROUP

To show the SNMP group configuration on the switch, use the command `show snmp group` in the Privileged EXEC mode.

```
Switch# show snmp
```

```
group Syntax show
```

```
snmp group Mode
```

Privileged EXEC

The following example shows the SNMP group configuration.

Example `Switch# show snmp group`



28.6 SHOW SNMP TRAP

To show the status of SNMP traps on the switch, use the command `show snmp trap` in the Privileged EXEC mode.

Switch#**show snmp**

trap Syntax **show**

snmp trap Mode

Privileged EXEC

The following example shows the status of SNMP traps.

Example Switch# **show snmp trap**

```
Switch# show snmp trap
```

28.7 SHOW SNMP VIEW

To show the SNMP view defined on the switch, use the command `show snmp view` in the Privileged EXEC mode.

```
Switch# show snmp
```

```
view Syntax show
```

```
snmp view Mode
```

Privileged EXEC

The following example shows the configuration of SNMP view.

```
ExampleSwitch# show snmp view
```



View Name	MIBs	View Type
all	all	readwrite

28.8 SHOW SNMP USER

To show the SNMP users defined on the switch, use the command `show snmp user` in the Privileged EXEC mode.

```
Switch# show snmp
```

```
user Syntax show
```

```
snmp user Mode
```

Privileged EXEC

The following example shows the configuration of SNMP user.

Example
Switch# show snmp user

```
Switch# show snmp user  
Total Entries: 0
```

28.9 SNMP

To enable the SNMP on the switch, use the command `snmp` in the Global Configuration mode. Otherwise, use the “**no**” form of the command to disable to SNMP.

```
Switch# configure terminal
```

```
Switch(config)# snmp
```

Syntax `snmp`

Default SNMP is disabled by

default Mode Global

Configuration

The following example enables the SNMP.

Example

```
Switch# configure terminal  
Switch(config)# snmp
```



28.10 SNMP COMMUNITY

To define the SNMP community that permit access for SNMP v1 and v2, use the command `snmp community` in the Global Configuration mode.

```
Switch# configure terminal
```

```
Switch(config)#snmp community community-name [view view-name]
```

```
(ro|rw) Switch(config)#snmp community community-name group group-
```

```
name Switch(config)#no snmp community community-name
```

```
snmp community community-name [view view-name] (ro|rw)
```

Syntax `snmp community community-name group group-name`

X

```
no snmp community community-name
```

community-name The SNMP community name. Its maximum length is 20 characters.

view view-name Specify the SNMP view configured by the command `snmp view` to define the object available to the community.

Parameter **ro** Read only access (default)

rw Writable access

group group-name Specify the SNMP group configured by the command

`snmp group` to define the object available to the community.

Mode Global Configuration


The following example defines the SNMP community named `private` with the default view `all`, and the access right is read-only.

```
Switch# configure terminal
```

Example

e

```
Switch(config)# snmp community private ro
```



```
Switch# configure terminal
Switch(config)# snmp community private ro
Switch# show snmp community
Community Name: private
Group Name: all
Access: ro
View: all
```

28.11 SNMP ENGINEID

To define the SNMP engine on the switch, use the command `snmp engineid` in the Global Configuration mode.

Switch# **configure terminal**

Switch(config)# **snmp engineid 00036D001122**

Syntax **Snmp engineid (default|ENGINEID)**

default Default engine ID generated on the basis of the switch MAC address.

Parameter **ENGINEID** Specify SNMP engine ID. The engine ID is the 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.

Default The default SNMP engine ID on the switch is based on switch MAC

address. Mode Global Configuration

The following example configure the switch SNMP

engine ID Switch# **configure terminal**

Example Switch(config)# **snmp engineid 00036D001122**

```
Switch# configure terminal
Switch(config)# snmp engineid 00036D001122
Switch(config)#
Switch# snmp engineid
Local SNMP Engine ID: 00036D001122

IP address:          Remote SNMP engineID:
-----
Local Engine ID:
```

28.12 SNMP ENGINEID RMOTE

To define the remote host for SNMP engine, use the command `snmp engineid remote` in the Global Configuration mode and use the “**no**” form of the command to delete the remote host from the SNMP engine.

```
Switch# configure terminal
```

```
Switch(config)# snmp engineid remote (ip-addr|ipv6-addr) [ENGINEID]
```

```
Switch(config)# no snmp engineid remote (ip-addr|ipv6-addr)
```

Syntax `snmp engineid remote (ip-addr|ipv6-addr) ENGINEID`

`no snmp engineid remote (ip-addr|ipv6-addr)`

ENGINEID Specify SNMP engine ID. The engine ID is a 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.

Parameter `ip-addr` IP address of the remote host

`ipv6-addr` IPv6 address of the remote host

Mode Global Configuration

The following example adds the remote 192.168.1.11 into SNMP

```
engine Switch# configure terminal
```

Example `Switch(config)# snmp engineid remote 192.168.1.1 100036D10000A`



```
Switch# configure terminal
Switch(config)# snmp engineid remote 192.168.1.1 100036D10000A
Switch(config)#
```

28.13 SNMP GROUP

To define the SNMP group, use the command `snmp group` in the Global Configuration mode, and use the “**no**” form of the command to delete the configuration. SNMP group configuration is used in the command `snmp user` to map SNMP users to the SNMP group. These users would be automatically mapped to the SNMP views defined in this command. The security level for SNMP v1 or v2 is always `noauth`.

Switch# **configure terminal**

Switch(config)# **snmp group group-name (1|2c|3) (noauth|auth|priv) read-view read-view write-view write-view [notify-view notify-view]**

Switch(config)# **no snmp group group-name security-mode version (1|2c|3)**

snmp group group-name (1|2c|3) (noauth|auth|priv) read-view read-view write-view write-view [notify-view notify-view]

Syntax
x

no snmp group group-name security-mode version (1|2c|3)

group-name Specify SNMP group name, and the maximum length is 30 characters. (1|2c|3) Specify the SNMP version.

noauth Specify that no packet authentication is performed.

auth Specify that no packet authentication without encryption is performed. It is applicable only to the SNMPv3 security mode.

priv Specify that no packet authentication with encryption is performed. It is applicable only to the SNMPv3 security mode.

Parameter

read-view read-view Set the view name that enables configuring the agent, and its maximum length is 30 characters.

write-view write-view Set the view name that enables viewing only, and its maximum length is 30 characters.

notify-view notify-view Sets the view name that sends only traps with contents that is included in SNMP view selected for notification.

The maximum length is 30 characters.

Mode Global Configuration

The following example adds SNMPv3

group Switch# **configure terminal**

Examp
le

Switch(config)# **snmp group v3 version 3 auth read-**

view all write-view all notify-view all

```
Switch(config)# snmp group v3 version 3 auth read-view all write-view all notify-view all
Switch(config)# exit
Switch# show snmp
Group Name      Auth  Priv  Notify  ReadView  WriteView
-----
v3              yes   yes   yes     all       all
v3              no    no    no      --        --
v3              no    no    no      --        --
Total Groups: 3
```

28.14 SNMP HOST

To configure the hosts to receive SNMP notifications, use the command `snmp host` in the Global Configuration mode and use the “**no**” form of the command to delete the configuration.

```
Switch# configure terminal
```

```
Switch(config)# snmp host (ip-addr|ipv6-addr|hostmane) [traps|informs] [version (1|2c)]  
community- name [udp-port udp-port] [timeout timeout] [retries retries]
```

```
Switch(config)# snmp host (ip-addr|ipv6-addr|hostmane) [traps|informs] version 3
```

```
[(auth|noauth|priv)] community-name [udp-port udp-port] [timeout
```

```
timeout] [retries retries]
```

```
Switch(config)# no snmp host (ip-addr|ipv6-addr|hostmane) [traps|informs] [version (1|2c|3)]
```

```
Synta  
x      snmp host (ip-addr|ipv6-addr|hostmane) [traps|informs] [version (1|2c)] community-  
name [udp-port udp-port] [timeout timeout] [retries retries] snmp host (ip-addr|ipv6-  
addr|hostmane) [traps|informs] version 3 [(auth|noauth|priv)] community-name [udp-  
port udp-port] [timeout timeout] [retries retries]
```

```
no snmp host (ip-addr|ipv6-addr|hostmane) [traps|informs] [version (1|2c|3)]
```

	ip-addr The IP address of recipient.
	ipv6-addr The IPv6 address of recipient.
	hostname The host name of recipient.
	traps Send SNMP traps to the host. It is the default action.
	informs Send SNMP informs to the host.
	version (1 2c 3) Specify the SNMP version.
Parameter	noauth Specify that no packet authentication is performed. It is applicable only to the SNMPv3 security mode.
	auth Specify that no packet authentication without encryption is performed. It is applicable only to the SNMPv3 security mode.
	priv Specify that no packet authentication with encryption is performed. It is applicable only to the SNMPv3 security mode.
	community-name The SNMP community sent with the notification.
	udp-port Specify the UDP port number.
	timeout Specify the SNMP informs timeout.
	retries Specify the retry counter of the SNMP informs.
Default	The default SNMP version for the command is SNMPv1.
Mode	Global Configuration

The following example adds the recipient 192.168.1.11 for the SNMP traps notification.

Example Switch# configure terminal

e

Switch(config)# snmp host 192.168.1.11 private

```
Switch# configure terminal
Switch# configure terminal
Switch(config)# snmp host 192.168.1.11 private
Switch(config)#
Switch# show snmp host

```

Host	Community	Trap Base	Notification Prio	Notification Type	UDP Port	Version	Timeout
192.168.1.11	private	0	trap	0	-	-	-

```
End of show
```

28.15 SNMP TRAP

To send the SNMP traps, use the command `snmp trap` in the Global Configuration mode and use the “no” form of the command to disable the SNMP

traps. Switch# **configure terminal**

Switch(config)# **snmp trap (auth|cold-start|linkUpDown|port-security|warm-start)**

Switch(config)# **no snmp trap (auth|cold-start|linkUpDown|port-security |warm-start)**

Synta
x **snmp trap (auth|cold-start|linkUpDown|port-security|warm-start)**
no snmp trap (auth|cold-start|linkUpDown|port-security |warm-start)

auth Enable the SNMP authentication failure trap.

cold-start Enable the SNMP cold start-up failure trap.

Parameter**linkUpDown** Enable the SNMP link up and down failure trap.

port-security Enable the SNMP port security trap.

warm-start Enable the SNMP warm start-up failure trap.

Default All the SNMP traps are

enabled Mode Global

Configuration

The following example disables and enables the SNMP link up and down traps individually.

Switch# **configure terminal**

Examp
e Switch(config)# **snmp trap linkUpDown**

```
Switch# configure terminal
Switch(config)# snmp trap linkUpDown
Switch(config)#
Switch# en snmp trap
SNMP auth failed trap : Enable
SNMP linkdown trap : Enable
SNMP cold-start trap : Enable
SNMP warm-start trap : Enable
```

28.16 SNMP USER

To define a SNMP user, use the command `snmp user` in the GlobalConfiguration mode and use the “no”

form to delete the SNMP user.

Switch# **configure terminal**

```
Switch(config)# snmp user username group-name [auth (md5|sha) AUTHPASSWD] snmp user username group-name auth (md5|sha) AUTHPASSWD priv PRIVPASSWD
```

```
Switch(config)# no snmp user username
```

Syntax
X

```
snmp user username group-name [auth (md5|sha) AUTHPASSWD] snmp user username group-name auth (md5|sha) AUTHPASSWD priv PRIVPASSWD  
no snmp user username
```

Parameter

username Specify the SNMP user name on the host that connects to the SNMP agent. The max character is 30 characters. For the SNMP v1 or v2c, the user name must match the community name by the command snmp host.

group-name Specify the SNMP group to which the SNMP user belongs. The SNMP group should be SNMPv3 and configured by the command snmp group.

auth (md5|) Specify the HMAC-MD5-96 authentication protocol as the user authentication.

auth (sha|) Specify the HMAC-SHA-96 authentication protocol as the user authentication.

AUTHPASSWD The password for authentication and the range of length is from 8 to 32 characters.

Priv PRIVPASSWD The private password for the privacy key, and the range of length is from 8 to 64 characters

Mode Global Configuration

The following example adds SNMP user v3 into the group v3 by the MD5 authentication. Switch# **configure terminal**

Example
e

```
Switch(config)# snmp user v3 v3 auth md5 12345678
```



```
Switch(config)# snmp user v3 v3 auth md5 12345678
Switch(config)# exit
Switch# show snmp user
Username: v3
Access: *****
Privilege Mode: sp
Access Group: v3
Authentication Protocol: md5
Encryption Protocol: none
Access Protocol: auth
Total Entries: 1
```

28.17 SNMP VIEW

To configure the SNMP view, use the command `snmp view` in the Global Configuration mode and use the “**no**” form of the command to delete the SNMP view. The default SNMP view cannot be deleted and modified by users. By default, the maximum numbers of SNMP view is limited to 16.

Switch# **configure terminal**

Switch(config)# **snmp view view-name subtreeoid-tree oid-mask (all|oid-mask) viewtype(included|excluded)**

Switch(config)# **no snmp view view-name subtree (all|oid-tree)**

Syntax

```
snmp view view-name subtreeoid-tree oid-mask (all|oid-mask)
viewtype(included|excluded)
no snmp view view-name subtree (all|oid-tree)
```

view-name The SNMP view name. Its maximum length is 30 characters.

subtreeoid-tree Specify the ASN.1 subtree object identifier (OID) to be included or excluded from the SNMP view.

Parameter

oid-mask (all|oid-mask) Specify the OID family mask. It is used to define a family of view subtrees. For example, OID mask FA.80 is 11111010.10000000. The length of the OID mask must be less than the length of subtreeOID. Viewtype

(included|excluded) Include or exclude the selected MIBs in the view.


Mode Global Configuration

The following example defines the SNMP view.

Switch# **configure terminal**

Example

```
Switch(config)# snmp view private subtree 1.3.3.1 oid-mask all viewtype included
```



```
Switch# configure terminal
Switch(config)# snmp view private subtree 1.3.3.1 oid-mask all viewtype included
Switch(config)#
Switch# show snmp view
View Name      Subtree OID      OID Mask      View Type
-----
all            1                all           included
private       1.3.3.1          all           included
Switch#
```

SPANNING TREE

Syntax **revision rev**
x no revision

Parameter **rev** The MSTP revision number. Its valid range is from 0 to

65535 Default The default revision number is 0.

Mode MST Configuration

The following example defines the revision MSTP configuration to 1.

Switch#**configure terminal**

Switch(config)# **spanning-tree mst configuration**

Example Switch(config-mst)# **revision 1**

Switch# **show spanning-tree mst configuration**

```
Switch# configure terminal
Switch(config)# spanning-tree mst configuration
Switch(config-mst)# revision 1
Switch(config-mst)#
Switch# show spanning-tree mst configuration
Name [test]
Revision 1 Instances configured 9
-----
Instance Vlans mapped
0 1-9,21-99,101-8094
1 10-20
2 100
```

29.4 SHOW SPANNING-TREE

To display the spanning tree configuration, use the command **show spanning-tree** in the Privileged EXEC

mode. Switch# **show spanning-tree**

Syntax **show spanning-tree**

Mode Privileged EXEC

The following example shows the spanning tree configuration.

Example Switch# show spanning-tree

```
Switch# show spanning-tree
Spanning tree disabled (BPDU Flooding) mode RSTP
Default port cost method: long
```

29.5 SHOW SPANNING-TREE INTERFACE

To show the STP configuration and statistics for an interface, use the command `show spanning-tree interface` in the Privileged EXEC mode.

Switch# **show spanning-tree interfaces gi1**

Syntax **show spanning-tree interface** *{IF_PORTS}* **[statistic]**

interface *IF_PORTS* An interface ID or the list of interface IDs.

Parameter **statistic** Display the STP statistic for an interface.

Mode Privileged EXEC

The following example shows the STP configuration for the interface gi23.

Example Switch# **show spanning-tree interfaces gi1**

```
Switch# show spanning-tree interfaces gi1
Spanning tree disabled
Switch#
```

29.6 SHOW SPANNING-TREE MST

To show the information for a specific MSTP instance, use the command `show spanning-tree mst` in the Privileged EXEC mode.

Switch# `show spanning-tree mst 0`

Syntax `show spanning-tree mst instance-id`

Parameter `instance-id` The MSTP instance ID. Its valid range is from 0

to 15. Mode Privileged EXEC

The following example displays the information for the MSTP instance 0 and 1

individually. Switch# `show spanning-tree mst 0`

Example

```
Switch# show spanning-tree mst 0
MST Instance Information
-----
Instance Type : CIST (0)
Bridge Identifier : 32768/0/00:00:00:00:00:00
-----
Designated Root Bridge : 0/0/00:00:00:00:00:00
External Root Path Cost : 0
Regional Root Bridge : 0/0/00:00:00:00:00:00
Internal Root Path Cost : 0
Designated Bridge : 0/0/00:00:00:00:00:00
Root Cost : 0/0
Max Age : 0
Forward Delay : 0
Topology Change : 0
Last Topology Change : 0
-----
VLANs mapped: 1-9,21-99,101-4094
-----
Interface      Role  Prio Cost      Prio-Abc  Type
-----
Gi2/1          DesG  Prio 20000    128.21  P2P (RSTP)
Gi2/3          DesG  Prio 20000    128.23  P2P (RSTP)
Gi2/24         DesG  Prio 20000    128.24  P2P (RSTP)
```

29.7 SHOW SPANNING-TREE MST CONFIGURATION

To show the global MST configuration, use the command `show spanning-tree mst configuration` in the Privileged EXEC mode.

```
Switch# show spanning-tree mst
```

configuration Syntax `show spanning-tree`

mst configuration Mode Privileged EXEC

The following example shows the global MST configuration.

Example `Switch# show spanning-tree mst configuration`

```
Switch# show spanning-tree mst configuration
Name: [test]
Revision: 2    Instances configured: 3
-----
Instance: Vlans mapped
-----
0          1-9,21-99,101-1094
1          10-20
2          100
```

29.8 SHOW SPANNING-TREE MST INTERFACE

To show the MSTP instance information on the specific interface, use the command `show spanning-tree mst interface` in the Privileged EXEC mode.

Switch# `show spanning-tree mst instance-id interface {IF_PORTS}`

Syntax `show spanning-tree mst instance-id interface {IF_PORTS}`

instance-id The MSTP instance ID. Its valid range is from 0 to 15.
Parameter **Interface** *IF_PORTS* An interface ID or the list of interface IDs.

Mode Privileged EXEC

The following example shows the MSTP 0 and 1 information individually on the interface `gi1`.

Switch# `show spanning-tree mst 0 interfaces gi1`

Example

```
Switch# show spanning-tree mst 0 interfaces gi1
MST Root Information
-----
Instance Type : CST (0)
-----
Port Identifier : 128/1
External Path-Cost : 0 /20000
Internal Path-Cost : 0 /20000
-----
Designated Root Bridge : 0/00:00:00:00:00:00
External Root Cost : 0
Regional Root Bridge : 0/00:00:00:00:00:00
Internal Root Cost : 0
Designated Bridge : 0/00:00:00:00:00:00
Internal Port Path Cost : 20000
Port Role : Disabled
Port State : Disabled
-----
```


loops are then removed by shutting down selected bridge interfaces and placing redundant switch ports in a backup, or blocked, state.

To configure the action of Bridge Protocol Data Unit (BPDU) handling when STP is disabled, use the command `spanning-tree bpdudisable` in the Global Configuration mode. To restore the configuration to the default action, use the `no` form of the command.

Switch#**configure terminal**

Switch(config)# **spanning-tree bpdu (filtering|flooding)**

Switch(config)# **no spanning-tree bpdu**

spanning-tree bpdu

Synta

x **(filtering|flooding) no spanning-tree**

bpdu

filtering Filter the BPDU when STP is disabled.

Paramet

er **flooding** Flood the BPDU when the STP is disabled.

Default The default configuration is

flooding. Mode Global Configuration

The following example configures the action of BPDU handling to filter when the STP is disabled.

Examp Switch#**configure terminal**

e Switch(config)# **spanning-tree bpdu filtering**

```
Switch# configure terminal
Switch(config)# spanning-tree bpdu filtering
```

29.11 SPANNING-TREE BPDU-FILTER

To enable the BPDU filter, use the command `spanning-tree bpdu-filter` in the Interface Configuration mode; and use “**no**” form of the command to disable the BPDU filter.

```
Switch#configure terminal
```

```
Switch(config)# interface {Interfac-ID}
```

```
Switch(config-if)# spanning-tree bpdu-filter
```

```
Switch(config-if)# no spanning-tree bpdu-  
filter
```

```
spanning-tree bpdu-filter
```

Synta

```
x no spanning-tree bpdu-filter
```

Default BPDU filter is

disabled. Mode Interface

Configuration

The following example enables the BPDU filter for interface GigabitEthernet 1.

```
Switch#configure terminal
```

```
Example Switch(config)# interface
```

```
GigabitEthernet 1 Switch(config-if)#
```

```
spanning-tree bpdu-filter
```

```
Switch# configure terminal  
Switch(config)# int g1  
Switch(config-if)# spanning-tree bpdu-filter
```

29.12 SPANNING-TREE BPDU-GUARD

To enable the BPDU filter, use the command `spanning-tree bpdu-guard` in the Interface Configuration mode and use `no` form of the command to disable the BPDU filter.

```
Switch#configure terminal
```

```
Switch(config)# interface {Interfac-ID}
```

```
Switch(config-if)# spanning-tree bpdu-guard
```

```
Switch(config-if)# no spanning-tree bpdu-  
guard
```

```
spanning-tree bpdu-guard
```

Synta

```
x no spanning-tree bpdu-guard
```

Default BPDU guard is

disabled Mode Interface

Configuration

The following example enables the BPDU guard for interface gi1.

```
Switch#configure terminal
```

Example Switch(config)# interface GigabitEthernet

```
1 Switch(config-if)# spanning-tree bpdu-
```

```
guard
```

```
Switch#configure terminal  
Switch(config)# int g1  
Switch(config-if)# spanning-tree bpdu-guard
```

29.13 SPANNING-TREE COST

To configure the STP path cost for an interface, use the command `spanning-tree cost` in the Interface Configuration mode; and use the `no` form of the command to restore it to the default configuration.

Default setting are as follows:-

Interface Speed	STP Cost
10 Mbps	100
100 Mbps	19
1 Gbps	4
10 Gbps	2

Fig 29.6 STP costs

```
Switch#configure terminal
```

```
Switch(config)# interface {Interfac-ID}
```

```
Switch(config-if)# spanning-tree cost
```

```
{cost}Switch(config-if)# no spanning-tree
```

```
cost {cost}
```

spanning-tree cost {cost}

Syntax

no spanning-tree cost {cost}

Parameter *Cost* The port path cost. For the long path cost method, its valid range is from 0 to 200000000; and the valid range is from 0 to 65535 for the short path cost method. The value 0 indicates AUTO, which the port path cost is determined by the port speed and the path cost method.

The default port path cost is 0, and it is determined by the port speed and the path cost method (long or short).

Interface	Long	Short
Gigabit Ethernet (1000Mbps)	20000	4
Fast Ethernet (100Mbps)	200000	19
Ethernet (10Mbps)	200000	100
	0	

Mode Interface Configuration

The following example configures port path cost to 30000 for interface gi2.

Switch#configure terminal

Example Switch(config)# **interface gi1**

e

Switch(config-if)# **spanning-tree cost 30000**

```
Switch#configure terminal
Switch(config)# int gi1
Switch(config-if)# spanning-tree cost 30000
```

29.14 SPANNING-TREE FORWARD-DELAY

To configure the STP bridge forward delay time, which is the amount of time that a port remains in the Listening and Learning states before it enters the Forwarding state, use the command `spanning-tree forward-time` in the Global Configuration mode. To restore it to the default configuration, use the **“no” form** of the command.

When the forward delay time is configured, the following relationship should be

maintained: $2 * (\text{forward-time} - 1) \geq \text{Max-Age}$

Timer	Default Value	Description
Hello	2 Seconds	How often will a BPDU be sent
Max Age	20 Seconds (10 x Hello Time)	How long will a port remain in Blocking state after a topology change
Forward Delay	15 Seconds	How long will a port remain in Listening/Learning states, before transitioning to Forwarding state. (15secs each by default, 30secs total)

Fig 29.7 Spanning Tree Default Timer

Switch#configure terminal

Switch(config)# `spanning-tree forward-delay {seconds}`

Switch(config)# `no spanning-tree forward-time {seconds}`

`spanning-tree forward-delay {seconds}`

Syntax

x `no spanning-tree forward-delay {seconds}`

Parameter *seconds* STP forward delay time. Its valid range is from 4 to 10 seconds.

Default The default forward delay time is 15

seconds. Mode Global Configuration

The following example configures STP forward delay time to 25.

Switch#configure terminal

Switch(config)# spanning-tree forward-delay 25

Switch# show spanning-tree mst 0

Example

```
Switch# configure terminal
Switch(config)# spanning-tree forward-delay 25
Switch(config)#
Switch# show spanning-tree mst 0

MST Instance Information
-----
Instance Type : CST (0)
Bridge Identifier : 32768/ 0/00:E0:4C:00:00:00
-----
Designated Root Bridge : 32768/ 0/00:E0:4C:00:00:00
External Root Path Cost : 0
Regional Root Bridge : 32768/ 0/00:E0:4C:00:00:00
Internal Root Path Cost : 0
Designated Bridge : 32768/ 0/00:E0:4C:00:00:00
Root Port : 0/0
Max Age : 20
Forward Delay : 25
Topology Changes : 3
Last Topology Change : 18025
-----
VLANs mapped: 1-9,21-99,101-4094

Interface      Role  Sts  Cost      Prio.Pbr  Type
-----
Ea01           Desg  FWD  20000     128.25    P2P (RSTP)
```

29.15 SPANNING-TREE HELLO-TIME

STP hello time is the time interval to broadcast its hello message to other bridges. To configure the STP hello time, use the command `spanning-tree hello-time` in the Global Configuration mode; and use the “no” form of the command to restore the hello time to default configuration.

When the hello time is configured, the following relationship should be maintained: $\text{Max-Age} \geq 2 * (\text{hello-time} + 1)$

```
Switch#configure terminal
```

```
Switch(config)# spanning-tree hello-time seconds
```

```
Switch(config)# no spanning-tree hello-time
```

```
spanning-tree hello-time
Syntax
x seconds no spanning-tree
hello-time
```

```
Parameter seconds STP hello time in second. Its valid range is from
1 to 10seconds
```

```
Default The default STP hello time is 2
```

```
seconds. Mode Global Configuration
```

The following example configures BPDU hello time to 4.

```
Switch#configure terminal
Switch(config)# spanning-tree hello-time 4
```

```
Switch#configure terminal
Switch(config)# spanning-tree hello-time 4
```


29.17 SPANNING-TREE LINK-TYPE

To set the RSTP link-type for an interface, use the command `spanning-tree link` in the Interface Configuration mode. For the default configuration, use the “no” form of the command.

```
Switch#configure terminal
```

```
Switch(config)# interface {Interface-ID}
```

```
Switch(config-if)# spanning-tree link-type (point-to-point|shared)
```

```
Switch(config-if)# no spanning-tree link-type(point-to-point|shared)
```

Syntax	<code>spanning-tree link-type (point-to-point shared)</code>
x	<code>no spanning-tree link-type(point-to-point shared)</code>
Parameter	<code>point-to-point</code> Specify the port link type is point to point. <code>shared</code> Specify the port link type is shared.
Default	The default configuration link type is point-to-point for the ports with full duplex configuration, and shared for the ports with half duplex settings.
Mode	Interface Configuration

The following example configures the link-type to point-to-point for the interface GigabitEthernet 1.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 1
```

```
Switch(config-if)# spanning-tree link-type point-to-point
```

```
Switch#show spanning-tree interface GigabitEthernet 1
Spanning tree enabled
Port 1 is 1281
Type 101 (STP)
Bridge ID Priority 0
MAC Address 000c.0000.0000
STP Filter Enabled
STP Guard Disabled
```

29.18 SPANNING-TREE MAX-HOPS

To specify the number of hops for a BPDU to be forwarded in the MSTP region, use the command `spanning- tree max-hops` in the Global Configuration mode and restore the setting to default configuration by the “**no**” form of the command.

Switch#configure terminal

Switch(config)# spanning-tree max-hops {counts}

Switch(config)# no spanning-tree max-hops {counts}

Syntax
x spanning-tree max-hops {counts}
no spanning-tree max-hops {counts}

Parameter *counts* Specify the number of hops in an MSTP region before the BPDU is discarded. The valid range is 1 to 40.

Default The default max-hops configuration

is 20 Mode Global Configuration

The following example specifies the max hops for BPDU to 10.

Switch#configure terminal

Switch(config)# spanning-tree max-hops 10

Example

```
Switch1(config)# spanning-tree max-hops 10
Switch1(config)#
Switch1#show spanning-tree
Spanning tree enabled state: STP
Hello Time: 2 sec Max Age: 20 sec Forward Delay: 15 sec
Number of designated VLANs: 1 (VLANs: default)
Number of root VLANs: 0
Number of VLANs in STP: 1 (VLANs: default)
VLAN: 1, Spanning tree enabled on this VLAN
Configuration:
Name      State      Prio. Num  Cost    Prio.  Role  OperPrnt  Prio.
-----  ---
VLAN0001  Forwarding  32768     4        128    Root  Disabled  32768
VLAN0002  Forwarding  32768     4        128    Root  Disabled  32768
VLAN0003  Forwarding  32768     4        128    Root  Disabled  32768
```

29.19 SPANNING-TREE MAXIMUM-AGE

To set the interval in seconds that the switch can wait without receiving the configuration messages, before attempting to redefine its own configuration, use the command spanning-tree maximum-age in the Global Configuration mode. For the default configuration, use the “no” form of the commands.

When the maximum age is configured, the following relationship should be

maintained: $2 * (\text{forward-time} - 1) \geq \text{Max-Age} \geq 2 * (\text{hello-time} + 1)$

Switch#configure terminal

Switch(config)# spanning-tree maximum-age *{seconds}*

Switch(config)# no spanning-tree maximum-age

Synta	spanning-tree maximum-age <i>{seconds}</i>
x	no spanning-tree maximum-age

Parameter **seconds** The interval in seconds for a switch to wait the configuration messages, without attempting to redefine its own configuration.

Default The default maximum age is 20 seconds.

Mode Global Configuration

The following example configures STP maximum age to 10.

Switch#configure terminal

Switch(config)# spanning-tree maximum-age 10

Example

```
Switch# configure terminal
Switch(config)# spanning-tree maximum-age 10
Switch(config)#
Switch# show spanning-tree

Spanning tree enabled mode STP
Default port cost: 100000000

Root ID    Priority    32768
Address    00001401000000
This bridge is the root
Hello Time  2 sec Max Age 10 sec Forward Delay 20 sec

Number of topology changes 1 last change occurred 05/03/15 age
Times: hold 0, topology change 0, notification 0
Hello 2, max age 10, forward delay 20

Interface
Name      State Prio.Nbr  Cost   Snt  Role EdgePort  Type
-----
1/24    enabled 128.25   20000  Fw  Desg  No STP (SRTS)
```

29.20 SPANNING-TREE MCHECK

To restart the Spanning Tree Protocol (STP) migration process (re-negotiate forcibly with its neighborhood) on the specific interface, use the command `spanning-tree mcheck` in the Interface Configuration mode.

```
Switch#configure terminal
```

```
Switch(config)# interface {Interface-
```

```
ID} Switch(config-if)# spanning-tree
```

```
mcheck
```

Syntax `spanning-tree mcheck`

Mode Interface Configuration

The following example restarts the STP negotiation on the interface `gi1`.

```
Switch#configure terminal
```

Example `Switch(config)# interface GigabitEthernet 1`

```
Switch(config-if)# spanning-tree mcheck
```

```
Switch# configure terminal
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# spanning-tree mcheck
```

29.21 SPANNING-TREE MODE

To specify the spanning tree operation mode, use the command of spanning- tree mode in the Global Configuration mode. For the default configuration, use the command “no” spanning- tree force-version in the Global Configuration mode.

When the switch is configured as MSTP mode, it can use STP and RSTP for the backward compatibility with switches working in STP and RSTP mode individually. For the RSTP configuration, the switch can also use STP for the switches working in the STP operation.

Switch#configure terminal

Switch(config)# spanning-tree mode (mstp|rstp|stp)

Switch(config)# no spanning-tree force-version

spanning-tree mode

Syntax

x (mstp|rstp|stp) no spanning-tree

force-version

mstp Enable the Multiple Spanning Tree (MSTP) operation.

Parameter **rstp** Enable the Rapid Spanning Tree (RSTP) operation.

stp Enable the Spanning Tree (STP) operation.

Default The default mode is

rstp. Mode Global

Configuration

Example

```
Switch#configure terminal
Switch(config)# spanning-tree mode mstp
Switch(config)#
Switch#show spanning-tree

Spanning tree enabled mode: MSTP
Default port cost method: long

Stacking Information .....
##### SW1 0 Vlan0001 192.21.99.101-4094
CPU Model ID Priority 32768
Address C0004C1001001000
This switch is a root for CIST and IST master
Hello Time 4 sec Max Age 10 sec Forward Delay 20 sec
Max Hops 20
Name State Prio.Msti Cost Stp Role EdgePort Type
-----
sw1 enabled 128.29 20000 P2W Damp No P2P Inte
```

T ets the STP operation to MSTP. Switch#**configure terminal**

h Switch(config)# **spanning-tree mode mstp**

e

f

o

l

l

o

w

i

n

g

e

x

a

m

p

l

e

s

29.22 SPANNING-TREE MST CONFIGURATION

To enter the MST configuration mode for the MSTP configuration modification, use the command `spanning-tree mst configuration` in the Global Configuration mode.

```
Switch#configure terminal
```

```
Switch(config)# spanning-tree mst configuration
```

Syntax `spanning-tree mst configuration`

Mode Global Configuration

The following example modifies the MSTP configuration in the MST Configuration mode.

```
Switch#configure terminal
```

```
Switch(config)# spanning-tree mst
```

```
configuration Switch(config-mst)# instance 1
```

Example `vlan 10-20 Switch(config-mst)# name test`

```
Switch(config-mst)# revision 1
```

```
Switch(config)# spanning-tree mst configuration
Switch(config-mst)# instance 1 vlan 10-20
Switch(config-mst)# name test
Switch(config-mst)# revision 1
Switch(config-mst)# end
Switch# show spanning-tree mst configuration
Name      [test]
Revision  1      Instance configured 3
-----
Instance  VLANs mapped
-----
0          1-9,21-99,101-4094
1          10-20
2          100
```

29.23 SPANNING-TREE MST COST

To configure the path cost for MSTP calculations, use the command `spanning-tree mst cost` in the Interface Configuration mode. If the loop occurs, the MSTP considers the path cost when selecting the interface into the Forwarding state. For the default configuration, use the “no” form of the command. When configuring the path cost on the CIST (instance 0), it is equal to the command `spanning-tree cost` in the Interface Configuration mode.

Switch#**configure terminal**

Switch(config)# **interface** {Interface-ID}

Switch(config-if)# **spanning-tree mst instance-id cost** {cost}

Switch(config-if)# **no spanning-tree mst instance-id cost** {cost}

Syntax
x **spanning-tree mst instance-id cost** {cost}
no spanning-tree mst instance-id cost {cost}

instance-id Specify the instance ID. The valid range is from 0 to 15.

Parameter **cost** Specify the path cost for the interfaces on the specific MSTP instance. For the long path cost method, its valid range is from 0 to 200000000; and the valid range is from 0 to 65535 for the short path cost method. The value 0 indicates AUTO, which the port path cost is determined by the port speed and the path cost method.

The default port path cost is 0, and it is determined by the port speed and the path cost method (long or short).

Interface	Long		Short
	Cost	Cost	
Default			
Gigabit Ethernet (1000Mbps)	20000	4	
Fast Ethernet (100Mbps)	200000	19	
Ethernet (10Mbps)	2000000	100	

Interface Configuration

Mode

The following example configures the path cost of interface fa1 on the instance 1 to

30000 Switch#configure terminal

Switch(config)# interface gi1

Example Switch(config-if)# spanning-tree mst 1 cost 30000

```
Switch(config-if)# spanning-tree mst
Switch(config-if)# spanning-tree mst 1 cost 30000
Switch(config-if)# end
Switch# show spanning-tree mst 1

MST Instance Information
-----
Instance Type / MSTI (1)
Bridge Identifier / 32769/1/00:00:00:00:00:00
Regional Root Bridge / 32769/1/00:00:00:00:00:00
Instance Root Path Cost / 0
Hello Time / 2
Max Age / 20
Forwarding Delay / 15
Topology Changes / 12
Last Topology Change / 243

VLANs mapped: 10-20

Interface  Role  Prio  Cost  Prio.Mtu  Type
-----  ---  ---  ---  ---  ---
gi1/24    Dns  Prio 300000 128.25  RIF Dns
gi1/25    Dns  Prio 300000 128.25  RIF Dns
gi1/26    Dns  Prio 30000 128.24  RIF Dns (STP)
```

29.24 SPANNING-TREE MST PORT-PRIORITY

To configure the interface priority on the specific instances, use the command `spanning-tree mst port- priority` in the Interface Configuration mode. For the default configuration, use the “**no**” form of the command.

The priority value must be the multiple of 16. When the port priority on the CIST (instance 0) is configured, it is equal to the command `spanning-tree port-priority` in the Interface Configuration mode.

```
Switch#configure terminal
```

```
Switch(config)# interface {Interface-ID}
```

```
Switch(config-if)# spanning-tree mst instance-id port-priority {priority}
```

```
Switch(config-if)# no spanning-tree mst instance-id {port-priority}
```

```
Switch(config-if) spanning-tree mst instance-id port-priority {priority}
```

Syntax

```
Switch(config-if) no spanning-tree mst instance-id {port-priority}
```

Parameter **instance-id** Specify the instance ID. The valid range is from 0 to 15.

Parameter **priority** Specify the interface priority on the specific instance.

Default The default port priority on each instance

is 128 Mode Interface Configuration

The following example sets the port priority of gi1 on the instance 1 to 144 and set the port priority of gi1 on the CIST (instance 0) to 96

```
Switch#configure terminal
```

```
Switch(config)# interface gi1
```

```
Switch(config-if)# spanning-tree mst 0 port-priority 96
```

Example

```

-----
Interface: 1/0/20
Description: 1/0/20
Speed: 1000000
Duplex: Full
MTU: 1500
VLAN: 1
-----
Interface: 1/0/21
Description: 1/0/21
Speed: 1000000
Duplex: Full
MTU: 1500
VLAN: 1
-----
Interface: 1/0/22
Description: 1/0/22
Speed: 1000000
Duplex: Full
MTU: 1500
VLAN: 1
-----
Interface: 1/0/23
Description: 1/0/23
Speed: 1000000
Duplex: Full
MTU: 1500
VLAN: 1
-----
Interface: 1/0/24
Description: 1/0/24
Speed: 1000000
Duplex: Full
MTU: 1500
VLAN: 1
-----

```

29.25 SPANNING-TREE MST PRIORITY

To configure the bridge priority on the specific instance, use the command `spanning-tree mst priority` in the Global Configuration mode. To restore the default configuration, use the “**no**” form of the command.

The value of bridge priority must be the multiple of 4096. A switch with the lowest priority is the root of the STP topology. For the configuration of bridge priority on the CIST (instance 0), it is equal to the command `spanning-tree priority` in the Global Configuration mode.

Switch#**configure terminal**

Switch(config)# **spanning-tree mst instance instance-id priority** *{priority}*

Switch(config)# **no spanning-tree mst instance instance-id** *{priority}*

spanning-tree mst instance instance-id priority *{priority}*
Syntax
x **no spanning-tree mst instance instance-id** *{priority}*

instance-id Specify the instance ID. The valid range is from 0 to 15.

Parameter *priority* Specify the bridge priority on the specific instance. The valid range is from 0 to 61440. It ensures the probability that the switch is selected as the root bridge, and the lower values has the higher priority for the switch to be selected as the root bridge.

Default The default priority on each instance is

32768. Mode Global Configuration

The following example modifies the bridge priority to 4096 on instance 0 and instance 1 individually.

Switch#**configure terminal**

Switch(config)# **spanning-tree mst 0 priority 4096**

Example

```
Switch(config)# spanning-tree mst 0 priority 4096
Switch(config)# exit
Switch# show spanning-tree mst 0
-----
MST Instance Information
-----
Instance Type : CIST (0)
Bridge Identifier : 4096/00:10:00:00:00:00
-----
Designated Root Bridge : 4096/00:10:00:00:00:00
External Root Path Cost : 0
Regional Root Bridge : 4096/00:10:00:00:00:00
Internal Root Path Cost : 0
Designated Bridge : 4096/00:10:00:00:00:00
Root Role : 0/0
Max Age : 35
Forward Delay : 25
Topology Change : 15
Last Topology Change : 722
-----
VLAN mapped: 1-9,21-89,101-4094
-----
Instance Role Sts Cost Prio Hbr Type
-----
MST0 Desg RND 2000000 128.21 4096 Ensr
MST1 Desg RND 2000000 128.21 4096 Ensr
MST2 Desg RND 2000000 128.21 4096 Ensr
MST3 Desg RND 2000000 128.21 4096 Ensr
```

29.26 SPANNING-TREE PATHCOST METHOD

To set the spanning tree path cost method, use the command `spanning-tree pathcost method` in the Global Configuration mode.

If the short method is specified, the switch calculates the path cost in the range 1 through 65535; otherwise, it calculates the path cost in the range 1 to 200000000.

Switch#**configure terminal**

Switch(config)# **spanning-tree pathcost method**

(long|short) Syntax **spanning-tree pathcost**

method (long|short)

Parameter
long The range for the path cost is from 1 to 200000000.
short The range for the path cost is from 1 to 65535

Default The default path cost method is

long. Mode Global Configuration

The following example modifies path cost method to short.

Switch#**configure terminal**

Example Switch(config)# **spanning-tree pathcost method short**

```
Switch(config)# spanning-tree pathcost method short
Switch(config)# exit
Switch# show spanning-tree interface GigabitEthernet 1
Span 1:23 enabled
State: disabled           Role: disabled
Type: dot1q               Prio: default
Type: P2P Internal        Edge: none
Designated Bridge Priority: 0      Address: 00:00:00:00:00:00
Designated port: 1/24         Designated port cost: 1
STP Filter: Enabled          BPDU guard: Enabled
Span 1:23: 1/24/1
```

29.27 SPANNING-TREE PORT-PRIORITY

To configure the STP priority for an interface, use the command `spanning-tree port-priority` in the Interface Configuration mode. For the default configuration, use the “**no**” form of the command. The priority value must be the multiple of 16.

```
Switch#configure terminal
```

```
Switch(config)# interface {Interface-ID}
```

```
Switch(config-if)# spanning-tree port-priority {priority}
```

```
Switch(config-if)# no spanning-tree port-priority {priority}
```

Syntax

```
spanning-tree port-priority {priority}
no spanning-tree port-priority {priority}
```

Parameter *priority*
Specify the priority for an interface. The valid range is from 0 to 240.

Default The default priority for each interface is

128. Mode Interface Configuration

The following example modifies the port priority to 96 for the interface `gi2`.

```
Switch#configure terminal
Switch(config)# interface gi2
Switch(config-if)# spanning-tree port-priority 96
```

```
Switch#show spanning-tree detail
Switch#show spanning-tree detail interface GigabitEthernet 0/24
```

29.28 SPANNING-TREE PRIORITY

To configure the bridge priority, use the command `spanning-tree mst priority` in the Global

Configuration mode. To restore the default configuration, use the no form of the command. The value of bridge priority must be the multiple of 4096. A switch with the lowest priority is the root of the STP topology. When switches with the same priority configuration in the environment, the switch with lowest MAC address would be selected as the root bridge.

Switch#**configure terminal**

29.29 SPANNING-TREE TX-HOLD-COUNT

To limit the maximum numbers of packets transmission per second, use the command `spanning-tree tx-hold-count` in the Global Configuration mode. For the default configuration, use the “no” form of the command.

Switch#**configure terminal**

Switch(config)# **spanning-tree tx-hold-count** *{count}*

Switch(config)# **no spanning-tree tx-hold-count***{count}*

Syntax
x **spanning-tree tx-hold-count** *{count}*
no spanning-tree tx-hold-count*{count}*

Parameter *Count* Specify the tx-hold-count used to limit the maximum numbers of packets transmission per second. The valid range is from 1 to 10.

Default The default value is 6.

Mode Global Configuration

The following example sets the tx-hold-count to 4.

Switch#**configure terminal**

Switch(config)# **spanning-tree tx-hold-count 4**

Example

```
Switch(config)# spanning-tree tx-hold-count 4
Switch(config)# exit
Switch# show spanning-tree
Spanning tree enabled state: STP
Default port cost: 100000000
Default port cost: 100000000

Gathering information .....
0009:0017:0000:0000:0000:0000:0000:0000
Priority: 4096
Address: 00:1b:0c:00:00:00
This system is not the STP root
Hello Time: 4 sec Max Age: 20 sec Forward Delay: 15 sec
Max Hops: 20

Name      State Prio.Prio  Cost  Sts  Role  EdgePort  Type
-----
0/21      blocking 32768,32 100   Fw  Design  P2P Disc
0/22      blocking 32768,32 100   Fw  Design  P2P Disc
0/23      blocking 32768,32 100   Fw  Design  P2P Disc
0/24      blocking 32768,4  4     Fw  Design  P2P Root (STP)
```

STORM CONTROL

Switches support rate-limiting traffic at Layer 2 using the **storm-control** commands. Storm control can be configured to set rising and falling thresholds for each of the three types of port traffic: unicast, multicast, and broadcast. Each rate limit can be configured on a per-port basis.

You can configure storm control to operate on each traffic type based on either packet rate or a percentage of the interface bandwidth. You can also specify rising and falling thresholds for each traffic type. If you don't specify a falling threshold, or if the falling threshold is the same as the rising threshold, the switch port will forward all traffic up to the configured limit and will not wait for that traffic to pass a specified falling threshold before forwarding it again.

When any of the configured thresholds is passed, the switch can take any of three additional actions, also on a per-port basis. The first, and the default, is that the switch can rate-limit by discarding excess traffic according to the configured command(s) and take no further action. The other two actions include performing the rate-limiting function and either shutting down the port or sending an SNMP trap.

30.1 SHOW STORM-CONTROL

Use “**show storm-control**” command to show all storm control related configurations including global configuration and per port configurations. Use “**show storm-control interface**” command to show selected port storm control configurations.

Switch# **show storm-control**

Switch# **show storm-control interface** *{IF_PORTS}*

show storm-control

Syntax


x **show storm-control interface** *{IF_PORTS}*

Parameter *IF_PORTS* Specify port to

show. Mode Privileged EXEC

This example shows how to show storm control global

configuration. Switch# **show storm-control**



Example

30.2 STORM-CONTROL

Storm control function is able to enable/disable on each single port. Use the

“**storm control**” command to enable storm control feature on the selected ports. And use “**no storm control**” command to disable storm control feature. Not only port is able to enable/disable on the port. Each storm control type is also able to enable/disable on each single port. Use the “**storm-control (broadcast|unknown-unicast|unknown-multicast)**” command to enable the storm control type you need and use “**no**” form to disable it.

Switch#**configure terminal**

Switch(config)# **interface** {Interface-

ID} Switch(config-if)# **storm-control**

Switch(config-if)# **no storm-control**

Switch(config-if)# **storm-control (broadcast | unknown-unicast | unknown-multicast) no storm-control (broadcast | unknown-unicast | unknown-multicast)**

	storm-control
	no storm-control
Synta x	storm-control (broadcast unknown-unicast unknown-multicast) no storm-control (broadcast unknown-unicast unknown-multicast)
	broadcast Select broadcast storm control type
Paramet er	unknown-unicast Select unknown unicast storm control type unknown- multicast Select unknown multicast storm control type
Mode	Interface Configuration

This example shows how to enable storm control on interface gi1.

Switch#configure terminal

Switch(config)# interface gi1

Switch(config-if)# storm-control

This example shows how to enable broadcast storm control and configure broadcast storm control rate to 200.

```
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# storm-control
Switch(config-if)# end
Switch# show storm-control
Storm control preamble and IFG: Enabled
Storm control unit: bps

```

Port	State	Broadcast	Unknown-Multicast	Known-Multicast	Action
		Kbps	Kbps	Kbps	
gi1	enable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi2	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi3	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi4	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi5	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi6	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi7	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi8	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi9	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi10	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi11	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi12	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi13	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi14	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi15	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi16	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi17	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp
gi18	disable	Off(10000)	Off(10000)	Off(10000)	Stpnp

Examp
le

Switch#configure terminal

Switch(config)# interface gi1

Switch(config-if)# storm-control broadcast

This example shows how to show current storm control configuration on interface gi1 Switch# show storm-control interfaces gi1

```
Switch(config)# interface GigabitEthernet 1
Switch(config-if)# storm-control broadcast
Switch(config-if)# end
Switch# show storm-control interfaces gi1

```

Port	State	Broadcast	Unknown-Multicast	Known-Multicast	Action
		Kbps	Kbps	Kbps	
gi1	enable	1000	Off(10000)	Off(10000)	Stpnp

30.3 STORM-CONTROL ACTION

Use “**storm-control action**” command to set the action when the received storm control packets exceed the maximum rate on an interface. Use “**no**” form to restore to default action.

Switch#**configure terminal**

Switch(config)# **interface** {Interface-ID}

Switch(config-if)# **storm-control action** (drop | shutdown)

Switch(config-if)# **no storm-control action**

storm-control action (drop |
Syntax
x **shutdown) no storm-control action**

Parameter drop shutdown Storm control rate calculates by

octet-based Default Default storm control action is drop.

Mode Interface Configuration

This example shows how to configure storm control action to shutdown port on interface gi1.

Switch#**configure terminal**

Switch(config)# **interface gi1**

Switch(config-if)# **storm-control action shutdown**

Example

This example shows how to show storm control action on interface

gi1. Switch# **show storm-control interfaces gi1**

```
Switch(config-if)# interface gi1
Switch(config-if)# storm-control action shutdown
Switch(config-if)# end
Switch# show storm-control interfaces gi1
```

Port	State	Dropout pps	Rate-Minimum pps	Rate-Maximum pps	Action
gi1	enable	10000	Off(10000)	Off(10000)	Shutdown

30.4 STORM-CONTROL IFG

Storm control mechanism will try to calculate ingress packets is exceed configured rate or not and do corresponding action. Use storm-control ifg command to include/exclude the preamble and inter frame gap into the calculating.

Switch#configure terminal

Switch(config)# storm-control ifg (include | exclude)

Syntax storm-control ifg (include | exclude)

Include Include preamble & IFG (20 bytes) when count ingress storm control rate.

Parameter **Exclude** Exclude preamble & IFG (20 bytes) when count ingress storm control rate

Default Default storm control inter frame gap is


excluded. Mode Global Configuration

This example shows how to configure storm inter frame gap to include.

Switch#configure terminal

Switch(config)# storm-control ifg include

This example shows how to show storm control global configuration. Switch# show storm-control



Port	Storm Type	Rate	Action	Status
Gi0/1	Storm Type	Rate	Action	Status
Gi0/2	Storm Type	Rate	Action	Status
Gi0/3	Storm Type	Rate	Action	Status
Gi0/4	Storm Type	Rate	Action	Status
Gi0/5	Storm Type	Rate	Action	Status
Gi0/6	Storm Type	Rate	Action	Status
Gi0/7	Storm Type	Rate	Action	Status
Gi0/8	Storm Type	Rate	Action	Status
Gi0/9	Storm Type	Rate	Action	Status
Gi0/10	Storm Type	Rate	Action	Status
Gi0/11	Storm Type	Rate	Action	Status
Gi0/12	Storm Type	Rate	Action	Status
Gi0/13	Storm Type	Rate	Action	Status
Gi0/14	Storm Type	Rate	Action	Status
Gi0/15	Storm Type	Rate	Action	Status
Gi0/16	Storm Type	Rate	Action	Status
Gi0/17	Storm Type	Rate	Action	Status
Gi0/18	Storm Type	Rate	Action	Status
Gi0/19	Storm Type	Rate	Action	Status
Gi0/20	Storm Type	Rate	Action	Status
Gi0/21	Storm Type	Rate	Action	Status
Gi0/22	Storm Type	Rate	Action	Status
Gi0/23	Storm Type	Rate	Action	Status
Gi0/24	Storm Type	Rate	Action	Status
Gi0/25	Storm Type	Rate	Action	Status
Gi0/26	Storm Type	Rate	Action	Status
Gi0/27	Storm Type	Rate	Action	Status
Gi0/28	Storm Type	Rate	Action	Status
Gi0/29	Storm Type	Rate	Action	Status
Gi0/30	Storm Type	Rate	Action	Status
Gi0/31	Storm Type	Rate	Action	Status

30.5 STORM-CONTROL LEVEL

Each control type is allowed to have different storm control rate. Use "storm-control (broadcast|unknown-unicast|unknown-multicast)level" command to configure it. Use "no" form to

restore to default rate.

Switch#**configure terminal**

Switch(config)# **interface** {Interface-ID}

Switch(config-if)# storm-control (broadcast | unknown-unicast | unknown-multicast) level <1- 1000000>

Switch(config-if)# no storm-control (broadcast | unknown-unicast | unknown-multicast) level

Syntax
x storm-control (broadcast | unknown-unicast | unknown-multicast) level <1- 1000000> no storm-control (broadcast | unknown-unicast | unknown-multicast) level

broadcast Select broadcast storm control type

unknown-unicast Select unknown unicast storm control type

unknown-multicast Select unknown multicast storm control

Parameter
type **Level** <1-1000000> Specify the storm control rate for

selected type. For bps, range is 16-1000000

For pps, range is 1-262143

Default broadcast storm control rate is 10000.

Default
Default unknown multicast storm control rate is 10000.

Default unknown unicast storm control rate is 10000.

Mode
Interface Configuration

This example shows how to enable broadcast storm control and configure broadcast storm control rate to 200.

Switch#configure terminal

Switch(config)# interface gi1

Switch(config-if)# storm-control broadcast

Example
Switch(config-if)# storm-control broadcast level 200

This example shows how to show current storm control configuration on interface

gi1

Switch# show storm-control interfaces gi1

```
Switch(config)# interface gi1
Switch(config-if)# storm-control broadcast
Switch(config-if)# storm-control broadcast level 200
Switch(config-if)# no
Switch# show storm-control interfaces gi1
```

Port	State	Broadcast kpps	Unknown-Multicast kpps	Unknown-Unicast kpps	Action
gi1	enable	200	off/ 10000	off/ 10000	Shutdown

30.6 STORM-CONTROL UNIT

Storm control mechanism will try to calculate ingress packets is exceed configured rate or not and do corresponding action. Use storm-control unit command to change the unit of calculating method.

Switch#configure terminal

Switch(config)# storm-control unit (bps | pps)

Syntax storm-control unit (bps | pps)

Parameter bps Storm control rate calculates by octet-based pps Storm control rate calculates by packet-based

Default Default storm control unit is

bps Mode Global Configuration

This example shows how to configure storm control rate unit as

pps. Switch#configure terminal

Switch(config)# storm-control unit pps

This example shows how to show storm control global

Example configuration. Switch# show storm-control

Port	State	Admins	pps	Storm-Multicast	pps	Storm-Unicast	pps	Action
Gi0/1	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/2	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/3	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/4	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/5	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/6	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/7	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/8	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/9	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/10	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/11	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/12	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/13	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/14	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/15	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/16	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/17	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/18	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/19	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/20	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/21	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/22	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/23	pps	pps	pps	pps	pps	pps	pps	Storm
Gi0/24	pps	pps	pps	pps	pps	pps	pps	Storm

SYSTEM FILE

31.1 BOOT SYSTEM

Dual image allow user to have a backup image in the flash partition. Use “**boot system**” command to select the active firmware image. And another firmware image will become a backup one.

Switch#**configure terminal**

Switch(config)# **boot system (image0 | image1)**

Syntax **boot system (image0 | image1)**

image0 Boot from flash image
Parameter partition 0 image1 Boot from flash
image partition 1

Default Default boot image is

image0. Mode Global

Configuration

This example shows how to select image1 as active image.

Switch#**configure terminal**

Switch(config)# **boot system image1**

Example Select "image1" Success

This example shows how to show active image

partition. Switch# **show flash**

```
root@switch:~# show flash
File Name      File Size      Modified
-----
startup-config 2389           2020-11-21 17:42:00
backup-config  238            2020-01-01 00:00:00
fpga           1675           2020-01-01 00:00:00
dms2           440            2020-01-01 00:00:00
vrf_config     215            2020-01-01 00:00:00
image0 (backup) 913273         2020-09-30 16:28:18
image1 (active) 913273         2020-10-10 16:41:08
```

31.2 COPY

There are many types of files in system. These files are very important for administrator to manage the switch. The most common file operation is copy. By using these copy commands, we can upgrade backup following type of files.

- Firmware Image
- Configuration Files
- Syslog Files

- Language Files
- Security Certificate

Switch# copy (flash:// | tftp://) (flash:// | tftp://)

Switch# copy tftp:// (backup-config | running-config | startup-config) copy (backup-config | running-config | startup-config) tftp://

Switch# copy (backup-config | startup-config) running-config copy (backup-config | running-config) startup-config copy (running-config | startup-config) backup-config

copy (flash:// | tftp://) (flash:// | tftp://)

Synta copy tftp:// (backup-config | running-config | startup-config) copy (backup-config | running-config | startup-config) tftp://

X

copy (backup-config | startup-config) running-config copy (backup-config | running-config) startup-config copy (running-config | startup-config) backup-config

flash:// Specify the file stored in flash to operation. Available files are: flash://startup-config flash://backup-config flash://rsa1 flash://rsa2 flash://dsa2 flash://image0 flash://image1 flash://ram.log flash://flash.log

tftp://

Parameter Specify remote tftp server and remote file name. The format is

“tftp://192.168.1.111/remote_file_name”

running-config Running configuration file

startup-config Startup configuration

file backup-config Backup

configuration file

Mode Privileged EXEC

Example

This example shows how to copy running configuration to startup configuration. Switch# **copy running-config startup-config**

This example shows how to backup running configuration to remote tftp server 192.168.111 with file name test1.cfg.

Switch# **copy running-config tftp://**

```
Switch# copy running-config tftp://
Uploading file. Please wait...
Save configuration failed.
Switch#
```

Switch# **copy tftp://192.168.1.111/test2.cfg startup-config**

Switch# **copy flash://dsa2 tftp://192.168.1.111/dsa2**

31.3 DELETE

Use “**delete**” command to delete configuration files or use “**delete system**” command to delete firmware image stored in flash. The “**delete startup-config**” command is used to restore factory default and it is equal to command “**restore-defaults**”.

```
Switch# delete (startup-config | backup-config | flash://)
```

```
Switch# delete system (image0 | image1)
```

Syntax
x **delete (startup-config | backup-config | flash://) delete system (image0 | image1)**

flash:// Specify the configuration file stored in flash to delete. Available files are:

flash://startup-config flash://backup-config startup-config

Parameter Delete startup configuration file

backup-config Delete backup configuration file

image0 Delete flash image0.

image1 Delete flash

image1 Mode Privileged EXEC

This example shows how to delete backup configuration

file. Switch# **delete backup-config**

Example

e This example shows how to delete backup firmware image

from flash. Switch# **delete system image1**

31.4 RESTORE-DEFAULTS

Use “**restore-defaults**” command to restore factory default of all system. The command is equal to “**delete startup-config**”.

Switch# **restore-defaults** [**interfaces** *{IF_PORTS}*]

Syntax **restore-defaults** [**interfaces** *{IF_PORTS}*]

Parameter **interfaces** *IF_PORTS* Specify port to restore its' running config

Mode Privileged EXEC

This example shows how to restore factory

Example defaults. Switch# **restore-defaults**
e



31.5 SAVE

Uses “**save**” command to save running configuration to startup configuration file. This command is equal to

“**copy running-config startup-config**”.

Switch# **save**

Syntax **save**

Mode Privileged EXEC

This example shows how to save running configuration to startup configuration.

Switch# **save**

```
Switch# save  
Success
```

This example shows how to show startup configuration

Example Switch# **show startup-config**

```
Switch# show startup-config  
startup CONFIG FILE IS: NVRAM  
! System Description: S7600-81332M Switch  
! System Version: vSolder00.2K.v1.4  
! System Name: Switch  
! System Up Time: 0 days, 0 hours, 30 mins.  
!  
! system location "default"  
system contact "default"  
no ip dhcp  
ip address 192.168.0.1 mask 255.255.255.0  
username "admin" secret encrypted $ytcw00z  
clock source local  
vlan 2-100  
voice-vlan oui-table 001E05B "3COM"  
voice-vlan oui-table 001034B "Cisco"  
voice-vlan oui-table 01E2175 "Hewlett"  
voice-vlan oui-table 001D01E "Arista"  
voice-vlan oui-table 00101E3 "Siemens"  
voice-vlan oui-table 0014089 "HPE/Phillips"  
voice-vlan oui-table 0010FEE "H3C"  
voice-vlan oui-table 001094E "Avaya"
```

31.6 SHOW CONFIG

Our configuration file is text based. Therefore, we can show the configuration on terminal and read it by this command. Use “**show config**” command to show configuration files stored in system. Use “**show config interfaces**” command to show specific port configurations.

```
Switch#show (running-config | startup-config | backup-config)
```

```
Switch#show running-config interfaces {IF_PORTS}
```

Syntax
x show (running-config | startup-config | backup-config) show running-config interfaces {IF_PORTS}

running-config Show running configuration on

terminal startup-config Show startup

Parameter configuration on terminal backup-config Show

backup configuration on terminal IF_PORTS

Specify port to show its' running config

Mode Privileged EXEC

31.7 SHOW FLASH

Use “**show flash**” command to show all files status which stored in

flash. Switch# **show flash**

Syntax **show flash**

Mode Privileged EXEC

This example shows how to show all files status stored in flash.

Example Switch# **show flash**

```
Switch# show flash
File Name      File Size      Modified
-----
startup-config 3889           2020-11-21 17:42:00
backup-config 1280           2020-01-01 00:00:00
cna2           1070           2020-08-01 00:00:01
cna3           440            2020-01-01 00:00:00
vsa_conf       3485           2020-08-01 00:00:01
image0 (backup) 9125373        2020-08-10 16:28:19
image0 (active) 9125240        2020-10-10 16:48:55
```

SURVEILLANCE VLAN

Creating a reliable surveillance system can be a challenging task. Adding surveillance to an existing network can be problematic; periods of heavy network traffic, such as during mass data transfers or a broadcast storm, can cause your surveillance video feeds to freeze, skip frames, or even drop out completely, surveillance vlan technology that addresses the issue of how to separate data and video in a single network deployment.




Fig 32.1 Surveillance VLAN concept

Surveillance VLAN allows quick, easy, and automatic creation of a reliable hybrid network that can handle both data and surveillance traffic. By connecting surveillance equipment such as IP cameras and NVRs, VLAN for surveillance traffic and sets Quality of Service (QoS) for that traffic to high-priority. This allows your surveillance traffic to be secure, and ensures that surveillance video continues to stream smoothly and reliably, even during periods of heavy data traffic. Doing this normally requires you to manually configure each setting and add each device to your network one by one.




Fig 32.2 Surveillance VLAN with Trust

32.1 SURVEILLANCE-VLAN

Use the surveillance vlan global configuration command to enable the functional Surveillance VLAN on the device. Use the “no” form of this command to disable Surveillance VLAN function. You can verify your setting by entering the show surveillance vlan Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch(config)# surveillance-vlan
```

```
Switch(config)# no surveillance-vlan
```

```
surveillance-vlan
```

Syntax

```
x no surveillance -vlan
```

Mode Global Configuration

The following example shows how to enable Surveillance VLAN.

```
Switch#configure terminal
```

Example Switch(config)# surveillance -vlan

```
Switch# show surveillance -vlan
```

```
Switch(config)# surveillance-vlan
Switch(config)# exit
Switch# show surveillance-vlan
AdminState Surveillance VLAN state : enabled
Surveillance VLAN ID : 2
Surveillance VLAN Aging : 1440 minutes
Surveillance VLAN Cos : 6
Surveillance Vlan up Remark: disabled

OUT table
OUT Desc | Description
```

32.2 SURVEILLANCE-VLAN (INTERFACE)

Use the surveillance vlan Interface configuration command to enable OUI surveillance VLAN configuration on an interface. Use the “no” form of this command to disable Surveillance VLAN on an interface. You can verify your setting by entering the show surveillance vlan Privileged EXEC command.

surveillance-vlan

Synta

x no surveillance-vlan

Mode Interface Configuration

The following example how to enable Surveillance VLAN function in oui mode on an interface

```
Switch#configure terminal
```

```
Switch(config)#interface range GigabitEthernet
```

1-3 Example Switch(config-if)#surveillance-vlan

```
Switch# show surveillance-vlan interfaces gi1-3
```

```
Switch(config)# interface range GigabitEthernet 1-3
Switch(config-if-range)# surveillance-vlan
Switch(config-if-range)# end
Switch# show surveillance-vlan interfaces gi1-3
  Port | State | Port Mode | Cos Mode
-----|-----|-----|-----
gi1   | Enabled | Auto | Src
gi2   | Enabled | Auto | Src
gi3   | Enabled | Auto | Src
```

32.3 SURVEILLANCE-VLAN VLAN

Use the surveillance vlan id global configuration command to configure the VLAN identifier of the surveillance VLAN statically. Use the “no” form of this command to restore surveillance VLAN id to default. You can verify your setting by entering the show surveillance vlan Privileged EXEC command.

Switch#configure terminal

Switch(config)#surveillance-vlan vlan <1-

4094> Switch(config)#no surveillance-vlan

vlan

surveillance-vlan vlan <1-4094>

Synta

x

no surveillance-vlan vlan

Parameter <1-4094>Specify the Surveillance VLAN

ID Default The default Surveillance VLAN ID is

None. Mode Global Configuration

The following example shows how to set Surveillance VLAN id. The VLAN id must be created first.

Switch#configure terminal

Switch(config)# surveillance-vlan vlan

Examp

e

128 Switch# show surveillance-vlan

```
Switch(config)# surveillance-vlan vlan 2
Switch(config)# exit
Switch# show surveillance-vlan
Administrative Surveillance VLAN state : enabled
Surveillance VLAN ID : 2
Surveillance VLAN Aging : 1440 minutes
Surveillance VLAN Cos : 6
Surveillance VLAN Ip Remark: disabled

OOI table
OOI Mac | Description
-----
```

32.4 SURVEILLANCE-VLAN OUI-TABLE

Use the surveillance vlan oui-table global configuration command to add OUI mac address to OUI Table. Use the no form of this command to remove all or specified OUI mac address. You can verify your setting by entering the show surveillance vlan Privileged EXEC command.

Switch#**configure terminal**

Switch(config)# **surveillance-vlan oui-table A:B:C [DESCRIPTION]**

Switch(config)# **no surveillance-vlan oui-table [A:B:C]**

	surveillance-vlan oui-table A:B:C [DESCRIPTION] no
Syntax	
x	surveillance-vlan oui-table [A:B:C]
	A:B:C Specify OUI Mac address to add or remove
Parameter	DESCRIPTION Specify description of the specified MAC address to the surveillance VLAN OUI table
Mode	Global Configuration

This following example shows how to add OUI Mac.

Switch#**configure terminal**

Switch(config)# **surveillance-vlan oui-table 00:01:02 "Test"**

Example

Switch# **show surveillance-vlan interfaces gi1-3**

```
Switch(config)# surveillance-vlan oui-table 00:01:02 Test1
Switch(config)# exit
Switch# show surveillance-vlan interfaces gi1-3
  Port | State | Port Mode | Cos Mode
-----|-----|-----|-----
gi1   | Enabled | Auto     | Svc
gi2   | Enabled | Auto     | Svc
gi3   | Enabled | Auto     | Svc
```

32.5 SURVEILLANCE-VLAN COS (GLOBAL)

Use the surveillance vlan cos global configurations command to configure the surveillance VLAN cos value and 1p remark function. Use the “no” form to restore to default mode. You can verify your setting by entering the show surveillance vlan Privileged EXEC command.

Switch#configure terminal

Switch(config)# surveillance-vlan cos <0-7> [remark]

Switch(config)# no surveillance-vlan cos

surveillance-vlan cos <0-7> [remark]

Syntax

x no surveillance-vlan cos

<0-7> Specify the surveillance VLAN Class of Service value in telephone OUI mode
Parameter

remark Specify that the L2 user priority is remarked with the

CoS value Default The default cos value is 6, remark is disabled.

Mode Global Configuration

The following example show how to set cos value and enable 1p remark function

Switch#configure terminal

Switch(config)# surveillance-vlan cos 7 remark

Example Switch# show surveillance-vlan
e

```
Switch(config)# surveillance-vlan cos 7 remark
Switch(config)# exit
Switch# show surveillance-vlan
Administrative Surveillance VLAN state : enabled
Surveillance VLAN ID : 7
Surveillance VLAN Group : 1440 minutes
Surveillance VLAN CoS : 7
Surveillance VLAN 1p Remark: enabled

OUI table
-----
OUI MAC | Description
-----
0010102 | Test
0010103 | Test
```

32.6 SURVEILLANCE-VLAN COS (INTERFACE)

Use the `surveillance vlan cos mode Interface configuration` command to configure OUI surveillance VLAN cos mode configuration on an interface. Use the **“no”** form to restore to default mode. You can verify your setting by entering the `show surveillance-vlan interfaces` Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch(config)#interface {Interface-ID}
```

Switch(config-if)#**surveillance-vlan cos (src | all)**

Switch(config-if)#**no surveillance-vlan cos**

surveillance-vlan cos (src | all)

Syntax

x **no surveillance-vlan cos**

src Specify QoS attributes are applied to packets with OUIs in the source MAC address.

Parameter

er All Specify QoS attributes are applied to packets that are classified to the Surveillance VLAN.

Default The default all port in Src

mode. Mode Interface

configuration

The following example how to configure surveillance packet QoS attributes on an interface

Switch#**configure terminal**

Switch(config)#**interface range gi1-3**

Example Switch(config-if)#**surveillance-vlan cos all**

e

Switch# **show surveillance-vlan interfaces gi**

1-3

```
Switch(config)# interface range gi1-3
Switch(config-if-range)# surveillance-vlan cos all
Switch(config-if-range)# end
Switch# show surveillance-vlan interfaces gi 1-3
-----
Port | State | Port Mode | Cos Mode
-----
gi1 | Enabled | Auto | All
gi2 | Enabled | Auto | All
gi3 | Enabled | Auto | All
```

32.7 SURVEILLANCE-VLAN MODE

Use the surveillance-vlan mode global configuration command to configure the surveillance VLAN mode for interface. Use the “no” form to restore to default mode. You can verify your setting by entering the show surveillance-vlan interfaces Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch(config)#interface {Interface-ID}
```

```
Switch(config-if)#surveillance-vlan mode (auto|manual)
```

```
Switch(config-if)#no surveillance-vlan mode
```

	surveillance-vlan mode (auto manual)
Syntax	
x	no surveillance-vlan mode
Parameter	auto Specifies that the port is identified as a candidate to join the surveillance VLAN. When a packet with a source OUI MAC address that identifies the remote equipment as surveillance equipment is seen on the port, the port joins the surveillance VLAN as a tagged port.
	manual Specifies that the port is manually assigned to the surveillance VLAN.
Default	The default is auto
mode. Mode	Interface

Configuration

The following example shows how to configure surveillance mode to manual

```
Switch#configure terminal
```

```
Switch(config)#interface range gi1-3
```

```
Switch(config-if)#surveillance-vlan mode  
manual Switch# show surveillance-vlan
```

i terfaces gi1-3

n

```
Switch(config)# interface range gi1-3
Switch(config-if-range)# surveillance-vlan mode Manual
Switch(config-if-range)# end
Switch# show surveillance-vlan interfaces gi1-3
  Port | State | Port Mode | Cos Mode
-----|-----|-----|-----
gi1   | Enabled | Manual   | All
gi2   | Enabled | Manual   | All
gi3   | Enabled | Manual   | All
```

32.8 SURVEILLANCE-VLAN AGING-TIME

Use the surveillance vlan aging-time global configuration command to configure the surveillance VLAN aging timeout. Use the “no” form to restore to default time. You can verify your setting by entering the show surveillance vlan Privileged EXEC command.

Switch#**configure terminal**

Switch(config)# **surveillance-vlan aging-time** <30-65536>

Switch(config)# **no surveillance-vlan aging-time**

surveillance-vlan aging-time <30-65536>

Syntax

x **no surveillance-vlan aging-time**

Parameter <30-65536>

Specify the Surveillance VLAN aging timeout interval in minutes

Default The default aging-timeout value is 1440

minutes Mode Global Configuration

The following example shows how to set aging time. Switch#**configure terminal**

Switch(config)# **surveillance-vlan aging-time**

Example

720 Switch# **show surveillance-vlan**

```
Switch(config)# surveillance-vlan aging-time 720
Switch(config)# exit
Switch# show surveillance-vlan
Administrative Surveillance VLAN state : disabled
Surveillance VLAN ID : none (disabled)
Surveillance VLAN Aging : 720 minutes
Surveillance VLAN Ccp : 6
Surveillance VLAN Ip Remark: disabled

Out table
Out MAC | Description
```

32.9 SHOW SURVEILLANCE-VLAN

Use the show surveillance vlan command in EXEC mode to display the surveillance VLAN status for all interfaces or for a specific interface if the surveillance VLAN type is OUI.

Switch#show surveillance-vlan

Switch#show surveillance-vlan interfaces [IF_PORTS]

show surveillance-vlan

Syntax

x show surveillance-vlan interfaces [IF_PORTS]

Parameter *IF_PORTS* Specifies interfaces to display surveillance VLAN settings in OUI

mode Mode Privileged EXEC

The following example show how to display surveillance vlan OUI mode

settings Switch# show surveillance-vlan

Example

e

```
Switch# show surveillance-vlan
Administrate Surveillance VLAN state : disabled
Surveillance VLAN ID : none (disable)
Surveillance VLAN Aging : 720 minutes
Surveillance VLAN CoS : 6
Surveillance VLAN Ip Remark: disabled

OUI table
OUI MAC | Description
```

TIME

NTP Version 3 (RFC 1305) allows IP hosts to synchronize their time-of-day clocks with a common source clock. For instance, routers and switches can synchronize their clocks to make event correlation from an SNMP management station more meaningful, by ensuring that any events and traps have accurate time stamps.

By design, most routers and switches use NTP *client mode*, adjusting their clocks based on the time as known by an NTP server. NTP defines the messages that flow between client and server, and the algorithms a client uses to adjust its clock. Routers and switches can also be configured as NTP servers, as well as using NTP *symmetric active mode*—a mode in which the router or switch mutually synchronizes with another NTP host. NTP servers may reference other NTP servers to obtain a more accurate clock source as defined by the *stratum level* of the ultimate source clock.

33.1 CLOCK SET

Use the clock set command to set static time. The static time won't save to configuration file. You can verify your setting by entering the show clock Privileged EXEC command.

```
Switch# clock set HH:MM:SS (jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov |dec) <1-31> <2000-2035>
```

Syntax `clock set HH:MM:SS (jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) <1-31><2000-2035>`

Parameter `HH:MM:SS <1-31> (jan|feb|mar|apr|may|jun|jul|aug| sep|oct|nov|dec) <2000-2035>` Specify static time of year, month, day, hour, minute, second

No default is defined.

Default The clock set to 2000/01/01 08:00:00 by default at startup.

Mode Privileged EXEC

Example

T example shows how to set static time of
h switch. Switch# **clockset 10:57:00 feb 1 2020**
e Switch# **show clock**

```
SWITCH# clock set 10:57:00 feb 1 2020
01-02-2020 10:57:00 UTC-7
SWITCH# show clock
01-02-2020 10:57:12 UTC-7
Time set manually
```

33.2 Clock timezone

Use the clock timezone command to set timezone setting. Use the “no” form of this command to restore to default setting. You can verify your setting by entering the show clock detail Privileged EXEC command.

Switch#**configure terminal**

Switch(config)# **clock timezone** ACRONYM HOUR-OFFSET [*minutes <0-59>*]

Switch# **no clock timezone**

clock timezone (ACRONYM HOUR-OFFSET) [*minutes <0-59>*]
Syntax
x **no clock timezone**

ACRONYM Specify acronym name of time

zone Parameter HOUR-OFFSET Specify hour offset of

time zone

Minutes <1-59> Specify minute offset of time

zone Default Default time zone is UTC+8.

Mode Global Configuration

The example shows how to set time zone of switch and then restore to default time zone.

Switch#**configure terminal**

Switch(config)# **clock timezone** test

+5 Switch# **show clock detail**

Examp

e

```
Switch(config)# c
Switch(config)# ex
Switch# show clock
01-02-2020 23:06:13
Time source is sn
Time zone:
Acronym is test
Offset is UTC+8
```

Switch(config)# no clock timezone

Switch# show clock detail

```
Switch(config)# no clock timezone
Switch(config)# ex
Switch# show clock detail
01-02-2020 11:07:51 UTC-7
Time source is snmp
Time zone:
Acronym is
Offset is UTC-7
```

33.3 CLOCK SOURCE

Use the clock source command to set the source of time. Use the “no” form of this command to restore to default setting. You can verify your setting by entering the show clock detail Privileged EXEC command.

Switch#**configure terminal**

Switch(config)# **clock source (local|ntp)**

Syntax **clock source (local|ntp)**

Parameter local Specify to use static time
Parameter ntp Specify to use ntp time

Default Default is using local

time Mode Global Configuration

The example shows how to set clock source of switch.

Switch#**configure terminal**

Example Switch(config)# **clock source ntp**

Switch(config)# **show clock detail**

```
Switch(config)# clock source ntp
Switch(config)# exit
Switch# show clock detail
03-02-2020 11:09:44 UTC-7
Time source is ntp
Time zone:
Acronym is
Offset is UTC-7
```

33.4 CLOCK SUMMER-TIME

Use the clock summer-time command to set daylight saving time for system time. The “usa” or “eu” means that use the global daylight saving policy which defined by international organization. In both the “date” and “recurring”, the first part of the command specifies when summer time begins, and the second part specifies when it ends. All times are relative to the local time zone. The “recurring” means that adjust time every year within the month. Use the no form of this command to default setting. You can verify your setting by entering the show clock detail Privileged EXEC command.

Switch#configure terminal

```
Switch(config)# clock summer-time ACRONYM date (jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) <1-31><2000-2037>
```

```
HH:MM (jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) <1-31><2000-2037> HH:MM [<1-1440>]
```

```
Switch(config)# clock summer-time ACRONYM recurring (usa|eu) [<1-1440>] clock summer-time ACRONYM recurring (<1-5>|first|last)
```

```
(sun|mon|tue|wed|thu|fri|sat)(jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec)HH:MM (<1-5>|first|last) (sun|mon|tue|wed|thu|fri|sat)(jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec)HH:MM [<1-1440>]
```

```
Switch(config)# no clock summer-time
```

```
clock summer-time ACRONYM date  
(jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec)  
<1-31><2000-2037>
```

```
HH:MM (jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) <1-31><2000-2037>  
HH:MM [<1-1440>]
```

```
Syntax  
x clock summer-time ACRONYM recurring (usa|eu) [<1-1440>] clock summer-time ACRONYM recurring (<1-5>|first|last)
```

```
(sun|mon|tue|wed|thu|fri|sat) (jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) HH:MM  
(  
<1-5>|first|last) (sun|mon|tue|wed|thu|fri|sat)  
(jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) HH:MM [<1-1440>]
```

```
no clock summer-time
```

ACRONYM<1-31> Specify acronym name of time

zone (jan|feb|mar|apr| may|jun|jul|aug|sep|

oct|nov|dec)

<2000-2037>HH:MM Specify non-recurring daylight saving time duration.

<1-1440>Specify adjust offset of daylight saving time

Parameter **usa** Using daylight saving time in the United States that starts on the second Sunday of March and ends on the first Sunday of November

eu Using daylight saving time in the Europe that starts on the last Sunday in March and ending on the last Sunday in October

(<1-5>|first|last) (sun|mon| tue|wed|thu|fri|sat) (jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) HH:MM (<1-5>|first|last)
(sun|mon|tue|wed|thu|fri|sat) (jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) HH:MM Specify recurring daylight saving time duration.

Mode Global Configuration

The example shows how to set clock summer time of switch. You can verify settings by the following show show clock command.

Switch#configure terminal

Switch(config)# clock summer-time test recurring usa

Example

Switch# show clock detail

```
Switch(config)# clock summer-time test recurring usa
Switch(config)# exit
Switch# show clock detail
01-02-2020 11:20:25 UTC-7
Time source is ntp
Time zone:
Acronym is
Offset is UTC-7
SummerTime:
Acronym is test
Recurring every year.
Begins at 2 0 3 2:0
Ends at 3 0 11 2:0
Offset is 60 minutes.
```

33.5 SHOW CLOCK

Use the show clock command to show clock of switch. The “**detail**” means that show more information of clock such as time zone and daylight saving time.

Switch# **show clock [detail]**

Syntax **show clock [detail]**

Parameterdetail Show more detail information of

clock Mode Privileged EXEC

The example shows how to show clock of switch and detail information.

Switch#**configure terminal**

Switch(config)# **clock source sntp**

Switch(config)# **clock summer-time DLS recurring usa**

Switch(config)# **sntp host 192.168.1.100**

Example Switch# **show clock**

e Switch# **show clock detail**

```
Switch(config)# clock source sntp
Switch(config)# clock summer-time DLS recurring usa
Switch(config)# sntp host 192.168.1.100
Switch(config)# exit
Switch# show clock
01-02-2020 11:22:50 UTC-7
Time source is sntp

Switch# show clock detail
01-02-2020 11:22:50 UTC-7
Time source is sntp

Time zone:
Acronym is
Offset is UTC-7

Summertime:
Summertime is DLS
Recurring every year.
Begin at 2 0 8 2:0
End at 1 0 11 2:0
Offset is 60 minutes.
```

33.6 SNTP

Use the sntp command to set remote SNTP server. Use the no form of this command to default setting. You can verify your setting by entering the show sntp Privileged EXEC command.

Switch#**configure terminal**

Switch(config)# **sntp host HOSTNAME [port <1-65535>]**

Switch(config)# no sntp

Synta sntp host HOSTNAME [*port <1-65535>*]
x no sntp

	HOSTNAME Specify ip address or hostname of sntp
Parameter	server sntp Specify server port of sntp server
Default	No default SNTP server defined. Default server port is 123 when server created.
Mode	Global Configuration

The example shows how to set remote SNTP server of switch.

Switch#**configure terminal**

Switch(config)# **clock source sntp**

Example Switch(config)# **sntp host**

192.168.1.100 Switch(config)# **show**

sntp

```
Switch# configure
Switch(config)# clock source sntp
Switch(config)# sntp host 192.168.1.100
Switch(config)# exit
Switch# show sntp
SNTP is enabled
SNTP Server address: 192.168.1.100
SNTP Server port: 123
```

33.7 SHOW SNTP

Use the show sntp command to remote SNTP server

information. Switch# **show sntp**

Syntax **show sntp**

Mode Privileged EXEC

The example shows how to show remote SNTP server.

Example Switch# **show sntp**

```
Switch# show sntp
SNTP is enabled
SNTP Server address: 192.168.1.100
SNTP Server port: 222
```

UDLD

Virtual LANs In an Ethernet LAN, a set of devices that receive a broadcast sent by any one of the devices in the same set is called a broadcast domain. On switches that have no concept of virtual LANs (VLAN), a switch simply forwards all broadcasts out all interfaces, except the interface on which it received the frame. As a result, all the interfaces on an individual switch are in the same broadcast domain. Also, if the switch connects to other switches and hubs, the interfaces on those switches and hubs are also in the same broadcast domain.

Fig 35.1 VLAN concept

A VLAN is simply an administratively defined subset of switch ports that are in the same broadcast domain. Ports can be grouped into different VLANs on a single switch, and on multiple interconnected switches as well. By creating multiple VLANs, the switches create multiple broadcast domains. By doing so, a broadcast sent by a device in one VLAN is forwarded to the other devices in that same VLAN; however, the broadcast is not forwarded to devices in the other VLANs.

With VLANs and IP, best practices dictate a one-to-one relationship between VLANs and IP subnets. Simply put, the devices in a single VLAN are typically also in the same single IP subnet. Alternately, it is possible to put multiple subnets in one VLAN, and use secondary IP addresses on routers to route between the VLANs and subnets. Also, although not typically done, you can design a network to use one subnet on multiple VLANs, and use routers with proxy ARP enabled to forward traffic between hosts in those VLANs.

Fig 35.2 Inter VLAN communication

VLAN Configuration

Step 1 Create the VLAN.

Step 2 Associate the correct ports with that VLAN.

35.1 VLAN

Use the `vlan` global configuration command to create VLAN. Use the `no` form of this command to remove exist VLAN. You can verify your setting by entering the `show vlan` Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#vlan {Vlan-ID}
```

```
Switch (config)#no vlan
```

```
          vlan
Syntax
x       No vlan
```

Default VLAN 1 created by

default Mode Global

Configuration

The following example creates and removes a VLAN entry (100).

```
Switch#configure terminal
```

ExampleSwitch (config)# vlan 10

```
Switch# show vlan
```



Name	VLAN	Status	Trunked Ports	Trapped Ports	Type
VLAN0001	1	default	Gi0/1-Gi0/24		default

35.2 NAME (VLAN)

Use the name vlan configuration command to set name of vlan. You can verify your setting by entering the show vlan Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#vlan {Vlan-No}
```

```
Switch(config-vlan)# name
```

```
{NAME}
```

Syntax **name** {NAME}

ParameterNAME Specify the name of the VLAN (Max. 32 chars).

Default Default name of new vlan is VLAN xxxx. Xxxx is 4-digit vlan

number. Mode VLAN Configuration

This example sets the VLAN name of VLAN 100 to be `VLAN- one-hundred`.

```
Switch#configure terminal
```

```
Switch(config)# vlan 10
```

Example Switch(config-vlan)# name VLAN-COMMANDO1

```
Switch# show vlan
```



Vlan	Vlan Name	Tagged Ports	Untagged Ports	Type
10	VLAN-COMMANDO1			Default
100	VLAN- one-hundred			Standalone

35.3 SWITCHPORT MODE

The VLAN mode is used to configure the port for different port role. Access port: Accepts only untagged frames and join an untagged VLAN. Hybrid port: Support all functions as defined in IEEE 802.1Q specification. Trunk port: An untagged member of one VLAN at most, and is a tagged member of zero or more VLANs. If it is an uplink port, it can recognize double tagging on this port. Tunnel port: Port-based Q- in-Q mode. Use the switch mode port configuration command to set mode of interface. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

Switch#**configure terminal**

Switch (config)#**interface** {Interface-ID}

Switch(config-if)# **switchport mode (access | hybrid | trunk [uplink] | tunnel)**

Syntax **switchport mode (access | hybrid | trunk [uplink] | tunnel)**

access Specify the VLAN mode to Access port.

hybrid Specify the VLAN mode to Hybrid port.

Parameter**trunk** Specify the VLAN mode to Trunk port.

uplink Specify the Uplink property on this Trunk port.

tunnel Specify the VLAN mode to Dot1Q Tunnel port.

Default Default is trunk mode of all

interfaces Mode Port Configuration

This example sets VLAN mode to Access port.

Switch#**configure terminal**

Switch(config)# **interface**

GigabitEthernet 2 Switch(config-if)#

Example
e **switchport mode access**

Switch# show interfaces switchportGigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode access
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port 1 gi2
Port Mode : Access
Group Status : disabled
Ingress Filtering : enabled
Compatible Frame Type : untagged-only
Ingress Untagged VLAN ( NATIVE ) : 1
Trunking VLANs Enabled:

Port is member in:
VLAN      Name      Egress rule
-----
1         default  Untagged

Forbidden VLANs:
VLAN      Name
-----
```

35.4 SWITCHPORT HYBRID PVID

Use the switch hybrid pvid port configuration command to set pvid of interface. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport hybrid pvid <1-
```

```
4094>
```

Syntax **switchport hybrid pvid** <1-4094>

Parameter <1-4094> Specify the port-based VLAN ID on the Hybrid port.

Default Default pvid is 1.

Mode Port

Configuration

This example sets PVID to 100.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
Exampl switchport mode hybrid
```

```
e Switch(config-if)# switchport hybrid pvid 100
```

```
Switch# show interfaces switchport gi2
```

```
Switch(config)# interface gigabitethernet 2
Switch(config-if)# switchport mode hybrid
Switch(config-if)# switchport hybrid pvid 100
Switch(config-if)# end
Switch# show interfaces switchport gi2
Port: gi2
Port Mode: Hybrid
Port Status: disabled
Ingress Filtering: enabled
Permissible Frame Type: all
Ingress Untagged VLAN ( NATIVE ): 100
Trunking VLANs Enabled:
.
Port is member in:
VLAN      Name      Ingress rule
-----
1         Default  Untagged
Forbidden VLANs:
VLAN      Name
-----
```

35.5 SWITCHPORT HYBRID INGRESS-FILTERING

Use the switchport hybrid ingress-filtering port configuration command to enable vlan ingress filter. Use the “no” form of this command to disable. You can verify your setting by entering the s show interfaces switchport Privileged EXEC command.

Switch#configure terminal

Switch (config)#interface {Interface-ID}

Switch(config-if)# **switchport hybrid ingress-filtering**

Switch(config-if)# **no switchport hybrid ingress-filtering**

switchport hybrid ingress-filtering
Synta
x **no switchport hybrid ingress-filtering**

Mode Port Configuration

This example sets ingress-filtering to disable.

Switch#**configure terminal**

Switch(config)# **interface**

GigabitEthernet 2 Switch(config-if)#

switchport mode hybrid

Examp| Switch(config-if)# **no switchport hybrid**
e **ingress- filtering**

Switch# **show interfaces switchport GigabitEthernet 2**

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode hybrid
Switch(config-if)# no switchport hybrid ingress-filtering
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Hybrid
Group Status : disabled
Ingress Filtering : disabled
Acceptable Frame Type : all
Ingress Untagged VLAN ( Native ) : 100
Trunking VLANs Enabled:

Port is member in:
Vlan      Name      Egress rule
-----
1         Default  Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.6 SWITCHPORT HYBRID ACCEPTABLE-FRAME-TYPE

Use the switchport hybrid accept-frame-type port configuration command to choose which type of frame can be accepted. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport hybrid acceptable-frame-type ( all | tagged-only | untagged-only )
```

Syntax **switchport hybrid acceptable-frame-type (all | tagged-only | untagged-only)**

all Specify to accept all frames.

Parameter **tagged-only** Specify to only accept tagged frames.

untagged-only Specify to only accept untagged frames.

Default Default is accept all

frames Mode Port

Configuration

This example sets acceptable-frame-type to tagged-

only. Switch#**configure terminal**

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
switchport mode hybrid
```

Example

```
Switch(config-if)# switchport hybrid acceptable-frame-type tagged-only
```

```
Switch# show interfaces switchport GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode hybrid
Switch(config-if)# switchport hybrid acceptable-frame-type tagged-only
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi1
Port Mode : Hybrid
Vlan Status : disabled
Access Filtering : disabled
Acceptable Frame Type : tagged-only
Trunking Unlabeled VLANs ( NATIVE ) : 100
Trunking VLANs Enabled:

Port is member in:
Vlan      Name      Egress rule
-----
1         default  Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.7 SWITCHPORT HYBRID ALLOWED VLAN

Use the switchport hybrid allow vlan add port configuration command to allow vlan on interface. Use the switchport hybrid allows vlan remove port configuration command to remove vlan on interface. You can verify your setting by entering the s show interfaces switchport Privileged EXEC command.

Switch#**configure terminal**

Switch (config)#**interface** {Interface-ID}

Switch(config-if)# **switchport hybrid allowed vlan add** {*VLAN-LIST*}

Switch(config-if)#**switchport hybrid allowed vlan remove** {*VLAN-LIST*}[**(tagged|untagged)**]

switchport hybrid allowed vlan add {*VLAN-LIST*}

Synta

x **switchport hybrid allowed vlan remove** {*VLAN-LIST*}[**(tagged|untagged)**]

VLAN-LIST Specifies the VLAN list to be added or remove.

Paramet

er **(tagged | untagged)** Specifies the member type is tagged or untagged.

Only vlan 1 is untagged member by

Defaul

t default. Default is tagged member when

added.

Mode Port Configuration

Example

T
h
i
s

e
x
a
m
p
l
e

s
e

ts port GigabitEthernet 2 VLAN to join the VLAN 100 as tagged member.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# switchport hybrid allowed vlan add 100-
```

```
105 Switch(config-if)# switchport hybrid allowed vlan
```

```
remove 105 Switch# show interfaces switchport
```

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport hybrid allowed vlan add 100-105
Switch(config-if)# switchport hybrid allowed vlan remove 105
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port: gi2
Port Mode: Hybrid
Orp Status : disabled
Ingress Filtering : disabled
Compatible Frame Type : tagged-only
Ingress Untagged VLAN (MRTM) : 100
Trunking VLANs Enabled:

Port is member in:
VLAN      Name      Egress rule
-----
1         Default  Untagged
Forbidden VLANs:
VLAN      Name
-----
```

35.8 SWITCHPORT ACCESS VLAN

Use the switchport access vlan port configuration command to set native vlan on interface. The vlan will be pvid on interface as well. Use the “no” form of this command to restore to default vlan. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport access vlan <1-
```

```
4094> Switch(config-if)# no switchport access
```

vlan

```
switchport access vlan <1-4094>
```

Synta

```
x no switchport access vlan
```

Parameter<1-4094>Specifies the access

VLAN ID. Default Default is vlan 1

Mode Port Configuration

This example sets Access port gi10 native VLAN ID to 100.

```
Switch#configure terminal
```

```
Switch(config)# interface gi2
```

```
Switch(config-if)# switchport mode
```

```
access Switch(config-if)# switchport
```

Example
e access vlan 4

```
Switch# show interfaces switchport GigabitEthernet 2
```

```
Switch(config)# interface gi2
Switch(config-if)# switchport mode access
Switch(config-if)# switchport access vlan 4
Switch(config-if)# exit
Switch(config)# exit
Switch# show interfaces switchport GigabitEthernet 2
Port: gi2
Port Mode: Access
Stp Status: disabled
Ingress Filtering: enabled
Acceptable Frame Type: untagged-only
Ingress Untagged VLAN ( NATIVE ) : 4
Trunking VLANs Enabled:

Port is member in:
Vlan      Name      Egress rule
-----
4         VLAN0004  Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.9 SWITCHPORT TUNNEL VLAN

Use the switchport tunnel vlan port configuration command to set dot1q tunnel vlan on interface. The vlan will be pvid on interface as well. Use the “no” form of this command to remove vlan on interface. The tunnel vlan id will set to reserve vlan 4095. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport tunnel vlan <1-
```

```
4094> Switch(config-if)# no switchport tunnel
```

```
vlan
```

```
switchport tunnel vlan <1-4094>
```

Synta

```
x no switchport tunnel vlan
```

Parameter <1-4094> Specifies the tunnel VLAN

ID. Default Default is vlan 1

Mode Port Configuration

This example sets Tunnel port GigabitEthernet 2 native VLAN to 4.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
switchport mode tunnel
```

Examp
le

```
Switch(config-if)# switchport tunnel vlan 4
```

```
Switch# show interfaces switchport GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode tunnel
Switch(config-if)# switchport tunnel vlan 4
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Tunnel
Swg Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress Untagged VLAN ( NATIVE ) : 4
Trunking VLANs Enabled:

Port is member in:
-----
Vlan      Name          Egress rule
-----
4         VLAN0004     Untagged
-----
Forbidden VLANs:
Vlan      Name
-----
```

35.10 SWITCHPORT TRUNK NATIVE VLAN

Use the switchport trunk native vlan port configuration command to set native vlan on interface. Use the “no” form of this command to restore to default vlan. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport trunk native vlan <1-4094>
```

```
Switch(config-if)# no switchport trunk native vlan
```

```
switchport trunk native vlan <1-4094>
```

Syntax

```
x no switchport trunk native vlan
```

Parameter <1-4094> Specifies the native VLAN

ID. Default Default is vlan 1

Mode Default is vlan 1

This example sets Trunk port GigabitEthernet 2 native VLAN to 4.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
switchport mode trunk
```

Example

```
Switch(config-if)# switchport trunk native vlan 4
```

```
Switch# show interfaces switchport
```

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode trunk
Switch(config-if)# switchport trunk native vlan 4
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2

Port : gi2
Port Mode : Trunk
Swg Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 4
Trunking VLANs Enabled:

Port is member in:
Vlan      Name          Egress rule
-----
4         VLAN0004     Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.11 SWITCHPORT TRUNK ALLOWED VLAN

Use the switchport trunk allow vlan add port configuration command to allow vlan on interface. Use the switchport trunk allows vlan remove port configuration command to remove vlan on interface. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

Switch#**configure terminal**

Switch (config)#**interface** {Interface-ID}

Switch(config-if)# **switchport trunk allowed vlan (add | remove) (VLAN-LIST | all)**

Syntax **switchport trunk allowed vlan (add | remove) (VLAN-LIST | all)**

(**add | remove**) Specify the action to add or remove the allowed VLAN list.

Parameter(**VLAN-LIST | all**) Specify the VLAN list or all VLANs to be added or removed.

Mode Port Configuration

This example sets Trunk port GigabitEthernet 2 to add the allowed

VLAN 4. Switch# **configure**

Switch(config)# **interface** GigabitEthernet 2

Switch(config-if)# **switchport trunk allowed vlan**

add 4 Switch# **show interfaces switchport**

Examp
le

GigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport trunk allowed vlan add 4
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Trunk
Group Status : disabled
Ingress Filtering : enabled
Nonnegotiable Frame Type : all
Ingress Disallowed VLANs ( NBRIVE ) : 4
Trunking VLANs Enabled: 4

Port is member in:
Vlan      Name      Egress rule
-----
4         VLAN004   Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.12 SWITCHPORT DEFAULT-VLAN TAGGED

Use the `switchport default vlan tagged` port configuration command to become default vlan tagged member. Use the `no` `switchport default vlan tagged` port configuration command to restore to default. You can verify your setting by entering the `show interfaces switchport` Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport default-vlan tagged
```

```
Switch(config-if)# no switchport default-vlan
```

```
tagged
```

```
switchport default-vlan tagged
```

Syntax

```
x no switchport default-vlan tagged
```

Default Default is

untagged Mode Port

Configuration

This example sets Trunk port GigabitEthernet 2 membership with the default VLAN to tag.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# switchport default-vlan
```

```
tagged
```

Example Switch# show interfaces switchport GigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport default-vlan tagged
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Hybrid
Group Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Egress UnTagged VLAN ( NATIVE ) : 1
Trunking VLANs Enabled: 0

Port is member in:
Vlan      Name      Egress rule
-----
1         default  Tagged

Forbidden VLANs:
Vlan      Name
-----
```

35.13 SWITCHPORT FORBIDDEN DEFAULT-VLAN

Use the switchport forbidden default-vlan port configuration command to forbid default-vlan on interface. Use the “no” switchport forbidden default-vlan port configuration command to restore to default. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport forbidden default-  
vlan
```

```
Switch(config-if)# no switchport forbidden default-vlan
```

```
switchport forbidden default-vlan
```

Syntax

```
x no switchport forbidden default-vlan
```

Default Default is

allowed Mode Port

Configuration

This example sets the membership of the default VLAN with port GigabitEthernet 2 to Forbidden.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# switchport forbidden default-  
vlan
```

```
Example Switch# show interfaces switchport GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport forbidden default-vlan
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Hybrid
STP Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress Untagged VLAN ( NATIVE ) : 4095
Trunking VLANs Enabled: 4

Port is member in:
VLAN      Name      Egress rule
-----
Forbidden VLANs:
VLAN      Name
-----
1          default
```

35.14 SWITCHPORT FORBIDDEN VLAN

Uses the switchport forbidden vlan add port configuration command to forbid vlan on interface. Use the switchport forbidden vlan remove port configuration command to accept vlan on interface. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport forbidden vlan ( add | remove ) VLAN-LIST
```

Syntax **switchport forbidden vlan (add | remove) *VLAN-LIST***

(add | remove) Add or remove forbidden membership.

Parameter *VLAN-LIST* Specify the VLAN list.

Mode Port Configuration

This example sets the membership of the VLAN 4 with port GigabitEthernet 2 to

Forbidden.

```
Switch#configure
```

```
terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Example Switch(config-if)# switchport forbidden vlan add
```

```
4 Switch# show interfaces switchport
```

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport forbidden vlan add 4
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Hybrid
Group Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 4095
Trunking VLANs Enabled: 4

Port is member in:
Vlan      Name      Egress rule
-----
Forbidden VLANs:
Vlan      Name
-----
1          default
4          VLAN0004
```

35.15 SWITCHPORT VLAN TPID

Use the `switchport vlan tpid` port configuration command to set TPID on interface. You can verify your setting by entering the `show running-config` Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport vlan tpid
```

```
(0x8100|0x88a8|0x9100|0x9200) Syntaxswitchport vlan tpid
```

```
(0x8100|0x88a8|0x9100|0x9200)
```

Parameter(0x8100|0x88a8|0x9100|0x9200) Select TPID to set.

Default Default TPID is 0x8100

Mode Port Configuration

This example sets the TPID to 0x9100 on interface GigabitEthernet 2.

```
Switch#configure terminal
```

```
Example Switch(config)# interface GigabitEthernet 2
```

e

```
Switch(config-if)# switchport vlan tpid
```

```
0x9100
```

```
Switch(config-if)# switchport mode trunk uplink
Switch(config-if)# switchport vlan tpid 0x9100
Switch(config-if)# exit
Switch(config)# do show run
```

35.16 MANAGEMENT-VLAN

Use the management vlan Global Configuration mode command to set management vlan id. Vlan id must be created first. Use the “no” form of this command to restore to default setting. You can verify your setting by entering the show management-vlan Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch(config)# management-vlan vlan <1-4094>
```

```
Switch(config)# no management-vlan
```

```
management-vlan vlan <1-4094>
```

Syntax

```
x no management-vlan
```

Parameter <1-4094> Specify the VLAN ID of management-

vlan. Default Default management vlan is 1.

Mode Global Configuration

The following example specifies that management vlan 2 is

created Switch#configure terminal

```
Switch(config)# vlan 2
```

Example Switch(config)# management-vlan vlan 2

The following example specifies that management-vlan is restored to be default VLAN.

```
Switch(config)# no management-vlan
```

35.17 SHOW VLAN

Display information about vlan entry.

Switch# **show vlan [(VLAN-LIST|dynamic|static)]**

Syntax **show vlan [(VLAN-LIST|dynamic|static)]**

Parameter (VLANLIST|dynamic|static)Specify vlan id to show information or show all static or dynamic vlan entries.

Mode Privileged EXEC

The following example specifies that show vlan

Switch# **show vlan**

Example

```
Switch# show vlan
VLAN Name      Unassigned Ports      Tagged Ports
-----
1 | default | gi1-20,lag1-8 |
---|-----|
2 | VLAN0002 |                |
---| Static |
```

35.18 SHOW VLAN INTERFACE MEMBERSHIP

Display information about vlan membership on interfaces.

Switch# **show vlan VLAN-LIST interfaces *{IF_PORTS}* membership**

Syntax **show vlan VLAN-LIST interfaces *{IF_PORTS}* membership**

Specify vlan to show

Parameter *IF_PORTS* Specify interface is to show

Mode Privileged EXEC

The following example specifies that show vlan interface membership

Example Switch# **show vlan 2 interfaces GigabitEthernet 2 membership**

```
Switch# show vlan 2 interfaces GigabitEthernet 2 membership
-----
VLAN ID : 2
VLAN Type : Static
-----
Port | Membership
----|-----
gi2 | Excluded
-----
```

35.19 SHOW INTERFACE SWITCHPORT

Display information about default vlan.

Switch# **show interface switchport interfaces**

{/F_PORTS} Syntax **show interface switchport**

interfaces *{/F_PORTS}* Default *IF_PORTS* Specify

interfaces protocol vlan to display Mode Privileged

EXEC

The following example specifies that show interface switchport.

Switch#**configure terminal**

Switch(config)# **interface** GigabitEthernet 2

Switch(config-if)# **switchport trunk allowed vlan**

add 2

ExampleSwitch# **show interfaces switchport** GigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport trunk allowed vlan add 2
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Trunk
Swg Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress Untagged VLAN ( NATIVE ) : 1
Trunking VLANs Enabled: 2

Port is member in:
Vlan      Name      Egress rule
-----
1         default  Untagged
2         VLAN0002  Tagged

Forbidden VLANs:
Vlan      Name
-----
```

35.20 SHOW MANAGEMENT-VLAN

Display information about management vlan.

Switch# **show management-vlan**

Syntax **show management-vlan**

Mode Privileged EXEC

The following example specifies that show management vlan

Example
Switch# **show management-vlan**

```
Switch# show management-vlan
Management VLAN ID : 00000001
-----
```

VLAN

Virtual LANs In an Ethernet LAN, a set of devices that receive a broadcast sent by any one of the devices in the same set is called a broadcast domain. On switches that have no concept of virtual LANs (VLAN), a switch simply forwards all broadcasts out all interfaces, except the interface on which it received the frame. As a result, all the interfaces on an individual switch are in the same broadcast domain. Also, if the switch connects to other switches and hubs, the interfaces on those switches and hubs are also in the same broadcast domain.




Fig 35.1 VLAN concept

A VLAN is simply an administratively defined subset of switch ports that are in the same broadcast domain. Ports can be grouped into different VLANs on a single switch, and on multiple interconnected switches as well. By creating multiple VLANs, the switches create multiple broadcast domains. By doing so, a broadcast sent by a device in one VLAN is forwarded to the other devices in that same VLAN; however, the broadcast is not forwarded to devices in the other VLANs.

With VLANs and IP, best practices dictate a one-to-one relationship between VLANs and IP subnets. Simply put, the devices in a single VLAN are typically also in the same single IP subnet. Alternately, it is possible to put multiple subnets in one VLAN, and use secondary IP addresses on routers to route between the VLANs and subnets. Also, although not typically done, you can design a network to use one subnet on multiple VLANs, and use routers with proxy ARP enabled to forward traffic between hosts in those VLANs.




Fig 35.2 Inter VLAN communication

VLAN Conguration

Step 1 Create the VLAN.

Step 2 Associate the correct ports with that VLAN.

35.1 VLAN

Use the `vlan` global configuration command to create VLAN. Use the `no` form of this command to remove exist VLAN. You can verify your setting by entering the `show vlan` Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#vlan {Vlan-ID}
```

```
Switch (config)#no vlan
```

```
          vlan
Syntax
x      No vlan
```

Default VLAN 1 created by

default Mode Global

Configuration

The following example creates and removes a VLAN entry (100).

```
Switch#configure terminal
```

ExampleSwitch (config)# vlan 10

```
Switch# show vlan
```



Vlan ID	Name	Status	Ports	Type
1	default	up	Gi1/0/24	default
10	vlan10	up		default

35.2 NAME (VLAN)

Use the name vlan configuration command to set name of vlan. You can verify your setting by entering the show vlan Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#vlan {Vlan-No}
```

```
Switch(config-vlan)# name
```

```
{NAME}
```

Syntax **name** {NAME}

ParameterNAME Specify the name of the VLAN (Max. 32 chars).

Default Default name of new vlan is VLAN xxxx. Xxxx is 4-digit vlan

number. Mode VLAN Configuration

This example sets the VLAN name of VLAN 100 to be `VLAN- one-hundred`.

```
Switch#configure terminal
```

```
Switch(config)# vlan 10
```

Example Switch(config-vlan)# name VLAN-COMMANDO1

```
Switch# show vlan
```



Vlan	Vlan Name	Tagged Ports	Untagged Ports	Type
10	VLAN-COMMANDO1			Default
100	VLAN- one-hundred			Standalone

35.3 SWITCHPORT MODE

The VLAN mode is used to configure the port for different port role. Access port: Accepts only untagged frames and join an untagged VLAN. Hybrid port: Support all functions as defined in IEEE 802.1Q specification. Trunk port: An untagged member of one VLAN at most, and is a tagged member of zero or more VLANs. If it is an uplink port, it can recognize double tagging on this port. Tunnel port: Port-based Q- in-Q mode. Use the switch mode port configuration command to set mode of interface. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

Switch#**configure terminal**

Switch (config)#**interface** {Interface-ID}

Switch(config-if)# **switchport mode (access | hybrid | trunk [uplink] | tunnel)**

Syntax **switchport mode (access | hybrid | trunk [uplink] | tunnel)**

access Specify the VLAN mode to Access port.

hybrid Specify the VLAN mode to Hybrid port.

Parameter**trunk** Specify the VLAN mode to Trunk port.

uplink Specify the Uplink property on this Trunk port.

tunnel Specify the VLAN mode to Dot1Q Tunnel port.

Default Default is trunk mode of all

interfaces Mode Port Configuration

This example sets VLAN mode to Access port.

Switch#**configure terminal**

Switch(config)# **interface**

GigabitEthernet 2 Switch(config-if)#

Example
e **switchport mode access**

Switch# show interfaces switchportGigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode access
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port 1 gi2
Port Mode : Access
Group Status : disabled
Ingress Filtering : enabled
Compatible Frame Type : untagged-only
Ingress Untagged VLAN ( NATIVE ) : 1
Trunking VLANs Enabled:

Port is member in:
VLAN      Name      Egress rule
-----
1         default  Untagged

Forbidden VLANs:
VLAN      Name
-----
```

35.4 SWITCHPORT HYBRID PVID

Use the switch hybrid pvid port configuration command to set pvid of interface. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport hybrid pvid <1-
```

```
4094>
```

Syntax **switchport hybrid pvid** <1-4094>

Parameter <1-4094> Specify the port-based VLAN ID on the Hybrid port.

Default Default pvid is 1.

Mode Port

Configuration

This example sets PVID to 100.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
Exampl switchport mode hybrid
```

```
e Switch(config-if)# switchport hybrid pvid 100
```

```
Switch# show interfaces switchport gi2
```

```
Switch(config)# interface gigabitEthernet 2
Switch(config-if)# switchport mode hybrid
Switch(config-if)# switchport hybrid pvid 100
Switch(config-if)# end
Switch# show interfaces switchport gi2
Port: gi2
Port Mode: Hybrid
Port Status: disabled
Ingress Filtering: enabled
Permissible Frame Type: all
Ingress Untagged VLAN ( NATIVE ): 100
Trunking VLANs Enabled:
.
Port is member in:
VLAN      Name      Ingress rule
-----
1         Default  Untagged
Forbidden VLANs:
VLAN      Name
-----
```

35.5 SWITCHPORT HYBRID INGRESS-FILTERING

Use the switchport hybrid ingress-filtering port configuration command to enable vlan ingress filter. Use the “no” form of this command to disable. You can verify your setting by entering the s show interfaces switchport Privileged EXEC command.

Switch#configure terminal

Switch (config)#interface {Interface-ID}

Switch(config-if)# **switchport hybrid ingress-filtering**

Switch(config-if)# **no switchport hybrid ingress-filtering**

switchport hybrid ingress-filtering
Synta
x **no switchport hybrid ingress-filtering**

Mode Port Configuration

This example sets ingress-filtering to disable.

Switch#**configure terminal**

Switch(config)# **interface**

GigabitEthernet 2 Switch(config-if)#

switchport mode hybrid

Examp| Switch(config-if)# **no switchport hybrid**
e **ingress- filtering**

Switch# **show interfaces switchport GigabitEthernet 2**

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode hybrid
Switch(config-if)# no switchport hybrid ingress-filtering
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Hybrid
Group Status : disabled
Ingress Filtering : disabled
Acceptable Frame Type : all
Ingress Untagged VLAN ( Native ) : 100
Trunking VLANs Enabled:

Port is member in:
Vlan      Name      Egress rule
-----
1         Default  Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.6 SWITCHPORT HYBRID ACCEPTABLE-FRAME-TYPE

Use the switchport hybrid accept-frame-type port configuration command to choose which type of frame can be accepted. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport hybrid acceptable-frame-type ( all | tagged-only | untagged-only )
```

Syntax **switchport hybrid acceptable-frame-type (all | tagged-only | untagged-only)**

all Specify to accept all frames.

Parameter **tagged-only** Specify to only accept tagged frames.

untagged-only Specify to only accept untagged frames.

Default Default is accept all

frames Mode Port

Configuration

This example sets acceptable-frame-type to tagged-

only. Switch#**configure terminal**

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
switchport mode hybrid
```

Example

```
Switch(config-if)# switchport hybrid acceptable-frame-type tagged-only
```

```
Switch# show interfaces switchport GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode hybrid
Switch(config-if)# switchport hybrid acceptable-frame-type tagged-only
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi1
Port Mode : Hybrid
Vlan Status : disabled
Access Filtering : disabled
Acceptable Frame Type : tagged-only
Trunking Unlabeled VLANs ( NATIVE ) : 100
Trunking VLANs Enabled:

Port is member in:
Vlan      Name      Egress rule
-----
1         default  Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.7 SWITCHPORT HYBRID ALLOWED VLAN

Use the switchport hybrid allow vlan add port configuration command to allow vlan on interface. Use the switchport hybrid allows vlan remove port configuration command to remove vlan on interface. You can verify your setting by entering the s show interfaces switchport Privileged EXEC command.

Switch#**configure terminal**

Switch (config)#**interface** {Interface-ID}

Switch(config-if)# **switchport hybrid allowed vlan add** {*VLAN-LIST*}

Switch(config-if)#**switchport hybrid allowed vlan remove** {*VLAN-LIST*}[**(tagged|untagged)**]

switchport hybrid allowed vlan add {*VLAN-LIST*}

Synta

x **switchport hybrid allowed vlan remove** {*VLAN-LIST*}[**(tagged|untagged)**]

VLAN-LIST Specifies the VLAN list to be added or remove.

Paramet

er **(tagged | untagged)** Specifies the member type is tagged or untagged.

Only vlan 1 is untagged member by

Defaul

t default. Default is tagged member when

added.

Mode Port Configuration

Example

T
h
i
s

e
x
a
m
p
l
e

s
e

ts port GigabitEthernet 2 VLAN to join the VLAN 100 as tagged member.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# switchport hybrid allowed vlan add 100-
```

```
105 Switch(config-if)# switchport hybrid allowed vlan
```

```
remove 105 Switch# show interfaces switchport
```

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport hybrid allowed vlan add 100-105
Switch(config-if)# switchport hybrid allowed vlan remove 105
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port: gi2
Port Mode: Hybrid
Orp Status: disabled
Ingress Filtering: disabled
Compatible Frame Type: tagged-only
Ingress Untagged VLAN (MRTM): 100
Trunking VLANs Enabled:
-----
Port is member in:
VLAN      Name      Egress rule
-----
1          Default  Untagged
-----
Forbidden VLANs:
VLAN      Name
-----
```

35.8 SWITCHPORT ACCESS VLAN

Use the switchport access vlan port configuration command to set native vlan on interface. The vlan will be pvid on interface as well. Use the “no” form of this command to restore to default vlan. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport access vlan <1-
```

```
4094> Switch(config-if)# no switchport access
```

vlan

```
switchport access vlan <1-4094>
```

Syntax

```
x no switchport access vlan
```

Parameter<1-4094> Specifies the access

VLAN ID. Default Default is vlan 1

Mode Port Configuration

This example sets Access port gi10 native VLAN ID to 100.

```
Switch#configure terminal
```

```
Switch(config)# interface gi2
```

```
Switch(config-if)# switchport mode
```

```
access Switch(config-if)# switchport
```

Example
e access vlan 4

```
Switch# show interfaces switchport GigabitEthernet 2
```

```
Switch(config)# interface gi2
Switch(config-if)# switchport mode access
Switch(config-if)# switchport access vlan 4
Switch(config-if)# exit
Switch(config)# exit
Switch# show interfaces switchport GigabitEthernet 2
Port: gi2
Port Mode: Access
Stp Status: disabled
Ingress Filtering: enabled
Acceptable Frame Type: untagged-only
Ingress Untagged VLAN ( NATIVE ): 4
Trunking VLANs Enabled:

Port is member in:
Vlan      Name      Egress rule
-----
4         VLAN0004  Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.9 SWITCHPORT TUNNEL VLAN

Use the switchport tunnel vlan port configuration command to set dot1q tunnel vlan on interface. The vlan will be pvid on interface as well. Use the “no” form of this command to remove vlan on interface. The tunnel vlan id will set to reserve vlan 4095. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport tunnel vlan <1-
```

```
4094> Switch(config-if)# no switchport tunnel
```

```
vlan
```

```
switchport tunnel vlan <1-4094>
```

Synta

```
x no switchport tunnel vlan
```

Parameter <1-4094> Specifies the tunnel VLAN

ID. Default Default is vlan 1

Mode Port Configuration

This example sets Tunnel port GigabitEthernet 2 native VLAN to 4.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
switchport mode tunnel
```

Examp
e

```
Switch(config-if)# switchport tunnel vlan 4
```

```
Switch# show interfaces switchport GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode tunnel
Switch(config-if)# switchport tunnel vlan 4
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Tunnel
Swg Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress Untagged VLAN ( NATIVE ) : 4
Trunking VLANs Enabled:

Port is member in:
-----
VLAN      Name                Egress rule
-----
4         VLAN0004            Untagged
-----
Forbidden VLANs:
VLAN      Name
-----
```

35.10 SWITCHPORT TRUNK NATIVE VLAN

Use the switchport trunk native vlan port configuration command to set native vlan on interface. Use the “no” form of this command to restore to default vlan. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport trunk native vlan <1-4094>
```

```
Switch(config-if)# no switchport trunk native vlan
```

```
switchport trunk native vlan <1-4094>
```

Syntax

```
x no switchport trunk native vlan
```

Parameter <1-4094> Specifies the native VLAN

ID. Default Default is vlan 1

Mode Default is vlan 1

This example sets Trunk port GigabitEthernet 2 native VLAN to 4.

```
Switch#configure terminal
```

```
Switch(config)# interface
```

```
GigabitEthernet 2 Switch(config-if)#
```

```
switchport mode trunk
```

Example

```
Switch(config-if)# switchport trunk native vlan 4
```

```
Switch# show interfaces switchport
```

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport mode trunk
Switch(config-if)# switchport trunk native vlan 4
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2

Port : gi2
Port Mode : Trunk
Smp Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 4
Trunking VLANs Enabled:

Port is member in:
Vlan      Name          Egress rule
-----
4         VLAN0004     Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.11 SWITCHPORT TRUNK ALLOWED VLAN

Use the switchport trunk allow vlan add port configuration command to allow vlan on interface. Use the switchport trunk allows vlan remove port configuration command to remove vlan on interface. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

Switch#**configure terminal**

Switch (config)#**interface** {Interface-ID}

Switch(config-if)# **switchport trunk allowed vlan (add | remove) (VLAN-LIST | all)**

Syntax **switchport trunk allowed vlan (add | remove) (VLAN-LIST | all)**

(**add | remove**) Specify the action to add or remove the allowed VLAN list.

Parameter(**VLAN-LIST | all**) Specify the VLAN list or all VLANs to be added or removed.

Mode Port Configuration

This example sets Trunk port GigabitEthernet 2 to add the allowed

VLAN 4. Switch# **configure**

Switch(config)# **interface** GigabitEthernet 2

Switch(config-if)# **switchport trunk allowed vlan**

add 4 Switch# **show interfaces switchport**

Examp
le

GigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport trunk allowed vlan add 4
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Trunk
Group Status : disabled
Ingress Filtering : enabled
Nonnegotiable Frame Type : all
Ingress Disallowed VLANs ( NBIIVE ) : 4
Trunking VLANs Enabled: 4

Port is member in:
Vlan      Name      Egress rule
-----
4         VLAN0004  Untagged

Forbidden VLANs:
Vlan      Name
-----
```

35.12 SWITCHPORT DEFAULT-VLAN TAGGED

Use the `switchport default vlan tagged` port configuration command to become default vlan tagged member. Use the `no` `switchport default vlan tagged` port configuration command to restore to default. You can verify your setting by entering the `show interfaces switchport` Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport default-vlan tagged
```

```
Switch(config-if)# no switchport default-vlan
```

```
tagged
```

```
switchport default-vlan tagged
```

Synta

```
x no switchport default-vlan tagged
```

Default Default is

untagged Mode Port

Configuration

This example sets Trunk port GigabitEthernet 2 membership with the default VLAN to tag.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# switchport default-vlan
```

```
tagged
```

Example Switch# show interfaces switchport GigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport default-vlan tagged
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Hybrid
Group Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Egress UnTagged VLAN ( NATIVE ) : 1
Trunking VLANs Enabled: 0

Port is member in:
Vlan      Name      Egress rule
-----
1         default  Tagged

Forbidden VLANs:
Vlan      Name
-----
```

35.13 SWITCHPORT FORBIDDEN DEFAULT-VLAN

Use the switchport forbidden default-vlan port configuration command to forbid default-vlan on interface. Use the “no” switchport forbidden default-vlan port configuration command to restore to default. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport forbidden default-  
vlan
```

```
Switch(config-if)# no switchport forbidden default-vlan
```

```
switchport forbidden default-vlan
```

Syntax

```
x no switchport forbidden default-vlan
```

Default Default is

allowed Mode Port

Configuration

This example sets the membership of the default VLAN with port GigabitEthernet 2 to Forbidden.

```
Switch#configure terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Switch(config-if)# switchport forbidden default-  
vlan
```

```
Example Switch# show interfaces switchport GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport forbidden default-vlan
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Hybrid
STP Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress Untagged VLAN ( NATIVE ) : 4095
Trunking VLANs Enabled: 4

Port is member in:
VLAN      Name      Egress rule
-----
Forbidden VLANs:
VLAN      Name
-----
1          default
```

35.14 SWITCHPORT FORBIDDEN VLAN

Uses the switchport forbidden vlan add port configuration command to forbid vlan on interface. Use the switchport forbidden vlan remove port configuration command to accept vlan on interface. You can verify your setting by entering the show interfaces switchport Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport forbidden vlan ( add | remove ) VLAN-LIST
```

Syntax **switchport forbidden vlan (add | remove) *VLAN-LIST***

(add | remove) Add or remove forbidden membership.

Parameter *VLAN-LIST* Specify the VLAN list.

Mode Port Configuration

This example sets the membership of the VLAN 4 with port GigabitEthernet 2 to

Forbidden.

```
Switch#configure
```

```
terminal
```

```
Switch(config)# interface GigabitEthernet 2
```

```
Example Switch(config-if)# switchport forbidden vlan add
```

```
4 Switch# show interfaces switchport
```

```
GigabitEthernet 2
```

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport forbidden vlan add 4
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Hybrid
Group Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 4095
Trunking VLANs Enabled: 4

Port is member in:
Vlan      Name      Egress rule
-----
Forbidden VLANs:
Vlan      Name
-----
1          default
4          VLAN0004
```

35.15 SWITCHPORT VLAN TPID

Use the `switchport vlan tpid` port configuration command to set TPID on interface. You can verify your setting by entering the `show running-config` Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch (config)#interface {Interface-ID}
```

```
Switch(config-if)# switchport vlan tpid
```

```
(0x8100|0x88a8|0x9100|0x9200) Syntaxswitchport vlan tpid
```

```
(0x8100|0x88a8|0x9100|0x9200)
```

Parameter(0x8100|0x88a8|0x9100|0x9200) Select TPID to set.

Default Default TPID is 0x8100

Mode Port Configuration

This example sets the TPID to 0x9100 on interface GigabitEthernet 2.

```
Switch#configure terminal
```

```
Example Switch(config)# interface GigabitEthernet 2
```

e

```
Switch(config-if)# switchport vlan tpid
```

```
0x9100
```

```
Switch(config-if)# switchport mode trunk uplink
Switch(config-if)# switchport vlan tpid 0x9100
Switch(config-if)# exit
Switch(config)# do show run
```

35.16 MANAGEMENT-VLAN

Use the management vlan Global Configuration mode command to set management vlan id. Vlan id must be created first. Use the “no” form of this command to restore to default setting. You can verify your setting by entering the show management-vlan Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch(config)# management-vlan vlan <1-4094>
```

```
Switch(config)# no management-vlan
```

```
management-vlan vlan <1-4094>
```

Syntax

```
x no management-vlan
```

Parameter <1-4094> Specify the VLAN ID of management-

vlan. Default Default management vlan is 1.

Mode Global Configuration

The following example specifies that management vlan 2 is

created Switch#configure terminal

```
Switch(config)# vlan 2
```

Example Switch(config)# management-vlan vlan 2

The following example specifies that management-vlan is restored to be default VLAN.

```
Switch(config)# no management-vlan
```

35.17 SHOW VLAN

Display information about vlan entry.

Switch# **show vlan [(VLAN-LIST|dynamic|static)]**

Syntax **show vlan [(VLAN-LIST|dynamic|static)]**

Parameter (VLANLIST|dynamic|static)Specify vlan id to show information or show all static or dynamic vlan entries.

Mode Privileged EXEC

The following example specifies that show vlan

Switch# **show vlan**

Example

```
Switch# show vlan
VLAN Name                Unassigned Ports      Tagged Ports
----
1 | default | gi1-20,lag1-8 |
---
2 | VLAN002 | --- |
---
Static
```

35.18 SHOW VLAN INTERFACE MEMBERSHIP

Display information about vlan membership on interfaces.

Switch# **show vlan VLAN-LIST interfaces *{IF_PORTS}* membership**

Syntax **show vlan VLAN-LIST interfaces *{IF_PORTS}* membership**

Specify vlan to show

Parameter *IF_PORTS* Specify interface is to show

Mode Privileged EXEC

The following example specifies that show vlan interface membership

Example Switch# **show vlan 2 interfaces GigabitEthernet 2 membership**

```
Switch# show vlan 2 interfaces GigabitEthernet 2 membership
-----
VLAN ID : 2
VLAN Type : Static
-----
Port | Membership
-----
gi2 | Excluded
-----
```

35.19 SHOW INTERFACE SWITCHPORT

Display information about default vlan.

Switch# **show interface switchport interfaces**

{/F_PORTS} Syntax **show interface switchport**

interfaces *{/F_PORTS}* Default *IF_PORTS* Specify

interfaces protocol vlan to display Mode Privileged

EXEC

The following example specifies that show interface switchport.

Switch#**configure terminal**

Switch(config)# **interface** GigabitEthernet 2

Switch(config-if)# **switchport trunk allowed vlan**

add 2

ExampleSwitch# **show interfaces switchport** GigabitEthernet 2

```
Switch(config)# interface GigabitEthernet 2
Switch(config-if)# switchport trunk allowed vlan add 2
Switch(config-if)# end
Switch# show interfaces switchport GigabitEthernet 2
Port : gi2
Port Mode : Trunk
Swg Status : disabled
Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress Untagged VLAN ( NATIVE ) : 1
Trunking VLANs Enabled: 2

Port is member in:
Vlan      Name      Egress rule
-----
1         default  Untagged
2         VLAN0002  Tagged

Forbidden VLANs:
Vlan      Name
-----
```

35.20 SHOW MANAGEMENT-VLAN

Display information about management vlan.

Switch# **show management-vlan**

Syntax **show management-vlan**

Mode Privileged EXEC

The following example specifies that show management vlan

Example
Switch# **show management-vlan**

```
Switch# show management-vlan
Management VLAN ID : 00000001
-----
```

VOICE VLAN

Syntax	<code>voice-vlan cos <0-7>[remark]</code>
x	<code>no voice-vlan cos</code>
Parameter	<0-7> Specify the voice VLAN Class of Service value in telephone oui mode remark Specify that the L2 user priority is remarked with the CoS value
Default	The default cos value is 6, remark is

disabled. Mode Global Configuration

The following example show how to set cos value and enable 1p remark function

Switch#**configure terminal**

Example

Switch(config)# **voice-vlan cos 7**

remark Switch# **show voice-vlan**

```
Switch(config)# voice-vlan cos 7 remark
Switch(config)# exit
Switch# show voice-vlan
Administrative Voice VLAN state : enabled
Voice VLAN ID : 7
Voice VLAN Assig : 1440 minutes
Voice VLAN Cos : 7
Voice VLAN 1p Remark: enabled
```


36.7 VOICE-VLAN MODE

Use the voice-vlan mode global configuration command to configure the voice VLAN mode for interface. Use the “no” form to restore to default mode. You can verify your setting by entering the show voice-vlan interfaces Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch(config)#interface {Interface-ID}
```

```
Switch(config-if)#voice-vlan mode
```

```
(auto|manual) Switch(config-if)#no voice-vlan
```

```
mode
```

	voice-vlan mode (auto manual)
Synta	
x	no voice-vlan mode

Paramet	Auto Specifies that the port is identified as a candidate to join the voice VLAN. When a packet with a source OUI MAC address that identifies the remote equipment as voice equipment is seen on the port, the port joins the voice VLAN as a tagged port.
er	

manual Specifies that the port is manually assigned to the voice VLAN.

Default	The default is auto
---------	---------------------

mode. Mode	Interface
------------	-----------

Configuration

Example

- T allowing example how to configure voice mode to manual
- h Switch#configure terminal
- e Switch(config)#interface range gi1-3
- f Switch(config-if)#voice-vlan mode
- o manual
- o Switch# show voice-vlan interfaces GigabitEthernet 1-8

```

Switch(config-if)# interface range gi1-3
Switch(config-if-range)# voice-vlan mode manual
Switch(config-if-range)# end
Switch# show voice-vlan interfaces GigabitEthernet 1-8
Voice VLAN Acctg    : 1440 seconds
Voice VLAN CSD     : 1 s
Voice VLAN Ipsec    : enabled

VLAN 2001
-----
VLAN 2001 | Description
-----
00:00:00 | RSM
00:00:00 | Cisco
00:00:00 | NetScal
00:00:00 | Flangol
00:00:00 | Jansone
00:00:00 | MCC/Phillips
00:00:00 | JEC
00:00:00 | Anyya
00:00:00 | West
00:00:00 | mmanab
00:00:00 | commandpoint
00:00:00 | test_command

Port | State | Port Mode | Cos Mode
-----
11 | Enabled | Manual | All
12 | Enabled | Manual | All
13 | Enabled | Manual | All
14 | Enabled | Auto | Hcp

```

36.8 VOICE-VLAN AGING-TIME

Use the voice vlan aging-time global configuration command to configure the voice VLAN aging timeout. Use the “no” form to restore to default time. You can verify your setting by entering the show voice vlan Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch(config)# voice-vlan aing-time <30-65536>
```

```
Switch(config)# no voice-vlan aing-time
```

```
voice-vlan aing-time <30-65536>
```

Synta

```
x no voice-vlan aing-time
```

Parameter <30-65536> Specify the voice VLAN aging timeout interval in minutes

Default The default aging-timeout value is 1440

minutes Mode Global Configuration

The following example shows how to set aging time. Switch#configure terminal

```
Switch(config)# voice-vlan aging-time
```

Examp
e

```
720 Switch# show voice-vlan
```

```
Switch(config)# voice-vlan aging-time 720
Switch(config)# end
Switch# show voice-vlan
Administrate Voice VLAN state : enabled
Voice VLAN ID : 2
Voice VLAN Aging : 720 minutes
Voice VLAN CoS : 7
Voice VLAN Ip Remark: enabled
```

36.9 SHOW VOICE-VLAN

Use the show voice vlan command in EXEC mode to display the voice VLAN status for all interfaces or for a specific interface if the voice VLAN type is OUI.

Switch# show voice-vlan

Switch# show voice-vlan interfaces *{IF_PORTS}*

show voice-vlan

Syntax

x show voice-vlan interfaces *{IF_PORTS}*

IF_PORTS Specifies interfaces to display voice VLAN settings

Parameter

er in oui mode

Mode Privileged EXEC

The following example show how to display voice vlan oui mode settings

Switch# show voice-vlan

```
Switch# show voice-vlan
Administrative Voice VLAN state : enabled
Voice VLAN ID : 2
Voice VLAN Aging : 720 minutes
Voice VLAN COS : 7
Voice VLAN Ip Remark: enabled
Switch#
```

Example Switch# show voice-vlan interfaces GigabitEthernet 1-4

```
Switch# show voice-vlan interfaces GigabitEthernet 1-4
Voice VLAN Aging : 720 minutes
Voice VLAN COS : 7
Voice VLAN Ip Remark: enabled

OUI table
-----
OUI MAC | Description
-----
0010:0000:0000 | SCOM
0010:0000:0000 | Cisco
0010:0000:0000 | Vestral
0010:001E:0000 | Pingtel
0010:0013:0000 | Siemens
0010:0009:0000 | NEC/Philips
0010:0012:0000 | NEC
0010:0012:0000 | Aways
0010:1002:0000 | "Test"
0010:1002:0000 | Commando
0010:1004:0000 | COMMANDO8TEST
0010:1005:0000 | test_COMMANDO

Port | State | Port Mode | Cos Mode
-----
g11 | Enabled | Manual | All
g12 | Disabled | Manual | All
g13 | Enabled | Manual | All
g14 | Enabled | Auto | Sec
```

STATIC ROUTING

Syntax
x `ipv6 neighbor ipv6-addr vlan vlan-id macaddr`
`no ipv6 neighbor`

ipv6-addr Neighbor ipv6 address

Parameter **vlanid** Vlan interface number

macaddr MAC address of ipv6 neighbor

entry Mode Global configuration

The following example shows how to configure an ipv6 neighbor entry.

Switch# **configure terminal**

Switch(config)# **ipv6 neighbor 2001:01::01:11 vlan 2**

Example 00:00:00:11:11:12

e

Switch# **show ipv6 neighbors**

```
Switch#show ipv6 neighbors 2001:01::01:11 00:00:00:11:11:12
Switch#show ipv6 neighbors
Switch#show ipv6 neighbors
IPv6 Neighbors          IPv6 Address          HW Address           State   Neighbor State
-----
Age: 1      2001:01::01:11      00:00:00:11:11:12   Stale   Stale
Total number of entries: 1
```

POE

Power over Ethernet (PoE) is technology that passes electric power over twisted-pair Ethernet cable to powered devices (PD), such as wireless access points, IP cameras, and VoIP phones in addition to the data that cable usually carries. It enables one RJ45 cable to provide both data connection and electric power to PDs instead of having a separate cable for each.




Fig 38.1 PoE Concept

PoE Standard	PoE Common Name	Power Output	Year	Comment
IEEE 802.3af	PoE	15.40 W	2003	12.95 W
IEEE 802.3at	PoE+	30 W	2009	25.50 W
IEEE 802.3bt Type 3	4PPoE, Ultra PoE, UPoE	60 W	2018	51 W
IEEE 802.3bt Type 4	Ultra PoE, UPoE, PoE++	Up to 100 W	2018	71 W for connected device

PoE, PoE+ and PoE++ Comparison Chart

As PoE/PoE+/PoE++ technology has developed the amount of power that can be sent over Ethernet cable has increased. IEEE-compliant PoE/PoE+/PoE++ switches and injectors can output anywhere from 12 watts to 100 watts of power per port.

38.1 POE PORT SETTING

Use the poe command in interface mode to enable port poe power supply. Use the "no" poe command in interface mode to disable port poe power supply. You can check the port poe

working status by using the show poe Privileged EXEC command.

```
Switch#configure terminal
```

```
Switch(config-if)# poe
```


38.2 POE PORT SCHEDULE SETTING

Use the `poe schedule` command in interface mode to set port poe power supply time. Use the “**no**” `poe schedule` command in interface mode to clear port poe power supply time. You can check the port poe work time setting view through the web.

```
Switch#configure terminal
```

```
Switch(config-if)#poe schedule week days hour
```

```
{hours} Switch(config-if)#no poe schedule week days
```

```
hour {hours}
```

```
                poe schedule week days hour hours  
Syntax  
x                no poe schedule week days hour hours
```

```
                days Port poe power supply  
Parameter  
er                days hours Port poe power  
                supply hours
```

```
                All ports open POE function all day by  
Default  
t                default. (Poe-enabled device)
```

```
Mode                interface configuration.
```

The following example shows how to config poe schedule.

```
Switch#configure terminal  
  
Switch(config)# interface GigabitEthernet 1  
Example Switch(config-if)# poe schedule week mon  
  
hour 1
```

Note: The configured time has a deviation of about 0~10

m

inutes.

```
Switch(config)# interface GigabitEthernet 1  
Switch(config-if)# poe schedule week Mon hour 1
```